



#### PHONES

(044) 360-7-130  
 (050) 336-0-130  
 (063) 788-0-130  
 (067) 233-0-130  
 (068) 282-0-130

# 130

COM.UA

## Internet store of autogoods



#### ICQ

294-0-130  
 597-0-130

#### SKYPE

km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |  
 CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |  
 GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules • Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps • LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronic • Front parktronic • Combined parktronic • Rear-view mirrors • Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation • Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Carsits • Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors • Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid • Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

<http://130.com.ua>

FOR CAR USE ONLY/NUR FÜR AUTOMOBIL GEBRAUCH/POUR APPLICATION AUTOMOBILE UNIQUEMENT/PARA USO EN AUTOMÓVILES/SOLO PER L'UTILIZZO IN AUTOMOBILE/ENDAST FÖR BILBRUK/ALLEEN VOOR GEBRUIK IN DE AUTO/ТОЛЬКО ДЛЯ ИСПОЛЬЗОВАНИЯ В АВТОМОБИЛЯХ/DO UŻYCIA TYLKO W SAMOCHODZIE/ΓΙΑ ΧΡΗΣΗ ΜΟΝΟ ΣΕ ΑΥΤΟΚΙΝΗΤΟ



## IN-DASH APP/DVD RECEIVER ICS-X8



**DIVX MP3 AAC**



- **OWNER'S MANUAL**  
Please read before using this equipment.
- **BEDIENUNGSANLEITUNG**  
Lesen Sie diese Bedienungsanleitung  
bitte vor Gebrauch des Gerätes.
- **MODE D'EMPLOI**  
Veuillez lire avant d'utiliser cet appareil.
- **MANUAL DE OPERACIÓN**  
Léalo antes de utilizar este equipo.
- **ISTRUZIONI PER L'USO**  
Si prega di leggere prima di utilizzare il  
attrezzatura.
- **ANVÄNDARHANDLEDNING**  
Innan du använder utrustningen bör du läsa  
igenom denna användarhandledning.
- **GEBRUIKERSHANDLEIDING**  
Lees deze aanwijzingen aandachtig alvorens  
dit toestel te gebruiken.
- **РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ**  
Прочтите настоящее руководство перед  
началом использования оборудования.
- **INSTRUKCJA OBSŁUGI**  
Prosimy zapoznać się z tą instrukcją przed  
przystąpieniem do użytkowania urządzenia.
- **ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΗΣ**  
Παρακαλούμε διαβάστε το πριν  
χρησιμοποιήσετε τη συσκευή.

**ALPINE ELECTRONICS MARKETING, INC.**  
1-1-8 Nishi Gotanda,  
Shinagawa-ku,  
Tokyo 141-0031, Japan  
Phone 03-5496-8231

**ALPINE ELECTRONICS OF AMERICA, INC.**  
19145 Gramercy Place, Torrance,  
California 90501, U.S.A.  
Phone 1-800-ALPINE-1 (1-800-257-4631)

**ALPINE ELECTRONICS OF CANADA, INC.**  
777 Supertest Road, Toronto,  
Ontario M3J 2M9, Canada  
Phone 1-800-ALPINE-1 (1-800-257-4631)

**ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD.**  
161-165 Princes Highway, Hallam  
Victoria 3803, Australia  
Phone 03-8787-1200

**ALPINE ELECTRONICS GmbH**  
Wilhelm-Wagenfeld-Str. 1-3, 80807 München, Germany  
Phone 089-32 42 640

**ALPINE ELECTRONICS OF U.K. LTD.**  
Alpine House  
Fletchamstead Highway, Coventry CV4 9TW, U.K.  
Phone 0870-33 33 763

**ALPINE ELECTRONICS FRANCE S.A.R.L.**  
(RCS PONTOISE B 338 101 280)  
98, Rue de la Belle Etoile, Z.I. Paris Nord II,  
B.P. 50016, 95945 Roissy Charles de Gaulle  
Cedex, France  
Phone 01-48638989

**ALPINE ITALIA S.p.A.**  
Viale C. Colombo 8, 20090 Trezzano  
Sul Naviglio (MI), Italy  
Phone 02-484781

**ALPINE ELECTRONICS DE ESPAÑA, S.A.**  
Portal de Gamarra 36, Pabellón, 32  
01013 Vitoria (Alava)-APDO 133, Spain  
Phone 945-283588

**ALPINE ELECTRONICS (BENELUX) GmbH**  
Leuvensesteenweg 510-B6,  
1930 Zaventem, Belgium  
Phone 02-725-13 15

EN

DE

FR

ES

IT

SE

NL

RU

PL

GR

130.com.ua

# Contents

## Operating Instructions

### WARNING

<b>WARNING</b> .....	<b>7</b>
<b>CAUTION</b> .....	<b>7</b>
<b>NOTICE</b> .....	<b>8</b>
<b>Discs Playable on This Unit</b> .....	<b>9</b>

### Features

Home Screen and Favorites .....	13
Switching between Simple mode and Info mode .....	13
Using the Media View button .....	14
Using the Media Control buttons .....	14
Easy-to-touch UP/DOWN switch .....	14

### Getting Started

Accessory List .....	15
Location of Controls .....	15
Touch operation .....	15
Turning Power On or Off .....	16
Turning the System On .....	16
Initial System Start-Up .....	16
Inserting/Ejecting a Disc .....	16
Inserting the Disc .....	16
Removing the Disc .....	16
Adjusting the Monitor Viewing Angle .....	17
Adjusting the Volume .....	17
Using the Home Screen .....	17
Displaying the Home Screen .....	17
Switching the Home Screen Page .....	17
Customizing the Home Screen .....	17
Using the Favorites Menu .....	18
Display the Favorites Menu .....	18
Customizing the Favorites Menu .....	18
Switching between Simple Mode & Info Mode .....	19
Selecting an Item in a List .....	20
About the Indicator Display .....	20

### Radio

Listening to the Radio .....	21
Presetting Stations Manually .....	21
Presetting Stations Automatically .....	21
Tuning to Preset Stations .....	22

### RDS

Turning AF (Alternative Frequencies) On or Off .....	23
Receiving Traffic Information .....	23
Receiving Traffic Information Manually .....	24
PTY (Programme Type) Tuning .....	24
Priority News .....	24
Displaying Radio Text .....	24

### CD/MP3/WMA/AAC

Playback .....	25
Repeat Play .....	25
M.I.X. (Random Play) .....	26
Selecting Folders (concerning MP3/WMA/AAC) .....	26
Searching from CD Text .....	26
File/Folder Name Search (Concerning MP3/WMA/AAC) .....	26
Folder Name Search mode .....	26
File Name Search mode .....	26
About MP3/WMA/AAC .....	26

### DVD

Playing a Disc .....	29
If a Menu Screen Appears .....	30
Numeric Keypad Input Operations .....	30
Displaying the Top Menu Screen .....	30
Displaying the Menu Screen .....	30
Displaying the Menu Operation Mode Screen .....	30
Stopping Playback (PRE STOP) .....	30
Stopping Playback .....	31
Fast-forwarding/Fast-reversing .....	31
Finding the Beginnings of Chapters/Tracks/Files .....	31
Playing Still Frames (Pausing) .....	31
Forward frame-by-frame Playback .....	31
Slow Motion Playback .....	31



Selecting Programme/Playlist .....	32
Selecting Folders .....	32
Repeat Playback .....	32
Searching by Title/Programme Number .....	32
Searching Directly by Chapter Number .....	33
Searching by Programme .....	33
Searching by Playlist .....	33
Searching for a Desired Video File .....	33
Folder Name Search mode .....	33
File Name Search mode .....	33
Switching the Angle .....	33
Switching the Audio Tracks .....	34
Switching the Subtitles (Subtitle Language) .....	34
About DivX® .....	34

## Setup

### Audio Setup

Audio Setup Operation .....	35
Setting the Balance/Fader/Subwoofer .....	35
Adjusting the Balance/Fader .....	35
Turning Subwoofer ON/OFF .....	35
Adjusting the Subwoofer Level .....	35
Setting the Subwoofer Phase .....	35
Setting the Volume for Each Application .....	35
Setting the MX (Media Xpander) .....	36
Equalizer Presets (Bass Max EQ) .....	36
Download Sound Setting .....	36
Setting Defeat .....	37
Adjusting the Time Correction (Time Correction) .....	37
Adjusting the Crossover Settings (X-OVER) .....	37
Adjusting the Parametric Equalizer Curve (Parametric EQ) .....	38
About Time Correction .....	39
About the Crossover .....	40

### Display Setup

Display Setup Operation .....	40
Switching Display Modes .....	41
Adjusting the Live Contrast .....	41
Selecting the Visual EQ Mode (Factory's setting) .....	41
Adjusting Brightness .....	41
Adjusting Colour of Picture .....	41
Adjusting Tint of Picture .....	41

Adjusting Image Contrast .....	41
Adjusting Picture Quality .....	41
Saving and calling the adjusted picture quality .....	41

### General Setup

General Setup Operation .....	42
Date/Time Setting .....	42
Setting of Calendar Display Pattern Switching .....	42
Setting the Clock Display .....	42
RDS Time Display .....	42
Setting the Time .....	42
Language Setting .....	42
Setting the Scroll .....	42
Format settings .....	42
Setting the Menu Language .....	43
About ICS-X8 .....	43
Displaying the Product Information .....	43
Checking the DivX® Registration .....	43
Initializing the System .....	43
BLUETOOTH Setting .....	43
Setting the BLUETOOTH On/Off .....	43
Setting the BLUETOOTH Device .....	43
Automatic Connection setting .....	44
Setting the Passcode .....	44
Changing the Character Code of the Phone Book .....	44
Sound Feedback Setting .....	44
Adjusting the Operating Sound .....	44
GPS Setting .....	44
Connecting to a GPS antenna .....	44
Displaying the GPS Information .....	44
Screen/LED Customize .....	44
Setting the Brightness of the Backlighting .....	45
Adjusting the Dimmer of Button Lighting at Night .....	45
Changing the Colour of the Home Button .....	45
Adjusting the Minimum Level of Backlight .....	45
Switching the Display Colour .....	45
Adjusting the Touch Panel .....	45
Remote Sensor Setting .....	46
Security Code Setting .....	46
Setting Security code .....	46

### Application Setup

Application Setup Operation .....	46
Camera Setting .....	47

Setting the Camera Input .....	47
Adjusting the Rear Camera Guide .....	47
Navigation Setting .....	48
Setting the Navigation Mode .....	48
Setting the Navigation Interruption .....	48
Adjusting Nav. Mix Level .....	48
AUX Setting .....	48
Setting the AUX Mode .....	48
Setting the AUX3 .....	49
RSE Setting .....	49
Setting the Rear Seat Entertainment System .....	49
Phone Setting .....	49
Setting Received Calls Automatically .....	49
Selecting the Output Speaker .....	49
Adjusting the Receive Volume .....	49
Adjusting the Transmit Volume .....	49
Adjusting the Calling Volume .....	49
Disc Setting .....	50
Changing the language setting .....	50
Setting of the Menu Language .....	50
Setting of the Audio Language .....	50
Setting of the Subtitle Language .....	50
Changing the Country Code Setting .....	50
Setting the Rating Level (Parental Lock) ....	50
Setting the TV Screen Mode .....	51
Radio Setting .....	51
PI SEEK Setting .....	51
Receiving RDS Regional (Local) Stations .....	51
Switching the Display Language of PTY (Programme Type) .....	51
Setting PTY31 (Emergency Broadcast) Reception .....	51
Setting the TUNER (FM) Tone Quality (Tuner Condition) .....	52

## BLUETOOTH Operation

Setup Before Using .....	53
About BLUETOOTH .....	53
About the Hands-Free Phone .....	53
Before Using BLUETOOTH .....	53
Connecting a BLUETOOTH Device .....	53
Disconnecting the BLUETOOTH Connection .....	53
Changing the connecting BLUETOOTH Device .....	53

### Hands-Free Phone Control

Answering a Call .....	54
Adjusting ringtone volume .....	54

Hanging up the Telephone .....	54
Calling .....	54
Dialling a Number In Call History .....	54
Dialing a Number In the Phone Book .....	54
Entering a Phone Number to Make a Call .....	54
Using Short Cut Dialling to Make a Call ....	55
Redial Function .....	55
Operations During a Conversation .....	55
Adjusting the Speech Volume .....	55
Changing the Voice Output .....	55
DTMF (Touch-Tone) Function .....	55
Phone Book Function .....	55
Synchronising the Phone Book .....	55
Adding the Phone Book .....	56
Deleting the Phone Book Entries .....	56
Percent Search Function .....	56
Assigning as a Short Cut Dialling Number ....	56

### BLUETOOTH Audio

Playback .....	58
Repeat Play .....	58
M.I.X. (Random Play) .....	59
Selecting Groups .....	59
Search Function .....	59

## Navigation System (Optional)

Switching the Navigation Screen (Optional) .....	59
---	----

## Auxiliary Device (Optional)

Operating Auxiliary Devices (Optional) .....	60
Operating an External DVD Player .....	60
Change to the External DVD Mode .....	60
About the DVD Operation Screen .....	60
Operating an External DVD Changer .....	61
Change to the External DVD Changer Mode .....	61
About the DVD Changer Operation Screen .....	61
Operating the Mobile Digital TV Receiver (DVB-T) .....	61
Changing to the Mobile Digital TV Receiver (DVB-T) Mode .....	61
About the DVB-T operation screen .....	62
Operating a TV .....	62
Change to the TV mode .....	62
About the TV operation screen .....	62

## Camera Operation (Optional)

Rear Camera Operation .....	63
Displaying the rear view video while the car is in reverse .....	63
Switching the Image Pattern for the Rear Camera .....	63
Guide Display ON/OFF Setting .....	63
Adjusting the Caution Display Location .....	63
About the Rear Camera Guide .....	63
Calibration when connected to HCE-C300R .....	66

## USB Memory (Optional)

Playback .....	67
Repeat Play .....	67
Random Play (M.I.X.) .....	68
Random Play (M.I.X. ALL) .....	68
Searching for a Desired Song .....	68
File/Folder Name Search .....	68
Tag Search .....	68
Direct Up/Down Function .....	69
Select the desired Folder (Folder up/down) .....	69

## iPod/iPhone (Optional)

Playback .....	71
Searching for a Music File .....	71
Searching for a Desired Video File .....	71
Percent Search Function .....	72
Alphabet Skip Function .....	72
Direct Up/Down Function .....	72
Search Position Memory .....	72
Repeat Play .....	72
Random Play (Shuffle) .....	73
Random Play (Shuffle All) .....	73
Displaying in Cover Flow .....	73

## Nokia(Optional)

DISCLAIMER .....	74
Using a Nokia Application .....	74
Displaying the Nokia Drive .....	74
Play Nokia Music .....	74

## Information

Product Software Update .....	75
About DVDs .....	75
List of Language Codes .....	76

List of Country Codes .....	77
In Case of Difficulty .....	79
If this Message Appears .....	80
Specifications .....	82

---

# Installation and Connections

<b>Warning</b> .....	<b>83</b>
<b>Caution</b> .....	<b>83</b>
<b>Precautions</b> .....	<b>83</b>
Installation .....	84
Connections .....	87
System Example .....	89

# Operating Instructions

## WARNING



### WARNING

**This symbol means important instructions. Failure to heed them can result in serious injury or death.**

#### **INSTALL THE PRODUCT CORRECTLY SO THAT THE DRIVER CANNOT WATCH TV/VIDEO UNLESS THE VEHICLE IS STOPPED AND THE EMERGENCY BRAKE IS APPLIED.**

It is dangerous for the driver to watch TV/Video while driving a vehicle. Installing this product incorrectly enables the driver to watch TV/Video while driving. This may cause a distraction, preventing the driver from looking ahead, thus causing an accident. The driver or other people could be severely injured.

#### **DO NOT WATCH VIDEO WHILE DRIVING.**

Watching the video may distract the driver from looking ahead of the vehicle and cause an accident.

#### **DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE.**

Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

#### **KEEP THE VOLUME AT A LEVEL WHERE YOU CAN STILL HEAR OUTSIDE NOISES WHILE DRIVING.**

Excessive volume levels that obscure sounds such as emergency vehicle sirens or road warning signals (train crossings, etc.) can be dangerous and may result in an accident. LISTENING AT LOUD VOLUME LEVELS IN A CAR MAY ALSO CAUSE HEARING DAMAGE.

#### **MINIMIZE DISPLAY VIEWING WHILE DRIVING.**

Viewing the display may distract the driver from looking ahead of the vehicle and cause an accident.

#### **DO NOT DISASSEMBLE OR ALTER.**

Doing so may result in an accident, fire or electric shock.

#### **USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.**

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

#### **KEEP SMALL OBJECTS SUCH AS SCREWS OUT OF THE REACH OF CHILDREN.**

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

#### **USE THE CORRECT AMPERE RATING WHEN REPLACING FUSES.**

Failure to do so may result in fire or electric shock.

#### **DO NOT BLOCK VENTS OR RADIATOR PANELS.**

Doing so may cause heat to build up inside and may result in fire.

#### **USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS.**

Use for other than its designed application may result in fire, electric shock or other injury.

#### **DO NOT PLACE HANDS, FINGERS OR FOREIGN OBJECTS IN INSERTION SLOTS OR GAPS.**

Doing so may result in personal injury or damage to the product.



### CAUTION

**This symbol means important instructions. Failure to heed them can result in injury or material property damage.**

#### **HALT USE IMMEDIATELY IF A PROBLEM APPEARS.**

Failure to do so may cause personal injury or damage to the product. Return it to your authorized Alpine dealer or the nearest Alpine Service Center for repairing.

#### **KEEP FINGERS AWAY WHILE THE MOTORIZED FRONT PANEL OR MOVING MONITOR IS IN MOTION.**

Failure to do so may result in personal injury or damage to the product.

## NOTICE

### Product Cleaning

Use a soft dry cloth for periodic cleaning of the product. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

### Temperature

Be sure the temperature inside the vehicle is between +45°C (+113°F) and 0°C (+32°F) before turning your unit on.

### Moisture Condensation

You may notice the disc playback sound wavering due to condensation. If this happens, remove the disc from the player and wait about an hour for the moisture to evaporate.

### Damaged Disc

Do not attempt to play cracked, warped, or damaged discs. Playing a bad disc could severely damage the playback mechanism.


### Maintenance

If you have problems, do not attempt to repair the unit yourself. Return it to your Alpine dealer or the nearest Alpine Service Station for servicing.

### Never Attempt the Following

Do not grip or pull out the disc while it is being pulled back into the player by the automatic reloading mechanism.

Do not attempt to insert a disc into the unit when the unit power is off.



### Inserting Discs

Your player accepts only one disc at a time for playback. Do not attempt to load more than one disc.

Make sure the label side is facing up when you insert the disc. "Disc error" will be displayed on your player if you insert a disc incorrectly. If "Disc error" continues to be displayed even though the disc has been inserted correctly, push the RESET switch with a pointed object such as a ballpoint pen.

Playing a disc while driving on a very bumpy road may result in skips, but this will not scratch the disc or damage the player.

### Irregular Shaped Discs


Be sure to use round shaped discs only for this unit and never use any special shaped discs.

Use of special shaped discs may cause damage to the mechanism.



### New Discs

To prevent the disc from jamming, "Disc error" is displayed if discs with irregular surfaces are inserted or if discs are inserted incorrectly. When a new disc is ejected immediately after initial loading, use your finger to feel around the inside of the centre hole and outside edge of the disc. If you feel any small bumps or irregularities, this could inhibit proper loading of the disc. To remove the bumps, rub the inside edge of the hole and outside edge of the disc with a ballpoint pen or other such instrument, then insert the disc again.




### Installation Location

Make sure the ICS-X8 will not be installed in a location subjected to:

- Direct sun and heat
- High humidity and water
- Excessive dust
- Excessive vibrations

### Correct Handling

Do not drop the disc while handling. Hold the disc so you will not leave fingerprints on the surface. Do not affix tape, paper, or gummed labels to the disc. Do not write on the disc.



### Disc Cleaning


Fingerprints, dust, or soil on the surface of the disc could cause the DVD player to skip. For routine cleaning, wipe the playing surface with a clean, soft cloth from the centre of the disc to the outer edge. If the surface is heavily soiled, dampen a clean, soft cloth in a solution of mild neutral detergent before cleaning the disc.






## Disc Accessories

There are various accessories available on the market for protecting the disc surface and improving sound quality. However, most of them will influence the thickness and/or diameter of the disc. Using such accessories can cause operational problems. We recommend not using these accessories on discs played in Alpine DVD players.



Transparent Sheet



Disc Stabilizer

Operation of some of the functions of this unit is very complex. Because of this, it was deemed necessary to place these functions into a special screen. This will restrict operation of these functions to times when the vehicle is parked. This ensures the focus of the driver's attention will be on the road and not on the ICS-X8. This has been done for the safety of the driver and passengers. Setup operations cannot be made if the car is moving. The car must be parked and the parking brake must be engaged for the procedure described in the Owner's Manual to be valid. The warning "Unable to operate while driving." will be displayed if any attempts are made to perform these operations while driving.

- The ICS-X8 draws minimal current even when its power switch is turned off. If the switched power (ignition) lead of the ICS-X8 is connected directly to the positive (+) post of the vehicle's battery, the battery may be discharged.*  
*An SPST (Single-Pole, Single-Throw) switch (sold separately) can be added to simplify this procedure. Then, you can simply place it in the OFF position when you leave the vehicle. Turn the SPST switch back ON before using the ICS-X8. For connecting the SPST switch, refer to the "Connection Diagram of SPST Switch (sold separately)" (page 86). If the power (ignition) lead is unswitched, it must be disconnected from the battery post should the vehicle be left unused for an extended period of time.*

## Discs Playable on This Unit

### Playable Discs

The discs listed below can be played on this unit.

	Mark (logo)	Recorded Content	Disc size
DVD Video		Audio + Video	12 cm*
Music CD		Audio	12 cm
DivX®		Audio + Video	12 cm

\* Two-layer DVD disc compatible

The formatted discs listed below can be played on this unit.

	CD-R/ CD-RW	DVD-R/ DVD-RW	DVD+R/ DVD+RW
CD Format	○		
MP3 Format ("mp3")	○	○	○
WMA Format ("wma")	○	○	○
AAC Format ("aac," "m4a")	○	○	○
DVD Video Format		○	○
DVD-VR Format		○	
DivX Format ("avi," "divx")	○	○	○

- Discs that are not finalized cannot be played back.

---

### Discs that cannot be played

DVD-ROMs, DVD-RAMs, CD-ROMs (excluding MP3/WMA/AAC files), photo CDs, etc.

---

### DualDisc

This unit is not compatible with DualDisc.

Using a DualDisc may cause unit malfunction, and may cause disc damage when the disc is inserted/ejected.

---

### DVD region number (playable region number)

This DVD player will play back any disc whose region number is 2 (or All). DVDs with a region number other than those listed below, cannot be played on this DVD player.



---

### Using compact discs (CD/CD-R/CD-RW)

If you use unspecified compact discs, correct performance cannot be guaranteed.

You can play CD-Rs (CD-Recordables)/CD-RWs (CD-ReWritables) which have been recorded only on audio devices. You can also play CD-Rs/CD-RWs containing MP3/WMA/AAC formatted audio files.

- Some of the following discs may not play on this unit:  
Flawed discs, discs with fingerprints, discs exposed to extreme temperatures or sunlight (e.g., left in the car or this unit), discs recorded under unstable conditions, discs on which a recording failed or a re-recording was attempted, copy-protected CDs which do not conform to the audio CD industry standard.
- Use discs with MP3/WMA/AAC files written in a format compliant with this unit. For details, see pages 26 and 27.

To customers using CD-R/CD-RW

- If a CD-R/CD-RW cannot be played back, make sure the last recording session was closed (finalized).
- Finalize the CD-R/CD-RW if necessary, and attempt playback again.

---

### Tips for making your own discs

The ICS-X8 plays DVD Video, DivX®, Audio CD and has a built in MP3/WMA/AAC decoder.

The following information is designed to help you create your own music CDs (either Audio CD or MP3/WMA/AAC encoded CD-R/RW files).

### What is the difference between an Audio and MP3/WMA/AAC CD?

An Audio CD is the same format as the commercial CDs you buy in the store (also known as CD-DA). MP3 (MPEG Audio Layer 3)/WMA (Windows Media Audio)/AAC (Advanced Audio Coding) is a data file that uses a compression scheme to reduce the size of the music file\*.

### Multisession CD-R/RW:

Once a recording has been stopped, this is considered one session. If the disc is not closed (finalized), additional data may be added. Once this additional data has been recorded, this becomes a "multisession" CD.

- \* If the first session on a disc containing both CD-DA data and MP3/WMA/AAC data is a CD-DA file, only CD-DA files will be played.

### Properly formatted MP3/WMA/AAC Discs:

Use ISO9660 formatting to insure proper playback. You may use standard ISO naming Level 1 (8.3 DOS standard), Level 2 (32 characters) or Joliet (Windows or Macintosh long filenames) file naming conventions\*.

- \* Please consult the Owner's manual for additional information.

---

### On handling compact discs (CD/CD-R/CD-RW)

- Do not touch the surface.
- Do not expose the disc to direct sunlight.
- Do not affix stickers or labels.
- Clean the disc when it is dusty.
- Make sure that the disc is smooth and flat.
- Do not use commercially available disc accessories.

**Do not leave the disc in the car or the unit for a long time. Never expose the disc to direct sunlight.**

Heat and humidity may damage the disc and you may not be able to play it again.

---

---

## Using DVD-Rs/DVD-RWs/DVD+Rs/DVD+RWs

- This unit is compatible with discs recorded in the standard DVD-Video format.
- Note that discs not finalized (processed to enable to play on playback-only DVD players) cannot be played on this DVD player.
- Some discs may not play back, depending on the recording device and disc format.
- Discs or files utilizing copy protection, may not be playable. Some recording systems may not properly format copied files to enable proper playback.
- In the following cases, the disc may not play on this unit: discs recorded by certain DVD recorders, certain irregular discs, flawed discs, dirty discs, when the pickup lens of this DVD player is dirty, or when moisture condensation has occurred inside the unit.
- Be sure to follow all cautions included with your DVD-Rs/DVD-RWs/DVD+Rs/DVD+RWs discs.
- Do not put stickers, seals, or tape on the label side of DVD-Rs/DVD-RWs/DVD+Rs/DVD+RWs.
- Compared to the regular discs, DVD-Rs/DVD-RWs/DVD+Rs/DVD+RWs are more affected by heat, moisture, and direct sunlight. If left in a car, etc., damage may occur and it might not play on this unit.
- The operable temperature range for disc playback is as follows:  
DVD-R/DVD-RW: -25 ~ +70°C  
DVD+R/DVD+RW: +5 ~ +55°C

---

## Disc terminology

### Title

If titles are programmed for the DVD, these are the largest units of division of the information recorded on the disc.

### Chapter

Each Title may also be divided into smaller divisions, called chapters. These can be specific scenes or musical selections.

---

## Protecting the USB connector

- Only an iPod/iPhone, USB memory or Nokia Phone can be connected to the USB connector on this unit. Correct performance using other USB products cannot be guaranteed.
- If the USB connector is used, be sure to use only the supplied connector cable with the unit. A USB hub is not supported.
- Depending on the connected USB memory device, the unit may not function or some functions may not be performed.
- The audio file format that can be played back on the unit is MP3/WMA/AAC.
- The video file format that can be played back on the unit is DivX®.
- Artist/song name, etc., can be displayed. Certain, special characters may not be correctly displayed.



## CAUTION

*Alpine accepts no responsibility for lost data, etc., even if data, etc., is lost while using this product.*

---

## On Handling USB Memory


- This unit can control a memory storage device that supports the USB Mass Storage Class (MSC) protocol. Playable audio file formats are MP3, WMA and AAC.
- USB memory function is not guaranteed. Use USB memory according to the terms of agreement. Read the USB memory Owner's Manual thoroughly.
- Avoid usage or storage in the following locations:
  - Anywhere in the car exposed to direct sunlight or high temperatures.
  - Anywhere the possibility of high humidity or corrosive substances are present.
- Fix the USB memory in a location where driver operation will not be hindered.
- USB memory may not function correctly at high or low temperature.
- Use only certified USB memory. Note that even certified USB memory, may not function correctly depending on its type or state.
- Depending on the settings of the USB memory type, memory state or encoding software, the unit may not play back or display properly.
- Files protected by DRM (Digital Rights Management), cannot be played back on this unit. These include AAC formatted files purchased from the iTunes Store and WMA or other files with some form of copyright protection.
- USB memory may take time to start playback. If there is a particular file other than audio in the USB memory, it may take considerable time before the file is played back or searched.
- The unit can play back "mp3," "wma" or "m4a" file extensions.
- Do not add the above extensions to a file other than audio data. This non-audio data will not be recognized. The resulting playback may contain noise that can damage speakers and/or amplifiers.
- It is recommended to back up important data on a personal computer.
- Do not remove the USB device while playback is in progress. Change application to something other than USB, then remove the USB device to prevent possible damage to its memory.

- 
- *This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.*
  - *Manufactured under licence from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.*
  - *Windows Media, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.*
  - *iPhone, iPod, iPod classic, iPod nano, iPod touch, and iTunes are trademarks of Apple Inc., registered in the U.S. and other countries.*
  - *“Made for iPod,” and “Made for iPhone,” mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance.*
  - *© 2010 Nokia. All rights reserved. Nokia and Works with Nokia are trademarks or registered trademarks of Nokia Corporation.*
  - *DivX<sup>®</sup>, DivX Certified<sup>®</sup> and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.*
  - *The BLUETOOTH<sup>®</sup> word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Alpine Electronics, Inc. is under licence.*
  - *“MPEG Layer-3 audio coding technology licenced from Fraunhofer IIS and Thomson.”*
  - *“Supply of this product only conveys a licence for private, non-commercial use and does not convey a licence nor imply any right to use this product in any commercial (i.e. revenue-generation) real time broadcasting (terrestrial, satellite, cable and/or any other media), broadcasting/streaming via internet, intranets and/or other networks or in other electronic content distribution systems, such as pay-audio or audio-on-demand applications. An independent licence for such use is required. For details, please visit <http://www.mp3licensing.com>”*

# Features


## Home Screen and Favorites

You can easily switch to the application of your choice from the Home Screen or Favorites. The Home Screen displays icons for applications usable with this unit. Favorites is a shortcut function that displays up to 4 icons on the screen you are using. The icon layout is customizable for your convenience.



## Switching between Simple mode and Info mode

The media screen display has two options to select from, Simple or Info mode. Info mode has additional operation buttons in the display.






## Using the Media View button

You can switch between the Navigation screen and the main screen for the current media source with just one touch.


<When the Navigation screen is displaying>



## Using the Media Control buttons

For operations like moving up or down between songs, in addition to using the operation buttons displayed on the screen, you can also use the Media Control buttons on the unit itself. This allows you to press a Media Control button to select a song even if the main screen for the media is not being displayed.

The operation of the Media Control buttons may change depending on the media you are using. A guide will display on the screen to show which switch controls what function. In this owner's manual, when the Media Control button guide and the onscreen button display are the same, only onscreen button operations are described.



## Easy-to-touch UP/DOWN switch

UP/DOWN buttons are displayed with large arrows on either side of the screen.





# Getting Started

## Accessory List

• ICS-X8.....	1
• Power cable.....	1
• Mounting sleeve .....	1
• Bracket key.....	2
• Flush head screw (M5x8) .....	6
• Screw (M5x8).....	8
• Rubber cap.....	1
• Hex bolt .....	1
• Face plate.....	1
• AUX/PRE OUT cable .....	1
• Camera cable.....	1
• USB extension cable (L type).....	1
• USB extension cable (I type).....	1
• Nokia Dock cable .....	1
• Microphone.....	1
• Owner's Manual.....	1 set

## Location of Controls



- ① **Home/⌂ button**  
Touch the Home button to call up Favorites.  
Press the Home button to call up the Home Screen.  
Press and hold for at least 5 seconds to turn the power off.
- ② **Remote Sensor**  
Point the remote control transmitter towards the remote sensor within a range of 2 metres.
- ③ **∨/∧ button**  
Press to adjust the volume.
- ④ **RESET switch**  
The system of this unit is reset.
- ⑤ **Media View button**  
• When using the Navigation system:  
Pressing toggles between the Navigation screen and Audio/Visual screen.  
• When not using the Navigation system:  
If **X** appears on the screen, pressing the  button will close the screen in the same way as touching **[X]**.

- ⑥ **Media Control button 1/2/3**  
This action varies according to the Audio/Visual application. (Track Up/Down, PLAY/PAUSE, Fast reverse/Fast forward, etc)
- ⑦ **⬆ button**  
Recalls the Open/Tilt screen. Executes display open/close, angle adjustment, and disc eject.

### Optional Remote Control Interface Box

This unit is operable using the vehicle's secondary radio controls. An Alpine Remote Control Interface Box (optional) is required. For details, contact your Alpine dealer.

### Controllable with Remote Control

This unit can be controlled with an optional Alpine remote control. For details, consult your Alpine dealer. Point the optional remote control transmitter at the remote control sensor.

### About the button descriptions used in this Owner's Manual

The buttons found on the face of the unit are expressed in bold (e.g. **Home/⌂**). The buttons found on the touch-screen display are shown in bold within brackets, **[ ]** (e.g. **[X]**).

## Touch operation

You can operate the system by using the touch panel on the screen.

- *Be sure to touch the onscreen button lightly with the pad of your finger to protect the display.*
- *If you touch a button and there is no reaction, remove your finger from the display once, and try again.*
- *Onscreen buttons that cannot be operated appear dull in colour.*

### Common onscreen buttons

**[<]**: Returns to the previous screen. Depending on the function, this button may cancel the operations performed on the screen.

**[X]**: Closes the window.



## Turning Power On or Off

Some of this unit's functions cannot be performed while the vehicle is in motion. Be sure to stop your vehicle in a safe location and apply the parking brake, before attempting these operations.

### 1 Turn the ignition key to the ACC or ON position.

The system turns on.

- When turned on, the system displays the last mode screen that was displayed before the ignition key was turned off. For example, if the unit is in radio mode when ignition is turned off, it will remain in radio mode when ignition is turned back on.


### 2 Press and hold the **Home/⏻** button for at least 5 seconds to turn the power off.

- The unit can be turned on by pressing any button.
- The ICS-X8 is a precision device. Careful handling of the unit should provide you with years of trouble-free operation.

## Turning the System On

With the Alpine system, when the ignition key is turned to ACC or ON, the opening screen will be automatically displayed.

### 1 When the system is used for the first time, the language selection menu is displayed. There are 15 languages to choose from. Touch [**▲**] or [**▼**] to scroll the list, and then touch the desired language.



- You can also scroll through lists by touching the screen and sliding your finger up and down.

### 2 Touch [**OK**].

The radio screen is displayed.


- Some of this unit's functions cannot be performed while the vehicle is in motion. Be sure to stop your vehicle in a safe location and apply the parking brake before attempting these operations.

## Initial System Start-Up

Be sure to press the RESET switch when using the unit for the first time, after changing the car battery, etc.

### 1 Turn off the unit power.

### 2 Press RESET switch with a ballpoint pen or similar pointed object.



## Inserting/Ejecting a Disc


### Inserting the Disc

#### 1 Press **▲**.

The Open/Tilt screen is displayed.

#### 2 Touch [**Open**].

#### 3 Insert the disc with the label side facing up.



Insert the disc until it is automatically pulled into the unit. The unit starts to play the disc.

### Removing the Disc

#### 1 Press **▲**.

The Open/Tilt screen is displayed.

#### 2 Touch [**▲ Disc**].

The monitor will open. Then the disc is ejected.

When the disc has been ejected part way, take it out.

#### 3 Touch [**Close**], or press **▲**.

- If the disc does not eject after touching [**▲ Disc**], press and hold **▲** for at least 5 seconds.
- Do not apply shock to the monitor when it is open as it may result in malfunction of the unit.
- The monitor will stop at the set tilt angle when closing.

#### CAUTION

Keep hands (or any other object) away from the monitor while it is opening or closing to avoid damage or injury. The back of the monitor tends to become very warm under normal operating conditions. This is not a malfunction, but care should be taken to avoid prolonged contact with it.

## Adjusting the Monitor Viewing Angle

Adjust the monitor's angle for better visibility.

- 1 **Press ▲.**  
The Open/Tilt screen is displayed.
- 2 **Touch [▲ Up] or [▼ Down] of "Tilt" to adjust the desired monitor angle.**  
The monitor angle can be adjusted in 5 stages.
- 3 **Touch [X] to return to the normal mode.**
  - The screen colour will vary when viewed at certain angles. Adjust the screen angle for the best viewing position.
  - If the voltage of the vehicle's battery power is low, the screen may blink when the screen angle is changed. This is normal and not a malfunction.

## Adjusting the Volume

**Adjust the volume by pressing ▼ or ▲.**

Volume decreases/increases continuously by pressing and holding ▼ or ▲.


Volume: 0 - 35

## Using the Home Screen

The Home Screen displays icons for applications that can be operated with this device. You can easily display the Home Screen and switch to the application of your choice.

### Displaying the Home Screen

- 1 **Press the Home button.**  
The Home screen is displayed. The Home button will blink slowly.




Touching an icon on the Home screen will switch to the screen for the selected application.

- 2 **Press Home button again to deactivate Home screen.**
  - A play button icon is displayed on the selected icon.
  - Icons on the Home screen are not displayed or their enabled/disabled indication is not displayed according to the setting and/or connection status of the external devices.

## Switching the Home Screen Page

To view the previous page or next page, slide your finger left or right while touching the background (avoiding the application icons).




Number of dots display

- The dots on the lower of the screen indicate the number of pages and the page currently displayed.  
Number of dots: page number  
White dot: current page

## Customizing the Home Screen

### Rearranging the Application Icons

- 1 **Touch and hold an application icon for at least 2 second.**  
The display will change to Icon Rearrangement mode. (X) will display on the icon.
- 2 **Drag and drop the icon to the desired location.**



The icon moves.

- 3 **Touch [X] to return to the normal mode.**
  - To move to the previous or next page, drag the icon to the left or right edge of the Home screen. Hold your finger down for at least 2 seconds after fixing the icon on the destination page to move it. Dragging an icon to the right edge of the screen on the last page will display a new page.

## Deleting an Application Icon

- 1 Touch and hold an application icon for at least 2 second.**  
The display changes to Icon Rearrangement mode. "✕" will display on the icon.
- 2 Touch [✕] on the icon.**  
The confirmation dialog screen appears.
- 3 Touch [OK].**  
The selected icon is deleted.
  - The Radio, Disc and Setup icons cannot be deleted.
  - If you delete a device icon, the connection for that device will be automatically set to OFF.
  - After deleting the icon for a device, if you set the connection of the device to ON, or reconnect the device, the icon will reappear on the Home screen.

## Using the Favorites Menu

Favorites is a shortcut function that lets you easily switch to the application of your choice. Favorites menu displays on your current screen and can register up to 4 icons for applications you use frequently.

### Display the Favorites Menu

- 1 Touch the Home button.**  
The Favorites menu is displayed.



Favorites menu

Touching an icon on the Favorites menu will switch to the screen of the selected application.

- 2 Touch Home button again to deactivate Favorites menu.**

### Customizing the Favorites Menu


You can customize Favorites in Rearrangement mode on the Home screen.

#### Rearranging Application Icons

- 1 Press the Home button.**  
The Home screen is displayed. The Home button will blink slowly.
- 2 Touch and hold an application icon for at least 2 second.**  
The display will change to Icon Rearrangement mode.



- 3 Touch an icon in Favorites or displayed on the Home screen and drag and drop to the desired location in Favorites.



- If you drag icons already inside the Favorites menu, you can rearrange their order. If you drag an icon displayed on the Home screen to the Favorites menu, it will replace an icon in the Favorites menu.

- 4 Touch [X] to return to the normal mode.

#### Deleting an Application Icon from the Favorites Menu

- 1 Press the **Home** button.

The Home screen is displayed. The Home button will blink slowly.

- 2 Touch and hold an application icon for at least 2 second.

The display will change to Icon Rearrangement mode.

- 3 Drag and drop the icon you want to delete to an area outside Favorites.

Icons you drag outside the Favorites menu will be deleted.



- 4 Touch [X] to return to the normal mode.

## Switching between Simple Mode & Info Mode

You can select between the Simple mode and Info mode for the main screen display for audio/visual applications. To display all the operation buttons, switch to Info mode.


### Touch [i].

The screen changes to Simple mode or Info mode.

#### ■ Display example for Simple mode




#### ■ Display example for Info mode



# Selecting an Item in a List

To scroll through a list, perform the following operations.


**Touch the screen and slide your finger up and down.**  
The screen will scroll along with your finger movement.  
Also, you can touch [▲] and [▼].



- After touching the screen, move your finger away from the screen before dragging and that item will be selected.

# About the Indicator Display

The Indicator Bar at the bottom of the screen displays various types of information, like the current time.



- ① The clock display  
You can switch between the 12 hour display and 24 hour display options (See page 42).
- ② Lights up when connected to a BLUETOOTH compatible device.  
[BT icon]: BLUETOOTH connection to audio device  
[HFP icon]: BLUETOOTH connection to Hands Free Phone  
Blinks while reconnecting. Does not display when connection is set to OFF.
- ③ Indicates the signal strength level of the connected BLUETOOTH compatible device.  
Displayed when BLUETOOTH setting is ON.

0	1	2	3	No Service
[Icon]	[Icon]	[Icon]	[Icon]	No Service

- ④ Indicates the signal strength level of GPS radio.  
Displayed when GPS antenna is connected.


GPS positioning status	No positioning	2D positioning	3D positioning
Icon	GPS	GPSII	GPSIII

- ⑤ RDS indicator  
For details on RDS, refer to page 23 to 24.
- ⑥ [Media View] button guide  
Indicates the action that occurs when the [Media View] button is pressed.  
→ [Music icon]: Audio/Visual screen  
→ [Navigation icon]: Navigation screen  
→ [Phone icon]: Phone screen\*
- \* Displayed when transmitting or during a call.
- ⑦ Media Control button guide  
Displays the operation icon (guide) corresponding to the currently selected audio/video application (source).  
Indicates the respective action for when Media Control button 1, 2 or 3 is pressed.


# Radio

## ■ Display example for Radio main screen

### Simple mode



### Info mode



- ① Preset No. Indicator
- ② Band display
- ③ Frequency display
- ④ Preset button
- ⑤ Audio Setup button (See "Audio Setup Operation" on page 35)
- ⑥ Media Control button guide (See page 14)

• For instructions on switching between Simple mode and Info mode, refer to "Switching between Simple Mode & Info Mode" (page 19).

## Listening to the Radio

- 1 Press the Home button.**  
The Home screen is displayed.
- 2 Touch [Radio].**  
The radio mode is activated and the display changes to the Radio mode screen.
- 3 Touch [Band] to select the desired radio band.**  
Each touch changes the bands as follows:  
FM-1 → FM-2 → FM-3 → MW → LW → FM-1

- 4 Press Media Control button 2 to choose the tuning mode.**

DX SEEK      Local SEEK      MANUAL



- There are two modes you can select for auto tuning, DX and Local:
- DX (Distance) mode;  
Both strong and weak stations will be tuned in.
- Local mode;  
Only strong stations will be tuned in.  
The initial setting is DX.
- If "PRESET" or "PTY" appears in the Media Control button 2 guide, press Media Control button 2 repeatedly until a tuning mode is displayed.

- 5 Touch [◀◀], [▶▶] or [◀], [▶] to change the radio frequency up or down respectively.**

In manual mode, touch and hold to change the frequency continuously.

- Operations can be performed in the same way by pressing Media Control buttons 1 or 3. Refer to "Using the Media Control buttons" (page 14).

## Presetting Stations Manually

- 1 Tune in a desired radio station you wish to store in the preset memory by manual or automatic seek tuning.**
- 2 Touch and hold any one of the preset buttons for at least 2 seconds.**  
The selected station is stored.
  - To toggle between preset buttons 1-3 and preset buttons 4-6, touch [◀] or [▶] on either side of the preset buttons.
- 3 Repeat the procedure to store up to 5 other stations onto the same band.**  
To use this procedure for other bands, simply select the desired band and repeat the procedure.  
A total of 30 stations can be stored in the preset memory (6 stations for each band; FM1, FM2, FM3, MW or LW).
- If a preset memory has already been set in the same preset number, it will be cleared and the new station will be memorized.

## Presetting Stations Automatically

The tuner can automatically seek and store 6 strong stations in the selected band in order of signal strength.

**After selecting the desired band, touch [A.Memo].**

The tuner automatically seeks and stores 6 strong stations into the preset buttons in order of signal strength.  
When automatic storing has completed, the station stored in the preset 1 is selected.

- If no stations are stored, the tuner will return to the original station you were listening to before the automatic storing procedure began.
- You can cancel this process by touching [A.Memo] while the tuner is automatically seeking stations. Cancelling will return the tuner preset to the previous setting.

---

## Tuning to Preset Stations

---

You can tune in the preset stations in memory on either band using its preset number.

**1 Touch [Band] repeatedly until the desired band is displayed.**

**2 Touch any one of the preset buttons that has a station stored to it.**

Or, when "PRESET" appears in the guide after pressing Media Control button 2 repeatedly, touch [◀], [▶], or press Media Control button 1 (◀) or Media Control button 3 (▶).

The preset station is received.

- To toggle between preset buttons 1-3 and preset buttons 4-6, touch [◀] or [▶] on either side of the preset buttons.
- You can check the selected Preset No. via the Preset No. Indicator.


# RDS

## ■ Display example for RDS Information

### Simple mode



### Info mode



- ① AF indicator
- ② Info area
- ③ RDS indicator

- For instructions on switching between Simple mode and Info mode, refer to “Switching between Simple Mode & Info Mode” (page 19).

## Turning AF (Alternative Frequencies) On or Off

The RDS (Radio Data System) is a radio information system using the 57 kHz subcarrier of regular FM broadcasts. The RDS allows you to receive a variety of information such as traffic information, station names, and to automatically re-tune to a stronger transmitter that is broadcasting the same programme.

### 1 Press the **Home** button.

The Home screen is displayed.

### 2 Touch **[Radio]**.

The radio mode is activated and the display changes to the Radio mode screen.

### 3 Touch **[AF]** to select the **AF (Alternative Frequency) ON or OFF mode**.

In AF ON mode, the “AF” Indicator lights up.

- RDS mode is not be displayed for the MW or LW band.
- When the AF ON mode is selected, the unit automatically tunes to a strong signal station in the AF list.
- Use the AF OFF mode when automatic re-tuning is not required.

### Tips

- If the unit receives the PTY31 (Emergency Broadcast) signal, the unit will show “Alarm-Alarm!” in the display only when PTY31 is set to on. For operation, refer to “Setting PTY31 (Emergency Broadcast) Reception” (page 51).
- The RDS digital data includes the following:
 

PI	Programme Identification
PS	Programme Service Name
AF	List of Alternative Frequencies
TP	Traffic Programme
TA	Traffic Announcement
PTY	Programme Type
EON	Enhanced Other Networks
- Refer to page 51 about “PI SEEK Setting,” “Receiving RDS Regional (Local) Stations,” “Switching the Display Language of PTY (Programme Type)” and “Setting PTY31 (Emergency Broadcast) Reception.”

## Receiving Traffic Information

### Touch **[TA]** to turn on the Traffic Information mode.

The TA indicator lights up.

When the traffic information station is tuned in, the TP indicator lights up.

Traffic information is heard only when it is being broadcast. If traffic information is not being broadcast, the unit is set in the standby mode.

When a traffic information broadcast begins, the unit automatically receives it and the display shows “T.Info.”

When the traffic information broadcast is over, the unit will automatically be set to the standby mode.

- If the traffic information broadcast signal falls below a certain level, the unit remains in the receiving mode for 1 minute. If the signal remains below a certain level for over 70 seconds, “TA” will blink in the display.
- If you do not want to listen to traffic information being received, touch **[TA]** to skip that traffic information message. The T. Info mode will remain in the ON position to receive the next traffic information message.
- If the volume level is changed while receiving traffic information, the changed volume level will be memorized. When traffic information is received next time, the volume level will be automatically adjusted to the level memorized.
- If the Traffic Information mode is activated, the unit automatically switches to radio source (even if you select another source) and receives the traffic information broadcast. When the traffic information is finished, the unit returns to the previous source.



---

## Receiving Traffic Information Manually

---

**1 Touch [TA] to turn on the Traffic Information mode.**  
The TA indicator lights up.

**2 Touch [◀◀] or [▶▶].**  
Seeks the broadcast station which is broadcasting the traffic information.

- You can seek the traffic information in DX Seek mode or Local Seek mode. Press **Media Control button 2** repeatedly to switch modes.
- Operations can be performed in the same way by pressing **Media Control buttons 1 or 3**. Refer to "Using the Media Control buttons" (page 14).

---

## PTY (Programme Type) Tuning

---

**1 Touch [🔍 PTY].**  
The Select PTY list screen is displayed.

**2 Touch the selected programme type to start searching for a station in the type.**  
If no PTY station is found, "No PTY." will be displayed.

**3 To select the station in the PTY, press Media Control button 2 repeatedly during reception of a PTY station to display "PTY" in the guide. And then, touch [◀] [▶], or press Media Control button 1 (◀) or Media Control button 3 (▶).**

---

## Priority News

---

This function gives priority to the News programme. Whenever the News programme broadcasts, it will interrupt the programme you are currently listening to.

**Touch [News] to activate the PRIORITY NEWS mode.**

The "NEWS" indicator appears in the display. Touch [News] again to deactivate the Priority News mode and return to the programme you were previously listening to.

---

## Displaying Radio Text

---

Text messages from a radio station can be displayed.

**1 Tune in a radio station that transmits text messages.**

**2 Touch the Info area (②) (page 23) in the FM radio mode to activate the Radio Text mode.**

**3 To deactivate the Radio Text mode, touch the Info area again.**


# CD/MP3/WMA/AAC

## ■ Display example for MP3/WMA/AAC main screen

### Simple mode



### Info mode



- ① Current song no./Total song no.
- ② Status Indicator  
The Indicator displays during Repeat and M.I.X. playback.
- ③ Song title
- ④ Artist title
- ⑤ Album title
- ⑥ Next file (song) title
- ⑦ Elapsed time
- ⑧ Audio Setup button (see “Audio Setup Operation” on page 35)

- If there is no CD text, the message “NO TEXT” appears.
- For instructions on switching between Simple mode and Info mode, refer to “Switching between Simple Mode & Info Mode” (page 19).

## Playback

### 1 Press the Home button.

The Home screen is displayed.

### 2 Touch [Disc].

The display shows the Disc mode screen.

When a disc is inserted into the disc slot of this unit, with the label side facing up, the unit starts playback of the disc.

### 3 Touch [◀◀] or [▶▶] to select the desired track (file).

#### Returning to the beginning of the current track (file):

Touch [◀◀].

#### Fast reverse :

Touch and hold [◀◀].

#### Advancing to the beginning of the next track (file) :

Touch [▶▶].

#### Fast forward :

Touch and hold [▶▶].

### 4 To pause playback, press Media Control button 2 (▶/||).

Pressing Media Control button 2 (▶/||) again will resume playback.

- Operations can be performed in the same way by pressing **Media Control buttons 1 or 3**. Refer to “Using the Media Control buttons” (page 14).
- The ICS-X8 can play back MP3/WMA/AAC files saved to CD or DVD. Use a format compliant with this unit.  
For further information about playing or storing MP3/WMA/AAC files, refer to pages 26 and 27 before using the unit.
- Any file protected by DRM (Digital Rights Management) copy protection, cannot be played back on this unit.
- If a disc contains both audio data and MP3/WMA/AAC data, this unit plays back only the audio data.
- The track display for CD audio data playback shows the track numbers recorded on the disc.
- If an MP3/WMA/AAC disc with many files and folders is played, it may take longer than normal to start playback.
- The playback time may not be correctly displayed when a VBR (Variable Bit Rate) recorded file is played back.

## Repeat Play

### Touch [↺] to repeatedly play back.

The tracks (files) will be played repeatedly.

The repeat mode switches every time the button is touched.

CD:

Repeat → (OFF) → Repeat



MP3/WMA/AAC:

Repeat → Repeat Folder\* → (OFF) → Repeat



- \* Only files in a folder are repeatedly played back.
- If the Repeat Play mode is activated during M.I.X. playback, the M.I.X. mode will be cancelled.

## M.I.X. (Random Play)

### Touch [⌂] during playback.

The tracks (files) on the disc will be played back in a random sequence.

The M.I.X. mode switches every time [⌂] is touched.

CD:

M.I.X. → (OFF) → M.I.X.

⌂[ALL] ⌂[ALL]

MP3/WMA/AAC:

M.I.X. Folder\* → M.I.X. File → (OFF) → M.I.X. Folder\*

⌂■ ⌂■ ⌂■

\* Only files in a folder are played back in random sequence.

- If the M.I.X. mode is activated during Repeat playback, the Repeat Play mode will be cancelled.
- If you select a track by using the search mode, the M.I.X. play mode will be cancelled.

## Selecting Folders (concerning MP3/WMA/AAC)

Folders can be changed when the screen is in Info mode.

Touch [◀■] or [■▶] to select the folder.

## Searching from CD Text

### 1 Touch [🔍 (Search)] during playback.

The CD text search screen is displayed.

### 2 Touch the selected track name.

The selected track will be played back.

- For details on how to scroll through the list, refer to “Selecting an Item in a List” (page 20).
- After selecting a track via a CD text search, touch [◀] on the CD main screen to display the search screen.

## File/Folder Name Search (Concerning MP3/WMA/AAC)

### 1 Touch [🔍 (Search)] during playback.

The search mode is activated.

### 2 Touch [AUDIO].

The folder name list screen is displayed.

### Folder Name Search mode

### 3 Touch [▶] in the desired folder.

The first file in the selected folder is played back.

### File Name Search mode

### 3 Touch the desired folder name.

The File name of the selected folder is displayed.

### 4 Touch the desired file name.

The selected file is played back.

- To return to the previous hierarchy, touch [◀].
- For details on how to scroll through the list, refer to “Selecting an Item in a List” (page 20).
- After selecting a folder via a Folder name search, touch [◀] on the main screen to display the folder search screen.
- After selecting a file via a File name search, touch [◀] on the main screen to display the file search screen.

## About MP3/WMA/AAC

### CAUTION

Except for private use, duplicating audio data (including MP3/WMA/AAC data) or distributing, transferring, or copying it, whether for free or for a fee, without permission of the copyright holder is strictly prohibited by the Copyright Act and by international treaty.

### What is MP3?

MP3, whose official name is “MPEG Audio Layer 3,” is a compression standard prescribed by the ISO, the International Standardization Organization and MPEG which is a joint activity institution of the IEC.

MP3 files contain compressed audio data. MP3 encoding is capable of compressing audio data at extremely high ratios, reducing the size of music files to as much as one-tenth their original size. This is achieved while still maintaining near CD quality. The MP3 format realizes such high compression ratios by eliminating the sounds that are either inaudible to the human ear or masked by other sounds.

### What is AAC?

AAC is the abbreviation for “Advanced Audio Coding,” and is a basic format of audio compression used by MPEG2 or MPEG4.

### What is WMA?

WMA, or “Windows Media™ Audio,” is compressed audio data. WMA is similar to MP3 audio data.

### Method for creating MP3/WMA/AAC files

Audio data is compressed using software with MP3/WMA/AAC codecs. For details on creating MP3/WMA/AAC files, refer to the user's manual for that software.

MP3/WMA/AAC files that are playable on this device have the file extensions.

MP3: “mp3”

WMA: “wma” (ver. 7.x, 8.x, 9.x are supported)

AAC: “m4a”

WMA is not supported for the following files, Windows Media Audio Professional, Windows Media Audio 9 Voice or Windows Media Audio 9 Pro Lossless.

There are many different versions of the AAC format. Confirm that the software being used conforms to the acceptable formats listed above. It's possible that the format may be unplayable even though the extension is valid. Playback of AAC files encoded by iTunes is supported.

### Supported playback sampling rates and bit rates

#### MP3

Sampling rates: 48 kHz, 44.1 kHz, 32 kHz, 24 kHz, 22.05 kHz, 16 kHz, 12 kHz, 11.025 kHz, 8 kHz

Bit rates: 8 - 320 kbps

#### WMA

Sampling rates: 48 kHz, 44.1 kHz, 32 kHz, 22.05 kHz, 16 kHz, 11.025 kHz, 8 kHz

Bit rates: 48 - 320 kbps

#### AAC

Sampling rates: 48 kHz, 44.1 kHz, 32 kHz, 24 kHz, 22.05 kHz, 16 kHz, 12 kHz, 11.025 kHz, 8 kHz

Bit rates: 16 - 320 kbps

This device may not play back correctly depending on sampling rates.

### ID3 tags/WMA tags

This device supports ID3 tag v1.0, v1.1, v2.2, v2.3, v2.4, and WMA tag Ver.1.x. If tag data is in an MP3/WMA/AAC file, this device can display the title (track title), artist name, and album name ID3 tag/WMA tag data (maximum 64 characters).

For non-supported characters, blank character, "No Title" is displayed.

The number of characters may be limited, or not correctly displayed, depending on the tag information.

### Playing back MP3/WMA/AAC

MP3/WMA/AAC files are prepared, then written to a CD-R, CD-RW (DVD-R/DVD-RW/DVD+R/DVD+RW) using CD-R writing software and USB memory.

- Maximum numbers of playable files / folders  
Disc: 1,000 files/folders (including Root Folder/DivX® file)  
USB memory: 10,000 files/folders (including Root Folder/DivX® file)
- \* If 2 USB memory devices are connected: 15,000 files/folders total
- Largest playable file size: 512 MB

Playback may not be performed if a disc exceeds the limitations described above.

If a file/folder name is long, the maximum possible number of files may decrease.

- Both Audio and Video files are counted if their formats are playable on this unit.

### Media supported

The media that this device can play back are CD-ROMs, CD-Rs, CD-RWs, DVD-Rs, DVD-RWs, DVD+Rs, DVD+RWs and USB memory.

### Corresponding File Systems

This device supports discs formatted with ISO9660 Level 1 or Level 2, UDF1.02 and UDF1.02(ISO Bridge).

Under the ISO9660 standard, there are some restrictions to remember.

The maximum nested folder depth is 8 (including the root directory). File names are limited to 256 characters (including the extension).

Valid characters for folder/file names are letters A-Z (all caps), numbers 0-9, and '\_' (underscore).

This device can play back discs in Joliet, Romeo, etc., and other standards that conform to ISO9660. However, sometimes the file names, folder names, etc., are not displayed correctly.


### Formats supported

This device supports CD-ROM Mode1, CD-ROM XA Mode2(Form1&2), Mixed Mode CD and Multi-Session.

This device cannot correctly play back discs recorded with Track At Once or packet writing.

### Order of files

Files are played back in the order that the writing software writes them to the disc. Therefore, the playback order may not be what's expected. Verify the writing order in the software's documentation. The playback order of the folders and files is as follows. (The following numbers may differ from actually displayed numbers.)



### Terminology

#### Bit rate

This is the "sound" compression rate specified for encoding. The higher the bit rate, the higher the sound quality, but also the larger the files.

#### Sampling rate

This value shows how many times per second the data is sampled (recorded). For example, music CDs use a sampling rate of 44.1 kHz, so the sound is sampled (recorded) 44,100 times per second. The higher the sampling rate, the higher the sound quality, but also the larger the volume of data.

#### Encoding

Converting music CDs, WAVE (AIFF) files, and other sound files into the specified audio compression format.

#### Tag

Song information such as track titles, artist names, album names, etc., written into MP3/WMA/AAC files.

#### Root folder

The root folder (or root directory) is found at the top of the file system. The root folder contains all folders and files. It is created automatically for all burned discs.

# DVD

## ■ Display example for DVD Video main screen


### Simple mode



### Info mode 1/2



### Info mode 2/2



## ■ Display example for DVD-VR main screen

### Info mode 1/2



### Info mode 2/2



## ■ Display example for DivX® main screen

### Info mode



- ① Title no.
- ② Chapter no.
- ③ Information display  
DVD-Video:  
Audio signal output/Subtitle/Angle  
DVD-VR:  
Programme name or Playlist name/Recording information/  
DISC name/Audio signal output/Subtitle  
DivX®:  
Title name/Artist name/Audio signal output/Subtitle
- ④ Elapsed time
- ⑤ Total playback time
- ⑥ Programme no. or Playlist no.
- ⑦ File no.
- ⑧ Total file no.
- ⑨ Audio Setup button (See "Audio Setup Operation" page 35)
- ⑩ Display Setup button (See "Display Setup Operation" page 40)
- ⑪ Disc Setup button (See "Disc Setting" page 50)

• For instructions on switching between Simple mode and Info mode, refer to "Switching between Simple Mode & Info Mode" (page 19).

Disc types that can be used for each heading are represented by the following marks.



DVD Commercial Video discs (used for the distribution of movies, etc.) or a DVD-R/DVD-RW, DVD+R/DVD+RW recorded in a video mode can be used.



DVD-R/DVD-RW discs recorded in DVD-VR mode can be used.



CD-R/CD-RW/DVD-R/DVD-RW/DVD+R/DVD+RW discs that are recorded in the DivX® mode can be used.

### The DVD operation screen display

Touch the screen while the DVD playback screen is displayed.

The DVD operation screen is displayed.



- The operation screen changes to the visual screen in the DVD mode for 5 seconds after an operation has been performed.
- If you try to activate the DVD while driving, the display will show the warning-Picture off for your safety.
- Some operations cannot be carried out depending on the disc or playback screen.

## Playing a Disc


### WARNING

It is dangerous for the driver to watch the DVD/TV/Video while driving the vehicle. The driver may be distracted from looking ahead and an accident could occur.

Install the ICS-X8 correctly so that the driver cannot watch DVD/TV/Video unless the vehicle is stopped and the emergency brake is applied.

If the ICS-X8 is not installed correctly, the driver will be able to watch the DVD/TV/Video while driving the vehicle and may be distracted from looking ahead causing an accident. The driver or other people could be severely injured.

### Caution

- Not all functions will operate for every DVD. See the individual DVD's instructions for details on the features supported.
- Fingerprints on a disc may adversely affect playback. If a problem occurs, remove the disc and check for fingerprints on the playback side. Clean the disc if necessary.
- If you switch the power or Ignition key OFF or change sources during playback, playback will continue where you left off when you resume playback.
- If you try to perform an invalid operation (based on the type of disc being played), the following mark is displayed on the monitor screen: 

- **Play Position Memory Function**  
Even if you turn power off or switch the Ignition key to OFF during playback or change the source, playback will continue from the point where playback stopped when the power is turned ON again.

## 1 Press the **Home** button.

The Home screen is displayed.

## 2 Touch **[Disc]**.

The display shows the Disc mode screen.

Or insert a disc with the label side facing up. The unit starts to play the disc.

- The reverse side of a double-sided DVD will not be played automatically.  
Remove the disc, turn it over, and reinsert it.
- DO NOT insert discs containing maps for the navigation system.  
Doing so could result in damage.
- Refer also to "Disc Setting" (page 50).
- While reading a DivX® file, the fast-forwarding/fast-reversing and repeat functions, etc. cannot be used.
- A DivX® file that exceeds 4GB cannot be played back.

## If a Menu Screen Appears

On DVD mode, menu screens may appear automatically. If this happens, perform the operation described below to start playback.

### Direct Menu Operations (DVD-V)


**Touch the DVD menu directly.**

- Some operations cannot be performed depending on the disc.

### Menu Operations (DVD-V)

#### 1 Touch [Key].


The menu operation mode will be displayed.



Touch [] [] to change the Key panel location from right to left or vice-versa.

Touch [Return] to return to the previous display.

#### 2 Select a desired menu item by touching [▼], [▲], [◀] or [▶].



- Touching [] in the operation panel returns to the screen in step 1.


#### 3 Touch [Enter] to confirm the selected item.

## Numeric Keypad Input Operations (DVD-V)

#### 1 After touching [Page 1/2], touch [10Key].

The numeric keypad input mode screen appears

#### 2 Touch a desired number.



Touch [] to delete an entered number.

Touch [Delete All] to delete all entered number.

#### 3 Touch [Enter] on the numeric keypad mode screen to confirm your selection.

Touch [] to hide the keypad display.

## Displaying the Top Menu Screen (DVD-V)

When a DVD contains two or more titles, the top menu screen appears.

**Touch [Top Menu].**

The top menu screen appears.

- To perform necessary operations, refer to "If a Menu Screen Appears" (page 30).

## Displaying the Menu Screen (DVD-V)

With a DVD having two or more menus, a menu screen will appear for the programmes available, in addition to the main programmes.

**Touch [Menu].**

The Root menu screen appears.

- To perform necessary operations, refer to "If a Menu Screen Appears" (page 30).

## Displaying the Menu Operation Mode Screen (DVD-V)

**Touch [].**

The menu operation mode screen appears.

- To perform necessary operations, refer to "If a Menu Screen Appears" (page 30).

## Stopping Playback (PRE STOP)

(DVD-V) (DVD-VR) (DivX)

Touch the stop button during playback to stop playback. That position is stored in the memory.

#### 1 Touch [■] during playback.

"Pre ■" indicator is displayed.

#### 2 Press Media Control button 2 (▶/II) in the PRE STOP mode.

Playback starts from the position at which it was stopped.

- For some discs, the position at which playback was stopped may not be accurate.



## Stopping Playback DVD-V DVD-VR DivX

**Touch [■] twice or touch and hold [■] for at least 2 seconds during playback.**

"■" indicator is displayed, and playback stops.

- Playback starts from the beginning when **Media Control button 2** (▶/II) is pressed while playback is stopped.

## Fast-forwarding/Fast-reversing

DVD-V DVD-VR DivX

- 1 **During playback, touch and hold [◀◀] (Fast-reverse) or touch and hold [▶▶] (Fast-forward).**

**DVD-Video, DVD-VR:**

Touch and hold for more than 1 second to forward/reverse at double speed.

Every time you touch [◀◀]/[▶▶] during fast- reverse/ fast- forward, the speed changes as follows: 2x → 8x → 32x → 2x.

**DivX®:**

Touch and hold for more than 1 second to forward/reverse at 8x speed.

Every time you touch [◀◀]/[▶▶] during fast- reverse/ fast- forward, the speed changes as follows: 8x → 16x → 32x → 8x.

- For a DivX® file that does not contain index information, the fast forward and the reverse option is not available.

- 2 **Pressing Media Control button 2 (▶/II) to return to normal playback.**

- Operations can be performed in the same way by pressing **Media Control buttons 1 or 3**. Refer to "Using the Media Control buttons" (page 14).
- No sound is played back during fast-forwarding/fast-reversing.
- On DVD mode, the menu screen may reappear during fast-forwarding/fast-reversing.
- This operation may not be possible on certain discs.

## Finding the Beginnings of Chapters/Tracks/Files DVD-V DVD-VR DivX

**During playback, touch [◀◀] or [▶▶].**

The chapter/track/file switches each time the button is touched, and playback of the selected chapter/track/file starts.

▶▶: Touch this to start playback from the beginning of the following chapter, track or file.

◀◀: Touch this to start playback from the beginning of the current chapter, track or file.

- Operations can be performed in the same way by pressing **Media Control buttons 1 or 3**. Refer to "Using the Media Control buttons" (page 14).
- Some DVDs do not have chapters.

### Supplementary explanations

"Chapters" are divisions of movies or musical selections on DVDs.

## Playing Still Frames (Pausing)

DVD-V DVD-VR DivX

- 1 **During playback, Press Media Control button 2 (▶/II).**

- 2 **Press Media Control button 2 (▶/II) to resume playback.**

- No sound is played during the still frame mode.
- The image or sound may stop temporarily when playback starts from the pause mode. This is not a malfunction.

## Forward frame-by-frame Playback

DVD-V DVD-VR

- 1 **In the pause mode, touch [▶▶].**

The picture advances by one frame each time the button is touched.

- 2 **Press Media Control button 2 (▶/II) to return to normal mode.**

- You can perform operations in the same way by pressing **Media Control button 3**. Refer to "Using the Media Control buttons" (page 14).
- No sound is output during forward frame-by-frame playback.
- You cannot execute reverse frame-by-frame playback.

## Slow Motion Playback DVD-V DVD-VR

- 1 **When [▶▶] is touched and held while in the pause mode, the 1/8th speed slow motion playback mode is set.**

Furthermore, when touched and held [▶▶] again, the slow motion speed switches to 1/2 the normal speed.

- 2 **Press Media Control button 2 (▶/II) to play back.**

- You can perform operations in the same way by pressing **Media Control button 3**. Refer to "Using the Media Control buttons" (page 14).
- No sound is played during slow motion playback.
- 1/2, 1/8 are approximate speeds. The actual speed differs from disc to disc.
- You cannot execute reverse slow motion playback.



## Selecting Programme/Playlist (DVD-VR)

You can select the previous or next programme when in programme playback mode. You can select the previous or next playlist in the playlist playback mode.

### 1 Touch [**◀ Program**] [**Program ▶**] or [**◀ Playlist**] [**Playlist ▶**] to select the previous or next programme or playlist.

- Touching [**◀ Program**] or [**◀ Playlist**] will play the previous programme or playlist from the first chapter.
- Touching [**Program ▶**] or [**Playlist ▶**] will play the next programme or playlist from the first chapter.

- Playlist selection can only be executed via a disc with a playlist.

## Selecting Folders (DivX)

Touch [**◀■**] or [**■▶**] to select the folder.

- Touch [**◀■**] to play from the first file of the previous folder.
- Touch [**■▶**] to play from the first file of the next folder.


## Repeat Playback (DVD-V) (DVD-VR) (DivX)

Use this function to play the disc's titles, chapters or tracks, etc., repeatedly.

Touch [**↺**].

The repeat mode switches every time the button is touched.


### DVD Video




- The REPEAT mode is always turned off when [**↺**] is touched and held for at least 2 seconds.

### DVD-VR

The Programme mode\*:




The Playlist mode\*:



\* Select the Programme or Playlist playback modes through the Search function. Refer to "Searching by Programme" or "Searching by Playlist" (page 33).

- Only discs containing a Playlist can be displayed.

### DivX®



## Searching by Title/Programme Number

(DVD-V) (DVD-VR)

Use this function to easily find positions on the DVD using the DVD's titles or programmes. Perform operations while playback is stopped.

### 1 Touch [**Page 1/2**] while playback is stopped.

### 2 Touch [**10Key**].

The numeric keypad input mode screen appears.

- For DVD Video, the numeric keypad can also be displayed by touching [**◀▶**] on the Menu screen and then touching [**Key**] twice.

### 3 Enter a desired title or programme by touching its number.

See page 30 for operation of the numeric keypad.

### 4 Touch [**Enter**].

Playback will start from the number selected.

### 5 Touch [**×**].

- Select the Programme playback modes through the Search function. Refer to "Searching by Programme" (page 33).
- This function cannot be used on discs on which no title numbers are recorded.
- Some disc may not accept any operation.

## Searching Directly by Chapter Number

DVD-V DVD-VR

Use this function to easily move to the beginnings of the chapters on the disc. Perform operations during playback, during PRE-STOP or while playback is paused.

- 1 Touch **[Page 1/2]** in any mode other than stop mode.
- 2 Touch **[10Key]**.  
The numeric keypad input mode screen will appear.
- 3 Touch and enter the chapter number you want to play.  
See page 30 for operation of the numeric keypad.
- 4 Touch **[Enter]** to confirm your selection.  
Playback will start from the selected chapter.
- 5 Touch **[X]**.

- This function is not available for a disc on which chapters are not stored.

## Searching by Programme DVD-VR

- 1 Touch **[Program]**.  
The programme search list screen is displayed.
  - 2 Touch the programme you want to play.  
The selected programme is played back.
- Touching **[Playlist]** on the programme search screen activates the playlist search screen.
  - If your last action was to run a programme search, you can activate the programme search screen by touching [**<**] on the DVD main screen as well.

## Searching by Playlist DVD-VR

- 1 Touch **[Playlist]**.  
The playlist search list screen is displayed.
  - 2 Touch the playlist you want to play.  
The selected playlist is played back, and then returns to the DVD mode main screen.
- Only discs containing a Playlist can be operated.
  - Touching **[Program]** on the playlist search screen activates the programme search screen.
  - If your last action was to run a playlist search, you can activate the playlist search screen by touching [**<**] on the DVD main screen as well.

## Searching for a Desired Video File

DivX

You can select a video file from the list screen.

- 1 Touch **[Q (Search)]**.  
The search mode is activated.
- 2 Touch **[VIDEO]**.  
The folder list screen appears.

### Folder Name Search mode

- 3 Touch **[▶ ]** in the desired folder.  
The first file in the selected folder is played back.

### File Name Search mode

- 3 Touch the desired folder name.  
The File name of the selected folder is displayed.
  - 4 Touch the desired file name.  
The selected file is played back.
- To return to the previous hierarchy, touch [**<**].
  - For details on how to scroll through the list, refer to "Selecting an Item in a List" (page 20).
  - After selecting a folder via a Folder name search, touch [**<**] on the main screen to display the folder search screen.
  - After selecting a file via a File name search, touch [**<**] on the main screen to display the file search screen.

## Switching the Angle DVD-V

On DVDs in which scenes have been filmed from multiple angles, the angle can be switched during playback.

### Touch **[Angle]**.

The angle switches between the angles recorded on the disc every time the button is touched.

- Some time may be required for the angle to change.
- Depending on the disc, the angle may switch in one of two ways.
  - Seamless: The angle switches smoothly.
  - Non-seamless: When the angle is switched, a still picture is displayed first, after which the angle switches.

---

## Switching the Audio Tracks

---



DVDs with multiplex audio or audio languages allow switching the sound during playback.

### Touch [Audio].

The sound switches between the alternate audio tracks recorded on the disc every time the button is touched.

- *The alternate track selected becomes the default setting every time the power is turned on or the disc is replaced. If the disc does not include that track, the disc's default language is selected instead.*
- *Not all discs will allow changing the alternate audio tracks during playback. In these cases, select audio tracks from the DVDs menu.*
- *There may be a delay before the selected alternate track begins to play.*

### DVD-VR disc with multiplex audio

#### Touch and hold [Audio] for at least 2 seconds.

The left and right channels will be output as shown below, each time the button is touched.

LR → LL → RR → LR

---

## Switching the Subtitles (Subtitle Language)

---



With DVDs on which multiple subtitle languages are recorded, the subtitle language can be switched during playback; moreover, subtitles can be hidden.

### Touch [Sub T.].

Touching this button repeatedly selects sequentially the subtitle languages recorded on the disc, and then turns the subtitles OFF.

- *There may be a delay before the selected subtitle appears.*
- *Not all discs will allow changing the subtitles during playback. In these cases, select subtitles from the DVDs menu.*
- *The subtitle language selected becomes the default setting every time the power is turned on or the disc is replaced. If the disc does not include that language, the disc's default language is selected instead. However, the subtitle language may differ depending on the disc.*
- *For some discs, the subtitles will be displayed even when this is set to OFF. However, the subtitle language may differ depending on the disc.*
- *Switches the subtitles ON/OFF while playing a DVD-VR disc.*

---

## About DivX®

---

DivX® is a codec (software) to compress moving images while maintaining image quality using a highly advanced compression ratio and operating speed.

- *Official DivX® Certified product*

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit [divx.com](http://divx.com) for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to [vod.divx.com](http://vod.divx.com) for more information on how to complete your registration.

### Media supported

The unit can play back CD-R/CD-RW/DVD-R/DVD-RW/DVD+R/DVD+RW discs and USB memory device that are recorded in the DivX® mode.

### Corresponding extension

"avi," "divx"

### Video Codec

DivX® versions 3, 4, 5, and 6 (versions 5 handle both interlaced and progressive)

### Audio Codec

MPEG1 Layer2 (MP2)	32 to 384 kbps
MPEG1 Layer3 (MP3)	32 to 320 kbps
MPEG2 Layer2 (MP2)	8 to 160 kbps
MPEG2 Layer3 (MP3)	8 to 160 kbps
Dolby Digital	32 to 448 kbps

### The optimum size for DivX® playback is as follows:

Screen Size: 96 to 720 pixel (horizontal) × 96 to 576 pixel (vertical)

With an aspect ratio other than 16:9, black bars may be displayed on the left and right sides, or at the top and bottom of the screen.

Image bit rate: "average 4 Mbps, Peak 8 Mbps"  
Home Theater Profile supported

# Setup


## Audio Setup

### Audio Setup Operation

The parking brake must be engaged to access the Setup screen. Attempting to access this screen while driving will display the warning-Unable to operate while driving.

The following steps 1 to 5 are common operations to each "Setting item" of Audio Setup. Refer to each section for details.

- 1 Touch [Setup] on the Home screen.**  
The Setup main screen is displayed.
- 2 Touch [Audio Setup].**  
The Audio Setup screen appears.
  - You can display the Audio Setup screen from each application screen. Touch [**Audio**] on any application screen. Adjust the settings for any function other than Time Correction, X-OVER, or Parametric EQ.
- 3 Select the desired item.**  
If ">>" appears, there is next hierarchy. Touch the desired item.  
If ">>" does not appear, proceed to step 4.



**Setting items:** Balance/Fader/Subwoofer / Application Volume Setup / Media Xpander / Bass Max EQ / Download Sound Setting / Defeat / Time Correction / X-OVER / Parametric EQ

- 4 Touch [◀] or [▶] etc., to change its setting.**
- 5 Touch [X] to return to the main application screen.**  
Touch [◀] to return to the previous screen.
  - Immediately after changing the Audio Setup (while the system is writing data automatically) do not turn the ignition key to OFF. Otherwise, the settings may not be changed.
  - For details on how to scroll through the list, refer to "Selecting an Item in a List" (page 20).

## Setting the Balance/Fader/Subwoofer

[Balance/Fader/Subwoofer] is selected on the Audio setup menu in step 3. Refer to "Audio Setup Operation" (page 35).




Image area

### Adjusting the Balance/Fader

Touch the desired point within the image area. Or touch [**▲ Front**] [**▼ Rear**] [**◀ Left**] [**Right ▶**].

**Balance:** L15 to R15  
**Fader:** F15 to R15

- To reset to the initial setting (Balance: 0, Fader: 0), touch [Center].

### Turning Subwoofer ON/OFF

If an optional subwoofer is connected to the unit, make the following setting.

**Setting item:** SubW.

**Setting contents:** On / Off (Initial setting: Off)

### Adjusting the Subwoofer Level

You can set the Subwoofer level when a Subwoofer is connected.

**Setting item:** SubW. LEVEL

**Setting contents:** 0 to 15 (Initial setting: 0)

- If the Subwoofer setting is "Off," the setting cannot be set.

### Setting the Subwoofer Phase

The subwoofer output phase is toggled Subwoofer Normal (0°) or Subwoofer Reverse (180°).

**Setting item:** SubW. Phase

**Setting contents:** 0° / 180° (Initial setting: 0°)

- If the Subwoofer setting is "Off," the setting cannot be set.

## Setting the Volume for Each Application

[Application Volume Setup] is selected on the Audio setup menu in step 3. Refer to "Audio Setup Operation" (page 35).

The volume level for each application can be adjusted.

**Setting item:** Radio / DVD / CD / Compress Media / NOKIA Music / iPod Music / iPod Video / AUX / AUX3 / BLUETOOTH Audio

**Setting contents:** -14 to +14 (Initial setting: 0)

- Settable applications differ depending on the connected device and settings.

## Setting the MX (Media Xpander)

[Media Xpander] is selected on the Audio setup menu in step 3. Refer to "Audio Setup Operation" (page 35).

MX (Media Xpander) makes vocals or instruments sound distinct regardless of the music source. The FM radio, CD, USB memory and iPod/iPhone, will be able to reproduce the music clearly even in cars with a lot of road noise.

**Setting item: Media Xpander**

- 1 Touch [On] of "ALL MX Off/On" in the MX setup screen.



- 2 Touch any of [ Off ] [ 1 ] [ 2 ] [ 3 ].

Application	Level			
	OFF	1	2	3
FM	Off	Movie	Movie	DVD Music
DVD	Off	Movie	Movie	DVD Music
CD	Off	Movie	Movie	DVD Music
Compress Media	Off	Movie	Movie	DVD Music
NOKIA	Off	Movie	Movie	DVD Music
AUX/AUX3	Off	Compress Media	Movie	Music

- The MX setting can be performed only when a source is currently selected.
- DVD Video and DVD-VR correspond to MX DVD.
- MP3/WMA/AAC/iPod/USB Audio/DivX®/BLUETOOTH Audio correspond to MX Compress Media.

### MX FM

The medium to high frequencies become more clear, and produces well balanced sound in all the bands.

### MX DVD

#### (Movie)

The dialog portion of the video is reproduced more clearly

#### (DVD Music)

This disc contains a large quantity of data such as music clip. MX uses this data to reproduce the sound accurately.

### MX CD

CD mode processes a large quantity of data. This data is used to reproduce the sound cleanly by making use of the data quantity.

### MX Compress Media

This corrects information that was omitted at the time of compression. This reproduces a well-balanced sound close to the original.

### MX NOKIA (OFF, Compress Media MX 1 to 3)

The medium to high frequencies become more clear, and produces well balanced sound in all the bands.

### MX AUX/AUX3

Choose the MX mode (Compress Media, Movie, or Music) that corresponds to the media connected.

- To cancel MX mode for all music applications, set MX to "Off" in step 1.
- Each music applications, such as FM radio, CD, and MP3/WMA/AAC can have its own MX setting.
- Setting to MX sets MX mode of each music applications to "Off."
- There is no MX mode for MW, LW radio.
- The function is inoperable when Defeat is set to "On."

## Equalizer Presets (Bass Max EQ)

[Bass Max EQ] is selected on the Audio setup menu in step 3. Refer to "Audio Setup Operation" (page 35).

10 typical equalizer settings are preset at the factory for a variety of musical source material.

**Setting item: Bass Max EQ**

**Setting contents: FLAT (Initial setting) / POPS / ROCK / NEWS / JAZZ / ELECTRICAL DANCE / HIP HOP / EASY LISTENING / COUNTRY / CLASSICAL**

- Only one type can be set to ON.
- When Bass Max EQ setting is edited, a Download Sound setting is disabled.
- When Bass Max EQ is set, the interlinked Parametric EQ settings are also changed. We recommend storing Parametric EQ settings in the Preset in advance.
- The Bass Max EQ setting can be configured when Defeat is "Off."

## Download Sound Setting

[Download Sound Setting] is selected on the Audio setup menu in step 3. Refer to "Audio Setup Operation" (page 35).


Using a USB memory device, the sound settings downloaded from the ALPINE website can be used to configure Time Correction, X-OVER and Parametric EQ settings.

For details about service and procedures of download, see ALPINE's web site.

**Setting item: Download Sound Setting**

The file name of download data shall be "A\_U\*\*\*\*.MP3."

A\_U\*\*\*\*.MP3



- Save the setting data in the root folder.

- 1 Touch [Download Sound Setting].

Setting data files are displayed in a list with a maximum of 5 items.

- 2 Touch the desired file.

- 3 Touch [OK].

The downloaded setting values are set as the Time Correction/X-OVER/Parametric EQ settings, and at the same time saved as Preset3, respectively.

- When no USB memory is connected, the "Download Sound Setting" function is not available.

- If Preset3 was already saved for Time Correction/X-OVER/ Parametric EQ, the data will be overwritten.
- If two USB memory devices are connected, you can switch between the two by touching [USB1 → 2] [USB2 → 1].

## Setting Defeat

[Defeat] is selected on the Audio setup menu in step 3. Refer to “Audio Setup Operation” (page 35).

If Defeat is “On,” MX, Bass Max EQ, Download Sound Setting and Parametric EQ functions are turned OFF. This disables any settings made for these functions.

**Setting item: Defeat**

**Setting content: Off / On (Initial setting: Off)**

## Adjusting the Time Correction (Time Correction)


[Time Correction] is selected on the Audio setup menu in step 3. Refer to “Audio Setup Operation” (page 35).

Before performing the following procedures, refer to “About Time Correction” (page 39).

**Setting item: Time Correction**

- 1 Touch [msec] or [cm] to select mode for making adjustments.

Each time you touch, the onscreen button and correction mode changes.



msec: Adjust time.

cm: Adjust listening position and distance from each speaker.

- 2 Touch [◀] or [▶] for each speaker to adjust the time or distance.  
0.0msec to 9.9msec (0.1msec/step)  
0.0cm to 336.6cm (3.4cm/step)
  - If the sum total of the setting values of all the speakers exceeds 20msec or 680cm, the settings may not function normally.
- 3 To store the adjusted setting value, touch and hold [Preset1], [Preset2], or [Preset3].

- Touch [Flat] to set all values to 0.0.
- If the Subwoofer setting is “Off,” the Subwoofer setting cannot be edited (Refer to page 35).

### Calling the Time Correction Value

Calling the pre-set time correction value.

Touch [Preset1], [Preset2], or [Preset3] on the time correction screen.

The setting stored in the Preset will be recalled.


## Adjusting the Crossover Settings (X-OVER)

[X-OVER] is selected on the Audio setup menu in step 3. Refer to “Audio Setup Operation” (page 35).

Before performing the following procedures, refer to “About the Crossover” (page 40).

**Setting item: X-OVER**

- 1 Touch [Channel] to select the channel.  
Each time you touch, the channel switches.



- The channel being adjusted is displayed in red.

→ Front HPF → Rear HPF → Subw. LPF

- 2 Adjust the crossover to your preference.

### Selecting the Cut-Off Frequency

Touch [◀] or [▶] of “Freq.,” then select the cut-off frequency.

**Setting contents: 20 / 25 / 31.5 / 40 / 50 / 63 / 80 (Initial setting) / 100 / 125 / 160 / 200 Hz**

### Adjusting the Slope

Touch [◀] or [▶] of “Slope,” then adjust the HPF or LPF slope.

**Setting contents: 0 (Initial setting) / 6 / 12 / 18 / 24 dB/oct**

### Adjusting the Level

Touch [▼] or [▲] of “Level,” then adjust the HPF or LPF level.

**Setting contents: -12 to 0 dB (Initial setting: 0)**

- 3 Repeat steps 1 to 2 to make adjustment to the other channels.
- 4 To store the adjusted setting value, touch and hold [Preset1], [Preset2], or [Preset3].

- Touch [Flat] to initialize all values.
- If the Subwoofer setting is “Off,” the Subwoofer setting cannot be edited (Refer to page 35).
- While adjusting the X-OVER you should consider the frequency response of the connected speakers.

### Calling the X-OVER adjusted value

Calling the pre-set X-OVER adjusted value.

Touch [Preset1], [Preset2], or [Preset3] on the X-OVER screen.

The setting stored in the Preset will be recalled.


## Adjusting the Parametric Equalizer Curve (Parametric EQ)

[Parametric EQ] is selected on the Audio setup menu in step 3. Refer to "Audio Setup Operation" (page 35).

You can modify the Equalizer settings to create a response curve more appealing to your personal taste.

**Setting item: Parametric EQ**

### 1 Adjust the Parametric EQ to your preference.



#### Adjusting the Band

Touch [Band] to select the band to be adjusted.

→ BAND1 → BAND2 → ... → BAND8 → BAND9

- You can select a band directly by touching the screen.

#### Adjusting the Frequency

Touch [◀] or [▶] of "Freq." to adjust the frequency of the selected band.

**Adjustable frequency bands: 20 Hz to 20 kHz (in 1/3 octave steps)**

- BAND1: 20 Hz~100 Hz (63 Hz)
- BAND2: 63 Hz~315 Hz (125 Hz)
- BAND3: 125 Hz~500Hz (250 Hz)
- BAND4: 250 Hz~1 kHz (500Hz)
- BAND5: 500 Hz~2 kHz (1 kHz)
- BAND6: 1 kHz~4 kHz (2 kHz)
- BAND7: 2 kHz~7.2 kHz (4 kHz)
- BAND8: 5.8 kHz~12 kHz (8 kHz)
- BAND9: 9 kHz~20 kHz (16 kHz)

#### Adjusting the Level

Touch [▼] or [▲] of "Level" to adjust the level of selected band.

**Setting contents: -7 to +7 (Initial setting: 0)**

#### Setting the Bandwidth

Touch [◀] or [▶] of "Q Adjust" to select the bandwidth.

**Setting contents: 1 (Initial setting) / 2 / 3**

### 2 To adjust another band, repeat step 1, and adjust all bands.

### 3 To store the adjusted setting value, touch and hold [Preset1], [Preset2], or [Preset3].

- Settings exceeding the frequency of adjacent bands are not available.
- While adjusting the Parametric EQ, you should consider the frequency response of the connected speakers.
- When the parametric EQ is adjusted, the adjustment for Bass Max EQ becomes ineffective.

- When Bass Max EQ is set, the interlinked Parametric EQ settings are also changed. We recommend storing Parametric EQ settings in the Preset in advance.
- Touch [Flat] to initialize all values.
- The Parametric EQ setting can be configured when Defeat is "Off."

#### Calling the Parametric EQ adjusted value

Calling the pre-set Parametric EQ adjusted value.

**Touch [Preset1], [Preset2], or [Preset3] on the Parametric EQ screen.**

The setting stored in the Preset will be recalled.




## About Time Correction

The distance between the listener and the speakers in a car vary widely due to the complex speaker placement. This difference in the distances from the speakers to the listener creates a shift in the sounds image and frequency characteristics. This is caused by the time delay between the sound reaching the listener's right versus the left ear. To correct this, this unit is able to delay the audio signal to the speakers closest to the listener. This effectively creates a perception of increased distance for those speakers. The listener can be placed at an equal distance between the left and right speakers for optimum staging. The adjustment will be made for each speaker in 3.4cm steps.

### Example 1. Listening Position: Front Left Seat

Adjust the time correction level of the front left speaker to a high value and the rear right to zero or a low value.



The sound is not balanced because the distance between the listening position and the various speakers is different. The difference in distance between the front left speaker and the rear right speaker is 1.75 m (68-7/8"). Here we calculate the time correction value for the front left speaker in the diagram on the above.

Conditions:

Farthest Speaker – listening position : 2.25 m (88-9/16")

Front left speaker – listening position : 0.5 m (19-11/16")

Calculation:  $L = 2.25\text{ m} - 0.5\text{ m} = 1.75\text{ m} (68-7/8")$

Time correction =  $1.75 \div 343^{*1} \times 1000 = 5.1\text{ (ms)}$

*\*1 Speed of sound: 343 m/s (765 mph) at 20°C*

In other words, giving the front left speaker a time correction value of 5.1 ms makes it seem as if its distance from the listener is the same as the distance to the farthest speaker.

Time correction eliminates the differences in the time required for the sound to reach the listening position.

The time of the front left speaker is corrected by 5.1 ms so that its sound reaches the listening position at the same time as the sound of other speakers.

### Example 2. Listening Position: All Seats

Adjust the time correction level of each speaker to almost the same level.

- 1** Sit in the listening position (driver's seat, etc.) and measure the distance (in meters) between your head and the various speakers.
- 2** Calculate the difference between the distance correction value to the farthest speaker and the other speakers.

$L = (\text{distance to farthest speaker}) - (\text{distance to other speakers})$

These values are the time correction values for the different speakers. Setting these values to make each sound reach the listening position at the same time as the sound of other speakers.

Time Correction Value List

Time Difference (msec)	Distance (cm)	Distance (inch)	Time Difference (msec)	Distance (cm)	Distance (inch)
0.0	0.0	0.0	5.1	173.4	68.3
0.1	3.4	1.3	5.2	176.8	69.7
0.2	6.8	2.7	5.3	180.2	71.0
0.3	10.2	4.0	5.4	183.6	72.4
0.4	13.6	5.4	5.5	187.0	73.7
0.5	17.0	6.7	5.6	190.4	75.0
0.6	20.4	8.0	5.7	193.8	76.4
0.7	23.8	9.4	5.8	197.2	77.7
0.8	27.2	10.7	5.9	200.6	79.1
0.9	30.6	12.1	6.0	204.0	80.4
1.0	34.0	13.4	6.1	207.4	81.7
1.1	37.4	14.7	6.2	210.8	83.1
1.2	40.8	16.1	6.3	214.2	84.4
1.3	44.2	17.4	6.4	217.6	85.8
1.4	47.6	18.8	6.5	221.0	87.1
1.5	51.0	20.1	6.6	224.4	88.4
1.6	54.4	21.4	6.7	227.8	89.8
1.7	57.8	22.8	6.8	231.2	91.1
1.8	61.2	24.1	6.9	234.6	92.5
1.9	64.6	25.5	7.0	238.0	93.8
2.0	68.0	26.8	7.1	241.4	95.1
2.1	71.4	28.1	7.2	244.8	96.5
2.2	74.8	29.5	7.3	248.2	97.8
2.3	78.2	30.8	7.4	251.6	99.2
2.4	81.6	32.2	7.5	255.0	100.5
2.5	85.0	33.5	7.6	258.4	101.8
2.6	88.4	34.8	7.7	261.8	103.2
2.7	91.8	36.2	7.8	265.2	104.5
2.8	95.2	37.5	7.9	268.6	105.9
2.9	98.6	38.9	8.0	272.0	107.2
3.0	102.0	40.2	8.1	275.4	108.5
3.1	105.4	41.5	8.2	278.8	109.9
3.2	108.8	42.9	8.3	282.2	111.2
3.3	112.2	44.2	8.4	285.6	112.6
3.4	115.6	45.6	8.5	289.0	113.9
3.5	119.0	46.9	8.6	292.4	115.2
3.6	122.4	48.2	8.7	295.8	116.6
3.7	125.8	49.6	8.8	299.2	117.9
3.8	129.2	50.9	8.9	302.6	119.3
3.9	132.6	52.3	9.0	306.0	120.6
4.0	136.0	53.6	9.1	309.4	121.9
4.1	139.4	54.9	9.2	312.8	123.3
4.2	142.8	56.3	9.3	316.2	124.6
4.3	146.2	57.6	9.4	319.6	126.0
4.4	149.6	59.0	9.5	323.0	127.3
4.5	153.0	60.3	9.6	326.4	128.6
4.6	156.4	61.6	9.7	329.8	130.0
4.7	159.8	63.0	9.8	333.2	131.3
4.8	163.2	64.3	9.9	336.6	132.7
4.9	166.6	65.7			
5.0	170.0	67.0			



## About the Crossover


### Crossover (X-OVER):

This unit is equipped with an active crossover. The crossover limits the frequencies delivered to the outputs. Each channel is controlled independently. Thus, each speaker pair can be driven by the frequencies for which they have been optimally designed.


The crossover adjusts the HPF (high pass filter) or LPF (low pass filter) of each band, and also the slope (how fast the filter rolls off the highs or lows).

Adjustments should be made according to the reproduction characteristics of the speakers. Depending on the speakers, a passive network may not be necessary. If you are unsure about this point, please consult your authorized Alpine dealer.

	Cut-off frequency (1/3 octave steps)		Slope		Level
	HPF	LPF	HPF	LPF	
Low range speaker	----	20 Hz - 200 Hz	----	FLAT, -6, -12, -18, -24 dB/oct.	0 to -12 dB
Rear high range speaker	20 Hz - 200 Hz	----	FLAT, -6, -12, -18, -24 dB/oct.	----	0 to -12 dB
Front high range speaker	20 Hz - 200 Hz	----	FLAT, -6, -12, -18, -24 dB/oct.	----	0 to -12 dB



(Different from actual display)



- **HPF (high pass filter):** Cuts the lower frequencies and allows the higher frequencies to pass.
  - **LPF (low pass filter):** Cuts the higher frequencies and allows the lower frequencies to pass.
  - **Slope:** The level change (in dB) for a frequency change of one octave.
  - The higher the slope value, the steeper the slope becomes.
  - Adjust the slope to FLAT to bypass the HP or LP filters.
  - Do not use a tweeter without the HPF on or set to a low frequency, as it may cause damage to the speaker due to the low frequency content.
  - You cannot adjust the crossover frequency higher than the HPF or lower than the LPF.
  - Adjustment should be made according to the recommended crossover frequency of the connected speakers. Determine the recommended crossover frequency of the speakers. Adjusting to a frequency range outside that recommended may cause damage to the speakers. For the recommended crossover frequencies of Alpine speakers, refer to the respective Owner's Manual.
- We are not responsible for damage or malfunction of speakers caused by using the crossover outside the recommended value.

## Display Setup

### Display Setup Operation

The parking brake must be engaged to access the Display mode screen. Attempting to access this screen while driving will display the warning-Unable to operate while driving.

The following steps 1 to 6 are common operations to each "Setting item" of Display Setup. Refer to each section for details.

#### 1 Touch [Setup] on the Home screen.

The Setup main screen is displayed.

#### 2 Touch [Display Setup].

The Display Setup screen appears.

- You can display the Display Setup screen from each application screen. Touch [Display] on any application screen (video mode).

#### 3 Touch the desired application.



- "Audio" can be selected while a video is playing.
- The camera names set under the "Direct Camera" settings are displayed. The camera names are not displayed when "Off" is set (page 47).
- If "Nav. In" is "Off," "Navigation" will not be displayed (page 48).

#### 4 Touch [ ] of the desired item.

Settable items differ depending on the application.

- [Audio] (Video media):  
Display Mode\* / Live Contrast / Visual EQ / Bright / Color / Tint / Contrast / Sharpness
- [Direct Camera]:  
Live Contrast / Bright / Color / Contrast
- [Navigation]:  
Bright / Contrast

\* When media is set to AUX, the settings cannot be changed in the situations below.

- When "AUX In" is set to "USB Player."
- When "AUX In" is set to "DVB-T" and "Direct Touch" is "On."

#### 5 Touch [ ] or [ ] to change its setting.

## 6 Touch [X] to return to the main application screen.

Touch [C] to return to the previous screen.

- Immediately after changing the settings of Display Setup (While the system is writing data automatically) do not turn the ignition key to OFF. Otherwise, the settings may not be changed.


### Switching Display Modes

**Setting item: Display Mode**

**Setting contents: WIDE (Initial setting) / CINEMA / NORMAL**



In WIDE mode, the monitor displays a normal picture wider to fit in a wide-screen monitor by evenly stretching out the picture horizontally.



In CINEMA mode, the monitor displays a normal picture by stretching out the picture horizontally and vertically. This mode is good for displaying a cinema type picture at the 16:9 ratio.



In NORMAL mode, the monitor displays a normal picture at the center of the screen with a vertical black band at each side.

### Adjusting the Live Contrast

This function automatically adjusts the areas on the screen that are too bright or too dark and corrects them to natural brightness.

**Setting item: Live Contrast**

**Setting contents: OFF (Initial setting) / LOW / HIGH**

### Selecting the Visual EQ Mode (Factory's setting)

You can select a mode suitable for the subject image.

**Setting item: Visual EQ**

**Setting contents: OFF (Initial setting) / NIGHT M. / SOFT / SHARP / CONTRAST**

- |           |   |
|-----------|---|
| OFF:      | Initial Setting   |
| NIGHT M.: | Suitable for movies in which dark scenes frequently appear. |
| SOFT:     | Suitable for CGs and animated films.                        |
| SHARP:    | Suitable for old movies where images are not clearly shown. |
| CONTRAST: | Suitable for recent movies.                                 |

- To return to the default video settings, set this function to OFF. Any Visual EQ selection or changes made are reset their initial settings.
- If any adjustments are made to the existing Visual EQ selections (NIGHT M., etc.), "CUSTOM" is displayed.

### Adjusting Brightness

**Setting item: Bright**

**Setting content: -15 to +15 (Initial setting: 0)**

You can adjust the brightness between MIN (-15) and MAX (+15). When it reaches the minimum or maximum point, the display shows "MIN" or "MAX" respectively.

### Adjusting Colour of Picture

**Setting item: Color**

**Setting content: -15 to +15 (Initial setting: 0)**

You can adjust the colour between MIN (-15) and MAX (+15). When it reaches the minimum or maximum point, the display shows "MIN" or "MAX" respectively.

### Adjusting Tint of Picture

**Setting item: Tint**

**Setting content: R15 to G15 (Initial setting: 0)**

Adjust the colour from R15 to G15.

- When setting PAL, you can not adjust the TINT.

### Adjusting Image Contrast

**Setting item: Contrast**

**Setting content: -15 to +15 (Initial setting: 0)**

You can adjust the contrast between MIN (-15) and MAX (+15). When it reaches the minimum or maximum point, the display shows "MIN" or "MAX" respectively.

### Adjusting Picture Quality

**Setting item: Sharpness**

**Setting content: -5 to +5 (Initial setting: 0)**

Picture quality adjustment range is -5 to +5. "SOFT" and "HARD" appear as the minimum and maximum values specified.

### Saving and calling the adjusted picture quality

When adjusting audio (video media), you can store the settings made for "Adjusting Live Contrast, Brightness, Color, Tint, Contrast and Sharpness."

**Setting item: Preset1 / Preset2**

- 1 After completing "Adjusting Live Contrast, Brightness, Color, Tint, Contrast and Sharpness" (page 41), touch and hold [Preset1] or [Preset2] to save the settings.
- 2 Touch [Preset1] or [Preset2] to call the saved settings.

- Visual EQ is registered as "CUSTOM."
- Display Mode cannot be registered.


# General Setup

## General Setup Operation

The parking brake must be engaged to access the General mode screen. Attempting to access this screen while driving will display the warning-Unable to operate while driving.

The following steps 1 to 4 are common operations to each "Setting item" of General Setup. Refer to each section for details.

- 1 Touch **[Setup]** on the Home screen.  
The Setup main screen is displayed.
- 2 Touch **[General Setup]**.  
The General Setup screen appears.
- 3 Touch **[◀]** or **[▶]** etc., of the desired item to change its setting. For items that have "»", touch the item to display the screen for the next hierarchy.



**Setting items:** *Date/Time / Language / About / BLUETOOTH / Sound Feedback / GPS / Screen/LED Customize / Remote Sensor / Security Code*

- Depending on the item, repeat step 3.

- 4 Touch **[X]** to return to the main application screen.  
Touch **[<]** to return to the previous screen.
- Immediately after changing the settings of General Setup (While the system is writing data automatically) do not turn the ignition key to OFF. Otherwise, the settings may not be changed.

## Date/Time Setting

Touch **[Date/Time]** on the General setup menu in step 3. Refer to "General Setup Operation" (page 42).

### Setting of Calendar Display Pattern Switching

You can switch the calendar display pattern to be shown when the time is displayed.

**Setting item:** *Calendar Type*  
**Setting contents:** *M/D / D/M (Initial setting)*

- M/D: shows the month/day
- D/M: shows the day/month

## Setting the Clock Display

You can select the clock display type, 12-hour or 24-hour, depending on your preference.

**Setting item:** *Clock Mode*  
**Setting contents:** *12h / 24h (Initial setting)*

## RDS Time Display

When ON is selected, the clock is adjusted automatically based on the time data sent from the RDS broadcast.

**Setting item:** *RDS Clock DISP*  
**Setting contents:** *Off (Initial setting) / On*

- Off: To adjust it manually.
- On: Adjust the clock automatically based on the time data. In this case, the clock cannot be adjusted manually.

## Setting the Time

**Setting item:** *Clock Adjust*  
**Additional items:** *Year / Month / Day / Hour / Minute*  
**Setting content:** *2011~ / JAN-DEC / 1-31 / 01-12 or 00-23 / 00-59 (Initial setting: 2011 / JAN / 1 / 00 / 00)*

- Year: Adjust the year.
- Month: Adjust the month.
- Day: Adjust the day.
- Hour: Adjust the hour.
- Minute: Adjust the minute.

- Touch and hold **[◀]** or **[▶]** to run through a change sequence automatically.
- Clock adjustment can be made when "RDS Time Display" (page 42) is set to "Off."

## Language Setting

Touch **[Language]** on the General setup menu in step 3. Refer to "General Setup Operation" (page 42).

## Setting the Scroll

Scroll display is available if CD text, folder name, file name or tag information is entered.

**Setting item:** *Auto Scroll*  
**Setting contents:** *Off / On (Initial setting)*

- Off: Turns off the scroll mode.
- On: Turns on the Auto scroll mode. Scroll display is repeated as long as the mode is turned on.

## Format settings

The character code to be used for tag text information displayed on the screen can be selected from 7 character codes.

**Setting item:** *Format Sel.*  
**Setting contents:** *EU1/EU2(Initial setting)/RUS/JPN/CHI/THA/ARA*

- EU1: ISO 8859-1
- EU2: ISO 8859-15
- RUS: ISO 8859-5
- JPN: CP932
- CHI: GB18030
- THA: CP874
- ARA: CP1256

## Setting the Menu Language

The Setup menu, feedback information, etc. for this unit can be changed to appear in the selected language.

**Setting item:** *Language Sel.*

**Setting contents:** *English/German/French/Spanish/Portuguese/  
Italian/Dutch/Finnish/Norwegian/Swedish/  
Russian/Japanese/ Thai/Arabic/Chinese*

- Touch **[OK]** to confirm the language and display the screen in the specified language.

## About ICS-X8

Touch **[About]** on the General setup menu in step 3. Refer to “General Setup Operation” (page 42).

## Displaying the Product Information

You can view the version information of this product. Make note of this information and refer to it whenever you contact Alpine Tech Support or an Alpine-authorized dealer.

**Contents:** *Serial No. / Firmware Version*

## Checking the DivX® Registration

This unit will display the registration code required to play a DivX® VOD (Video On Demand), or you can also display the deregistration code.

**Setting item:** *Warranty / Copyright Info.*

### Displaying the Registration Code

- 1 Touch **[Warranty/Copyright Info.]**.
- 2 Touch **[DivX(R) VOD]**.
- 3 Touch **[Registration]**.  
The registration code is displayed on the screen.
- 4 Touch **[OK]**.

### Displaying the Deregistration Code

- 1 Touch **[Warranty/Copyright Info.]**.
  - 2 Touch **[DivX(R) VOD]**.
  - 3 Touch **[Deregistration]**.  
The confirmation dialog screen appears.
  - 4 Touch **[OK]**.  
The deregistration code is displayed on the screen.
- When you have finished, touch **[Cancel]**. If you want to continue and display a new registration code, touch **[OK]**, check the registration code, and then touch **[OK]** again.

## Initializing the System

You can initialize all data, to restore the factory settings. Remove the CD/DVD disc, etc. from the system before operation

**Setting item:** *Clear All Settings*

- 1 Touch **[Reset]** of “Clear All Settings.”
  - 2 After the confirmation message appears, touch **[OK]**.  
The system starts initialization.
- Do not turn on/off the power or change the ignition key position until system restart is completed.

## BLUETOOTH Setting

[BLUETOOTH] is selected on the General setup menu in step 3. Refer to “General Setup Operation” (page 42).

## Setting the BLUETOOTH On/Off

When using BLUETOOTH, first set the BLUETOOTH mode to “On.”

**Touch [On] or [Off] of “BLUETOOTH” in the General Setup screen.**

After selecting “On,” you can adjust BLUETOOTH settings by touching [BLUETOOTH].

- If the Bluetooth setting is “Off,” you cannot move to the BLUETOOTH setting screen.

## Setting the BLUETOOTH Device

### Registering the BLUETOOTH Device

The BLUETOOTH device is used when a connectable BLUETOOTH compatible device is searched and connected from this unit, or a new BLUETOOTH compatible device is registered.

- 1 Touch **[Set BLUETOOTH Device]**.
- 2 Touch **[Search]** of “No Device.”  
The Device list displays up to 10 items.
- 3 Touch **[Audio], [HFT] or [Both]** of the device you want to connect from the list.  

Audio:	Sets for use as an Audio device
HFT:	Sets for use as a Hands Free Device.
Both:	Sets for use as both an Audio device and Hands Free Device.

  - You can connect (pair) up to 5 BLUETOOTH compatible mobile phones.
- 4 When the device registration is complete, a message appears and the device returns to normal mode.
  - The BLUETOOTH registration process differs depending on the device version and SSP (Simple Secure Pairing). If a 4 or 6 character Passcode appears on this device, enter the Passcode using the BLUETOOTH compatible device.  
If a 6 character Passkey appears on this device, make sure the same passkey is displayed on the BLUETOOTH compatible device and touch “Yes.”
  - If all the 5 devices have been registered, you cannot register the 6th device. To register another device, you need to delete one of the devices from position 1 to 5 first.

## Setting the BLUETOOTH Device

Select one of 5 paired BLUETOOTH compatible devices that you previously registered.

- 1 Touch **[Set BLUETOOTH Device]**.
- 2 Touch **[Audio]** or **[HFT]** of the device you want to connect from the Paired Device list.

## Deleting a BLUETOOTH Device from the list

You can delete the information of a previously connected BLUETOOTH compatible device.

- 1 Touch **[Set BLUETOOTH Device]**.
- 2 Touch **[Delete]** of the BLUETOOTH compatible device to delete from the Paired Device list.  
A message is displayed.
- 3 Touch **[OK]**.

- Touching **[Cancel]** will cancel the setting.

## Automatic Connection setting

If the Automatic Connecting setting is “On,” automatic connection is performed for the audio device registered in the Paired Device list.

**Setting item:** Auto Connect

**Setting contents:** Off (Initial setting) / On

## Setting the Passcode

You can set the code for connecting with a BLUETOOTH compatible device.

**Setting item:** Passcode Change

- 1 Touch **[Input]** of “Passcode Change.”  
A numeric keypad screen is displayed.
- 2 Enter a 4-digit passcode, and then touch **[Enter]**.

- The initial number is 0000.
- For details on how to input the numeric keypad, refer to “Numeric Keypad Input Operations” (page 30).

## Changing the Character Code of the Phone Book

You can select the character code that is used when transferring the phone book or history from a mobile phone. If unreadable characters appear in the transferred data, select the correct character code.

**Setting item:** Default Phonebook Encoding

**Setting contents:** EU1 / EU2 (Initial setting) / Russian / Japanese / Chinese / Thai / Arabic / Unicode UTF-8 / Unicode UTF-16LE / Unicode UTF-16BE

- 1 Touch **[Default Phonebook Encoding]**.  
The Character code list screen is displayed.

## 2 Touch the desired character code.

EU1: ISO 8859-1  
EU2: ISO 8859-15  
Russian: ISO 8859-5  
Japanese: CP932  
Chinese: GB18030  
Thai: CP874  
Arabic: CP1256  
Unicode UTF-8  
Unicode UTF-16LE  
Unicode UTF-16BE

## 3 Touch **[OK]**.

## Sound Feedback Setting

[Sound Feedback] is selected on the General setup menu in step 3. Refer to “General Setup Operation” (page 42).

## Adjusting the Operating Sound

You can change the volume of the sound heard when a button is touched.

**Setting item:** Sound Feedback

**Setting contents:** 0 to 7 (Initial setting: 4)

## GPS Setting

[GPS] is selected on the General setup menu in step 3. Refer to “General Setup Operation” (page 42).

## Connecting to a GPS antenna

Set to “On” when connecting a GPS antenna (sold separately) to this unit.

**Touch **[On]** or **[Off]** of “GPS” in the General Setup screen.**

After selecting “On,” you can display GPS Information by touching [ >> ].

- If the GPS setting is “Off,” the GPS setting information screen is not displayed.

## Displaying the GPS Information

**Touch **[GPS]** in the General Setup screen.**

The GPS information screen is displayed.

## Screen/LED Customize

Touch **[Screen/LED Customize]** on the General setup menu in step 3. Refer to “General Setup Operation” (page 42).

## Setting the Brightness of the Backlighting

Backlighting is provided by a fluorescent light built into the liquid crystal panel. The illumination control adjusts the brightness of the backlighting based on the car ambient lighting for easier viewing.

**Setting item: Dimmer**

**Setting contents: Auto (Initial setting) / On / Off**

- Auto: Adjust the brightness of the background illumination of the monitor automatically to the brightness of the car interior.
- On: Keep the background illumination of the monitor dark.
- Off: Deactivate Auto Dimmer mode to keep the background illumination of the monitor bright.

- When "Auto" or "On" is set, the setting is also applied for the button lighting in "Adjusting the Dimmer of Button Lighting at Night" (page 45), and "Adjusting the Minimum Level of Backlight" (page 45).

## Adjusting the Dimmer of Button Lighting at Night

You can adjust the brightness of the button lighting at night with the dimmer.

**Setting item: LED Dimmer Level**

**Setting level: -2 to +2 (Initial setting: 0)**

## Changing the Colour of the Home Button

There are 5 colors available to select from for the Home button.

**Setting item: LED Color**

**Setting contents: Blue (Initial setting) / Red / Green / Amber**

## Adjusting the Minimum Level of Backlight

You can adjust the brightness of the backlight. This function could be used, for instance, to change the screen brightness while traveling at night.

**Setting item: Screen Dimmer Level**

**Setting content: -15 to +15 (Initial setting: 0)**

You can adjust the level between MIN (-15) and MAX (+15). When it reaches the minimum or maximum point, the display shows "MIN" or "MAX" respectively.

## Switching the Display Colour

You can choose from 4 different display colours.

**Setting item: Screen Color**

**Setting contents: Blue (Initial setting) / Red / Green / Amber**

## Adjusting the Touch Panel

Adjustment becomes necessary when the display position on the LCD and the touch position on the touch panel do not match.

**Setting item: Screen Alignment**


- 1 Touch **[Screen Alignment]** in the Screen/LED Customize screen.

The adjustment screen appears.

- 2 Accurately touch the  mark provided in the upper left corner of the screen.

- 3 Accurately touch the  mark provided in the lower right corner of the screen.

This completes adjustment, and returns to the previous screen.

- If you have touched a location other than the  mark, touch **[Reset]** to restore the adjustment screen to the initial setting.
- If you touch **[Cancel]** on the adjustment screen, no adjustment is done and returns to the previous screen.

## Remote Sensor Setting

[Remote Sensor] is selected on the General setup menu in step 3. Refer to "General Setup Operation" (page 42).

For remote control operation, the remote sensor of the external device (monitor, etc.) can be switched, as you prefer.

**Setting item: Remote Sensor**

**Setting contents: Front (Initial setting) / Rear**

- Front: The remote sensor of this unit is effective.  
Rear: The remote sensor of the external monitor connected to AUX OUTPUT of this unit becomes effective. The remote control operates the source connected to the AUX OUTPUT terminals.

- If the RSE (page 49) is "Off," the setting is not displayed.

## Security Code Setting

[Security Code] is selected on the General setup menu in step 3. Refer to "General Setup Operation" (page 42).

### Setting Security code

You can set the system to be unusable without entering a password. When you turn this setting to "On" and set a password, password input is required when the system is connected to a battery and turned on for the first time.

**Setting item: Security Code**

**Setting contents: Off (Initial setting) / On**

### Setting the password

- 1 Touch [◀] or [▶] of "Security Code" to set to "On."
  - 2 After the confirmation message appears, touch [OK].  
The password setting screen is displayed.
  - 3 Enter a password, then touch [Enter].
    - Enter the 6-digit number.
    - Input numbers are displayed as "\*."
  - 4 Enter the same password again, then touch [Enter].  
The password is set and the system returns to the previous screen.
- If you forget a registered password, you can not use this unit. In this case, service will be required.

### Clearing the password

- 1 Touch [◀] or [▶] of "Security Code" to set to "Off."  
The password setting screen is displayed.
- 2 Enter the password you have set, then touch [Enter].  
The password is cleared and the system returns to the previous screen.
  - Input numbers are displayed as "\*."


## Application Setup

### Application Setup Operation

The parking brake must be engaged to access the Application mode screen. Attempting to access this screen while driving will display the warning-Unable to operate while driving.

The following steps 1 to 5 are common operations to each "Setting item" of Application Setup. Refer to each section for details.

- 1 Touch [Setup] on the Home screen.  
The Setup main screen is displayed.
- 2 Touch [Application Setup].  
The Application Setup screen appears.
- 3 Select the desired item.  
If ">>" appears, there is next hierarchy. Touch the desired item.  
If ">>" does not appear, proceed to step 4.



**Setting items: Camera / Navigation / AUX / RSE / Phone / Disc / Radio**

- 4 Touch [◀] or [▶] etc., to change its setting.
  - 5 Touch [X] to return to the main application screen.  
Touch [◀] to return to the previous screen.
- Immediately after changing the Application Setup (while the system is writing data automatically) do not turn the ignition key to OFF. Otherwise, the settings may not be changed.

## Camera Setting

Touch **[Camera]** on the Application setup menu in step 3. Refer to “Application Setup Operation” (page 46).

### Setting the Camera Input

With an optional camera connected, its video is output to the monitor. When the camera is connected, set this item.

**Setting item: Direct Camera**

**Setting contents: Off (Initial setting) / Rear**

Rear: Rear camera

After selecting “Rear” in the “Direct Camera” setting, touch of **[Direct Camera]**, the following additional items can be adjusted.

### Switching video patterns for Rear camera

The video pattern can be changed when connected to HCE-C200R, etc.

**Setting item: Guide Adjustment**

#### 1 Touch **[Guide Adjustment]**.

The camera guide adjustment screen is displayed.

#### 2 Touch **[Back]**, **[Panorama]**, **[Corner]**, or **[Top]**.

The view will change to the selected view.

#### 3 Touch **[<]** to return to the previous screen.

- For an explanation of video patterns, see the camera Owner's Manual.

### Adjusting the Rear Camera Guide

If you select “Rear,” you can adjust the camera guide position.

**Setting item: Guide Adjustment**

#### 1 Touch **[Guide Adjustment]**.

The camera guide adjustment screen is displayed.

- If the video pattern is set to “Corner,” the camera guide will not be displayed.


#### 2 Touch **[Adjust]**.

- If **[Adjust]** does not appear, proceed to step 3.

#### 3 Touch the guide you intend to adjust.

Guide line can also be selected by touching **[▲]** **[▼]**.

### Display example for rear camera mode



#### 4 Touch **[↑]**, **[↓]**, **[←]** or **[→]** to adjust the position of the guide.


- Touching **[Clear]** clears adjustments and returns to the setting before guide line alteration.

#### 5 After the adjustment is completed, touch **[Set]**.

### Adjusting guides simultaneously

#### 1 Touch **[Link]**.

The 3 vertical guides of the currently-selected guide link together, allowing them to be adjusted simultaneously.



### Turning guide display On/Off

Turning the selected guide off.

#### 1 Touch **[On/Off]**.

The currently selected guide will turn off.

#### 2 To turn the guide on, touch **[On/Off]** again.

- Guides that are turned off are still adjustable.

### Returning guides to default.

#### 1 Touch **[Default]**.

A message window will appear.

#### 2 Touch **[OK]**.

Adjusted values will return to default settings.



## Navigation Setting

Touch **[Navigation]** on the Application setup menu in step 3. Refer to “Application Setup Operation” (page 46).

### Setting the Navigation Mode

When you connect an optional Alpine navigation system, set it to “On.”

**Setting item:** *Nav. In*

**Setting contents:** *Off (Initial setting) / On*

- Off: Navigation mode is not displayed. The settings related to the navigation can not be changed from this unit.
- On: Navigation mode is displayed.

- To use a Nokia navigation application, refer to “Using a Nokia Application” (page 74).

### Setting the Navigation Interruption

The Navi guide screen for the Navigation system can be interrupt to another screen.

**Setting item:** *Nav. Int.*

**Setting contents:** *Off / On (Initial setting)*

- Off: The navigation interruption mode is turned off.
- On: The navigation interruption mode is on.

- This setting is effective when Nav. In is “On” in “Setting the Navigation Mode” (page 48).

### Adjusting Nav. Mix Level

You can adjust the volume of navigation interruption.

**Setting item:** *Nav. Mix Level*

**Setting contents:** *0 to 15 (Initial setting: 7)*

- This setting is effective when Nav. In is “On” in “Setting the Navigation Mode” (page 48).

## AUX Setting

Touch **[AUX]** on the Application setup menu in step 3. Refer to “Application Setup Operation” (page 46).

### Setting the AUX Mode

**Setting item:** *AUX In*

**Setting contents:** *Off / On (Initial setting)*

- Off: AUX source is not displayed.
- On: AUX source is displayed.

- After selecting “On” in the “AUX In” setting, touch **[AUX In]**, the following further items can be adjusted.

### Setting the Primary AUX Name

**Setting item:** *Primary Name*

**Setting contents:** *AUX1(Initial setting) / DVD / GAME / EXT.DVD / DVD-CHG. / DVB-T / TV / USB Player*

- When a DVB-T tuner or USB Player (sold separately) is connected, you can use it to connect one more External Input device. Setting the Secondary name can change the mode name display of this device.

### Setting the Secondary AUX Name

Secondary name can be set only when Primary name is set to “DVB-T” or “USB Player.”

**Setting item:** *Secondary Name*

**Setting contents:** *OFF (Initial setting) / AUX2 / DVD / GAME / EXT.DVD / DVD-CHG. / DVB-T\*<sup>1</sup> / TV / USB Player\*<sup>2</sup>*

- The selected source name is displayed instead of AUX mode name.

\*<sup>1</sup> If the Primary Name is DVB-T, DVB-T is not displayed as a Secondary Name option.

\*<sup>2</sup> If the Primary Name is USB Player, USB Player is not displayed as a Secondary Name option.

### Setting Direct Touch Operation

If DVB-T is set as the Primary Name or Secondary Name, this setting is available.

**Setting item:** *Direct Touch*

**Setting contents:** *ON (Initial setting) / OFF*

- ON: Direct Touch operation is available on the DVB-T screen.
- OFF: Direct Touch operation is not available on the DVB-T screen.

### Switching the Visual Input Signal System

After setting to “On” in “Setting the AUX Mode,” this setting can be carried out. The video input type can be changed.

**Setting item:** *Signal*

**Setting contents:** *Auto (Initial setting) / NTSC / PAL*

- Auto: The video input signal type (NTSC or PAL) will be automatically selected.
- NTSC/PAL: Choose the video input signal type manually.

## Setting the AUX3

Connection with external input devices is available through the iPod VIDEO connector. An optional adapter cable is required (standard RCA to 3.5ø mini-phono plug or 3.5ø to 3.5ø mini phono plug). You can also play back video connecting with an optional AV cable (4-pole mini AV plug to 3-RCA).

**Setting item:** *AUX3 In Sel.*


**Setting contents:** *iPod Video (Initial setting) / AUX3*

iPod Video: Set when connected to an iPod or iPhone.

AUX3: Set when connected to an external input device.

### ■ Usable 4-pole mini AV plug

The unit accepts the following 4-pole mini AV plug pin-out:



- Please check pin-out carefully before use of this product. Depending on the cable, there may be no picture and/or sound.

## Switching the Visual Input Signal System (AUX3 In Sel.)

After setting to "AUX3" in "Setting the AUX3 In Sel.," this setting can be carried out. The video input type can be changed.

**Setting item:** *Signal*

**Setting contents:** *Auto (Initial setting) / NTSC / PAL*

Auto: The video input signal type (NTSC or PAL) will be automatically selected.

NTSC/PAL: Choose the video input signal type manually.

## RSE Setting

[RSE] is selected on the Application setup menu in step 3. Refer to "Application Setup Operation" (page 46).

## Setting the Rear Seat Entertainment System

Video and audio can be output to the rear monitor.

**Setting item:** *RSE*

**Setting contents:** *Off (Initial setting) / On*

## Phone Setting

Touch [Phone] on the Application setup menu in step 3. Refer to "Application Setup Operation" (page 46).

### Setting Received Calls Automatically

When a call is received, you can set whether to answer it automatically or not.

**Setting item:** *Auto Answer*

**Setting contents:** *Off (Initial setting) / On*

On: When a call is received, it will be answered automatically

Off: When a call is received, it will not be answered automatically

### Setting the time for automatic reception of a call

When "Auto Answer" is set to "On," you can set how many seconds to let elapse before letting the Auto Answer pick up the call.

**Setting item:** *Time*

**Setting contents:** *5sec / 10sec (Initial setting) / 15sec / 20sec*

#### 1 Touch [Auto Answer].

The Auto Answer setting screen is displayed.

#### 2 Touch [◀] or [▶].

## Selecting the Output Speaker

You can select which speaker in the car will output the audio from the phone.

**Setting item:** *Phone Speaker*

**Setting contents:** *All(Initial setting) / Front L / Front R / Front LR*

All: The sound is output from all speakers in car.

Front L: The sound is only output from the front left speaker.

Front R: The sound is only output from the front right speaker.

Front LR: The sound is output from the front left and front right speakers.

- The setting cannot be adjusted during a phone call. Adjust the setting before placing a call.

## Adjusting the Receive Volume

You can adjust the volume of the incoming call.

**Setting item:** *Receiver Volume*

**Setting contents:** *1 to 11 (Initial setting: 5)*

## Adjusting the Transmit Volume

You can adjust the transmit volume, during the call.

**Setting item:** *Transmitter Volume*

**Setting contents:** *1 to 11 (Initial setting: 5)*

## Adjusting the Calling Volume

You can adjust the receive volume, during the call.

**Setting item:** *Calling Volume*

**Setting contents:** *1 to 11 (Initial setting: 5)*

## Disc Setting

Touch **[Disc]** on the Application setup menu in step 3. Refer to "Application Setup Operation" (page 46).

**Not settable during DVD Video play. Touch [■].**

### Changing the language setting

The audio language, subtitle language and menu language can be set according to your preferences.

Once set, this becomes the default language. This function is convenient if you always want to listen in English, for example. (The language setting is not effective on some discs. In this case, the default language is set at the factory.)

- When the settings are changed, old settings are overwritten. Make a note of the current settings before making changes.
- To temporarily change the language of the current disc, either do so from the DVD menu or by using the operation described in the section "Switching the Audio Tracks" (page 34).
- If the disc does not include the selected language, the disc's default language is set.

#### To play in a language other than those displayed

- 1 Touch **[Code]**.  
The numeric keypad screen is displayed.
  - 2 Touch the 4-digit numeral of the language number.  
To reference language numbers, refer to "List of Language Codes" (page 76).
  - 3 Touch **[Enter]** to memorize the number.
- The setting content changes to "OTHER" if the desired language code is input.

### Setting of the Menu Language

Set the language used for the menus (title menu, etc.).

**Setting item: Menu Language**

**Setting contents: Auto (Initial setting) / EN / JP / DE / ES / FR / IT / SE / RU / CN**

- When "Auto" is selected, the primary menu language among the recorded ones is played.
- As for the language abbreviation, refer to "List of Language Codes" (page 76).

### Setting of the Audio Language

Set the audio language produced from the speakers.

**Setting item: Audio Language**

**Setting contents: Auto (Initial setting) / EN / JP / DE / ES / FR / IT / SE / RU / CN**

- When "Auto" is selected, the primary audio language among the recorded ones is applied.
- As for the language abbreviation, refer to "List of Language Codes" (page 76).

### Setting of the Subtitle Language

Set the language of the subtitles displayed on the screen.

**Setting item: SUBT. Language**

**Setting contents: Auto (Initial setting) / EN / JP / DE / ES / FR / IT / SE / RU / CN**

- When "Auto" is selected, the primary subtitle language among the recorded ones is applied.

- As for the language abbreviation, refer to "List of Language Codes" (page 76).

## Changing the Country Code Setting

Set the country code of which you want to set the rating level (Parental lock).

**Setting item: Country Code**

**Setting contents: Auto / OTHER**

- Auto:** The primary country code among those recorded is played.
- OTHER:** The setting content changes to "OTHER" if the desired country code is input.

- If settings are changed, the old settings are overwritten. Make a note of the current settings before making changes. The settings will be cleared if the vehicle's battery is disconnected.

- 1 Touch **[Code]**.
- 2 Touch **[←]** or **[Delete All]**.  
Delete the displayed country number.
- 3 Touch the 4-digit country code.  
As for the country number, refer to "List of Country Codes" (page 77).
- 4 Touch **[Enter]** to memorize the code.

## Setting the Rating Level (Parental Lock)

This function can help limit the viewing of movies to children of appropriate age levels only.

**Setting item: Parental**

- If settings are changed, the old settings are overwritten. Make a note of the current settings before making changes. The memory will be cleared if the vehicle's battery is disconnected.
- On unrated discs, playback will not be restricted even if the rating level is set.
- If you want to play back a disc with parental lock, and its use is currently restricted, change the rating level and the country number in order to play back the disc.
- Once set, this rating level remains in memory until changed. To enable playback of discs of higher rating levels, or to cancel the parental lock, the setting must be changed.
- Not all discs provide a parental lock. If you are unsure about a disc, play it first to confirm. Do not leave discs accessible to young children for whom you deem them inappropriate.

- 1 Touch **[Input]**.  
The numeric keypad screen is displayed.
- 2 Touch the numeric keypad to input a 4-digit password.  
The initial number is 1111. Input number are displayed as "\*".
- 3 Touch **[Enter]** to memorize the number.  
The Parental screen appears.

### ■ Set the rating level of PARENTAL

- 4 Touch **[▶]** of "Parental" to turn "On."
- 5 Touch **[◀]** or **[▶]** of "Parental Level" to select the rating level (1 to 8).  
Select "Off" to cancel parental lock or if you do not want to set a rating level. The smaller the number, the higher the restriction.
- 6 Touch **[<]** to return to the previous screen.

## ■ Changing the password

- 4 Touch [Input] of "Password Change."  
The numeric keypad screen is displayed.
- 5 Touch the input screen to enter a new 4-digit password.
  - *Keep a note of the number somewhere safe in case you should forget it.*
- 6 Touch [Enter] to memorize the number.
- 7 Touch [<] to return to the previous screen.

### Changing the rating level temporarily

Some discs may request that you change the rating level set in the default settings during playback. In this case, the message "Do you wish to change Parental level? [OK] [Cancel]."

If this screen appears, change the level as follows:

- **To change parental level and play, touch [OK].**  
When [OK] is touched, the numeric keypad input screen is displayed. Input the 4-digit password you set in "Setting the Rating Level (Parental Lock)," then touch [Enter].
- **To play without changing the parental level, touch [Cancel].**  
(If [Cancel] is touched, playback will be at the parental level set in "Setting the Rating Level (Parental Lock).")

## Setting the TV Screen Mode

Use the procedure described below to modify the output screen according to the type of TV monitor (rear monitor) being used. If the rear monitor is not connected, the screen setting is 16:9.

**Setting item: TV Screen**

**Setting contents: 4:3LB / 4:3PS / 16:9 (Initial setting)**

- *For some discs, the picture may not be set to the selected screen size. (For details, refer to the explanation on the disc's jacket.)*

### 4:3 LETTER BOX:

Select this when connected to a conventional 4:3 size (normal TV aspect ratio) monitor. There may be black stripes visible at the top and bottom of the screen (when playing a 16:9 size movie). The width of these stripes will depend upon the original aspect ratio of the theatrical release of the movie.



### 4:3 PAN-SCAN:

Select this when connected to a conventional 4:3 size monitor. The picture will fill the entire TV screen. However, due to the mismatch in aspect ratio, parts of the movie at the extreme left and right sides will not be visible (when playing a 16:9 size movie).



### 16:9 WIDE:

Select this when connected to a wide screen TV. This is the factory setting.



## Radio Setting

Touch [Radio] on the Application setup menu in step 3. Refer to "Application Setup Operation" (page 46).

### PI SEEK Setting

**Setting item: PI Seek**

**Setting contents: Auto / Off (Initial setting)**

### Receiving RDS Regional (Local) Stations

When Off is selected, the unit automatically keeps receiving the local RDS station.

**Setting item: RDS Regional**

**Setting contents: On (Initial setting) / Off**

### Switching the Display Language of PTY (Programme Type)

**Setting item: PTY Language**

**Setting contents: ENG (Initial setting) / GER / FRE / SPA / POR / ITA / DUT / DAN / FIN / NOR / SWE / RUS**

ENG:	English
GER:	German
FRE:	French
SPA:	Spanish
POR:	Portuguese
ITA:	Italian
DUT:	Dutch
DAN:	Danish
FIN:	Finnish
NOR:	Norwegian
SWE:	Swedish
RUS:	Russian

### Setting PTY31 (Emergency Broadcast) Reception

PTY31 (Emergency Broadcast) reception can be set to On/Off.

**Setting item: PTY31**

**Setting contents: On (Initial setting) / Off**

- *The unit automatically gives priority to an emergency broadcast whenever it begins, and interrupts the programme you are currently listening to when PTY31 is set to "On."*
- *The unit will show "Alarm" in the display during PTY31 reception.*

## Setting the TUNER (FM) Tone Quality (Tuner Condition)

This unit can set your preferred tone quality for FM radio source.

### **Setting item: FM Tuner Setting**

**Setting contents: Normal (Initial setting) / HiFi / Stable**

Normal:	Standard setting
HiFi:	High-quality setting
Stable:	Control noise

- *Noise may be more noticeable when HiFi is set, depending on the reception status. In this case, the Normal setting is recommended.*

130.com.ua

# BLUETOOTH Operation

## Setup Before Using

### About BLUETOOTH

BLUETOOTH is a wireless technology allowing communication between a mobile device or personal computer over short distances. This enables a hands-free call or data transmission between BLUETOOTH compatible devices. BLUETOOTH transmission is available in the unlicensed 2.4 GHz spectrum if the distance between devices is within 10 meters. For details, refer to the BLUETOOTH website (<http://www.bluetooth.com/>).

- Depending on the BLUETOOTH version, a BLUETOOTH compatible device may not be able to communicate with this unit.
- Proper function of this unit with all BLUETOOTH compatible devices is not guaranteed. For handling of the BLUETOOTH compatible device, consult your ALPINE dealer or ALPINE website.
- Depending on the surroundings, BLUETOOTH wireless connection may be unstable.
- When you place a call, or perform setup operations, be sure to stop your car in a safe place.
- Depending on the connected BLUETOOTH compatible device(s), the function may differ. Also refer to the Owner's Manual of the connected device(s).

### About the Hands-Free Phone

Hands-free calls are possible when using a HFP (Hands-Free Profile) compatible mobile phone with this unit.

- Avoid performing a hands-free call in heavy traffic or on narrow or winding streets.
- Close the windows while calling to reduce background noise.
- If both calling parties are using hands-free devices, or the call is made in a noisy location, difficulty hearing the other person's voice is normal.
- Depending on telephone line conditions or certain mobile devices used, voices may sound unnatural.
- When using a microphone, speak as directly as you can into the microphone to obtain the best sound quality.
- Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality.

All features, functionality, and other product specifications, as well as the information contained in the Owner's Manual are based upon the latest available information and are believed to be accurate at the time of printing.

Alpine reserves the right to change or modify any information or specifications without notice or obligation.

### Before Using BLUETOOTH

Before using the hands-free phone/audio function, the following settings need to be made.

- 1 Set "BLUETOOTH" to "On" (see page 43).

- 2 Register a BLUETOOTH device in this unit (see page 43).

- Refer to "BLUETOOTH Setting" (page 43).
- You can search for this unit using a BLUETOOTH compatible device, and then connect that BLUETOOTH compatible device to this unit. The device name of this unit is "ICS-X8" and the initial number of the passcode is "0000." Also refer to the Owner's Manual of the connected device(s).


## Connecting a BLUETOOTH Device

Registering a BLUETOOTH device in ICS-X8 enables automatic connection.

If it does not connect automatically, run through the connection procedure again.

- 1 Press the **Home** button.  
The Home screen is displayed.

- 2 Touch **[Phone]** or **[BLUETOOTH]**.



- 3 Touch **[Reconnect]**.  
BLUETOOTH connection will start.

### Disconnecting the BLUETOOTH Connection

Touch **[Disconnect]** on the "Phone" or "BLUETOOTH Audio" screen.

The BLUETOOTH connection is disconnected.

## Changing the connecting BLUETOOTH Device

If multiple BLUETOOTH devices are registered in this device, you can change the connection among the registered devices.

- 1 Press the **Home** button.  
The Home screen is displayed.
- 2 Touch **[Phone]** or **[BLUETOOTH]**.
- 3 Touch **[Change]**.  
The Set BLUETOOTH Device screen is displayed.
- 4 Touch **[Audio]** or **[HFT]** of the selected device.  
The connection will transfer to the selected device.

# Hands-Free Phone Control

## Answering a Call

Incoming calls are announced by the received call ring tone and a displayed message (PHONE No., etc.).

- 1 **An incoming call triggers the ringtone and an incoming call display.**
- 2 **Touch [📞] or press Media Control button 1.**  
The call starts.

- When “Setting Received Calls Automatically” (page 49) is set to “On,” you can receive a call automatically.
- During a call, the audio for the current mode on the unit is muted. After calling, playback will resume.
- When the caller’s number is transmitted to the system, if the caller’s name is stored in the phone book, the name is displayed. If the name is not stored, the number is displayed. When neither the name or the number is unavailable, “Unknown” is displayed.

## Adjusting ringtone volume

The ringtone volume is adjustable on the incoming call message screen.

**Touch [⏮] or [⏭] for “Vol.”**

## Hanging up the Telephone

**Touch [📞] or press Media Control button 3.**  
The call finishes.

## Calling

Use the Phone menu screen to make a phone call.

### Calling display example




## Dialling a Number In Call History

You can use 4 types of history to make a phone call. Call History saves up to 60 phone numbers. If the limit is exceeded, the oldest phone number is deleted.

- 1 **Press the Home button.**  
The Home screen is displayed.
- 2 **Touch [Phone].**  
The phone menu screen is displayed.

- 3 **Touch [Recent Calls].**  
The Recent Calls screen appears.

### Display example for Call History screen



- 📞 : Dialed history
- 📞 : Unanswered history
- 📞 : Received history
- 📞 : Missed Incoming history

- 4 **Touch the name or the telephone number from the call history list.**

The details screen of the call history is displayed.

- 5 **Touch [📞].**  
The phone call is started.

## Dialing a Number In the Phone Book

You can use the phone book of the mobile phone to make a phone call. Before using, you need to transfer the phone book from the mobile phone to the system. For details on how to transfer the phone book, refer to “Synchronising the Phone Book” (page 55).

- 1 **Press the Home button.**  
The Home screen is displayed.
- 2 **Touch [Phone].**  
The phone menu screen is displayed.
- 3 **Touch [Phone Book].**
- 4 **Touch the person name or the telephone number from the Phone Book list.**
- 5 **Touch [📞].**  
The phone call is started.

## Entering a Phone Number to Make a Call

- 1 **Press the Home button.**  
The Home screen is displayed.
- 2 **Touch [Phone].**  
The phone menu screen is displayed.
- 3 **Touch [Keypad].**  
The number input screen appears.
- 4 **Enter the phone number you wish to call.**
  - You can enter up to 31 digits.
- 5 **Touch [📞].**  
The phone call is started.

## Using Short Cut Dialling to Make a Call

You can assign up to 3 phone numbers for one-touch dialling to make a call easily. For how to assign one-touch dialling, refer to “Assigning as a Short Cut Dialling Number” (page 56).

### 1 Press the **Home** button.

The Home screen is displayed.

### 2 Touch **[Phone]**.

The phone menu screen is displayed.

### 3 Touch **[Dial1]**, **[Dial2]** or **[Dial3]**.

The phone call is sent to the stored number.

- If a name has been registered, the name is displayed on the shortcut button.

## Redial Function

You can redial the person you have previously called.

### 1 Press the **Home** button.

The Home screen is displayed.

### 2 Touch **[Phone]**.

The phone menu screen is displayed.

### 3 Touch **[Redial]**.

### 4 Touch **[Call]**.

The number is redialed.

## Operations During a Conversation

### Display example



- ① Name and phone number
- ② Conversation time

## Adjusting the Speech Volume

You can adjust the transmit volume and receive volume respectively.

### Touch **[◀]** or **[▶]** for “Vol.”

📞: Outgoing volume

📞: Incoming volume

You can adjust the volume in 11 levels.

Touch **[◀]** to turn down the volume. Touch **[▶]** to turn up the volume.

## Changing the Voice Output

The voice output for calls is switchable between car speakers and the mobile phone speaker.

### Touch **[🔊] ↔ 📞]** or press **Media Control button 2**.

- Depending on the mobile phone, this operation may not be possible.

## DTMF (Touch-Tone) Function

Transmits a DTMF (Touch-Tone) during a call.

### 1 Touch **[Keypad]**.


The number input screen appears.

### 2 Input number.

- You can transmit a Touch-Tone signal during a call.
- Touching and holding “0” initiates “+” tone transmission.

## Phone Book Function

### Display example for Phone Book screen



- ① An icon is displayed to indicate that multiple phone numbers are registered under an entry.

## Synchronising the Phone Book

You can synchronise the system’s phone book with the mobile phone’s phone book.

### 1 Press the **Home** button.

The Home screen is displayed.

### 2 Touch **[Phone]**.

The phone menu screen is displayed.

### 3 Touch **[Load]**.

### 4 Touch **[SYNC]**.

Synchronisation of the phone books starts.

- You can store up to 1,000 phone numbers in the phone book of the system.
- You can store up to 5 phone numbers by one person’s name.



## Adding the Phone Book

- 1 Press the Home button.**  
The Home screen is displayed.
- 2 Touch [Phone].**  
The phone menu screen is displayed.
- 3 Touch [Load].**
- 4 Touch [Add].**  
Stays on standby for connection of the mobile phone.
  - Touch [Cancel] to cancel the standby mode.
- 5 The mobile phone accesses this unit and then transfers the phone book from the mobile phone to this unit.**
  - Mobile phone connection is cancelled while the phone book is being transferred.

## Deleting the Phone Book Entries

### Deleting One Entry from the Phone Book

- 1 Press the Home button.**  
The Home screen is displayed.
- 2 Touch [Phone].**  
The Phone menu screen is displayed.
- 3 Touch [Phone Book].**  
The Phone Book screen is displayed.
- 4 Touch the phone number you intend to delete.**  
The detail screen of the Phone book is displayed.  
When 2 phone numbers are stored in the entry, touch the phone number you intend to delete.
- 5 Touch [Delete].**  
The confirmation screen is displayed.
- 6 Touch [OK].**  
The selected number is deleted.


### Deleting All Entries from the Phone Book

- 1 Press the Home button.**  
The Home screen is displayed.
- 2 Touch [Phone].**  
The Phone menu screen is displayed.
- 3 Touch [Phone Book].**  
The Phone Book screen is displayed.
- 4 Touch [Delete All].**  
The confirmation screen is displayed.
- 5 Touch [OK].**  
All entries of the phone book are deleted.

## Percent Search Function

The unit's percent search function can be used to search for phone book, more efficiently.

- 1 Press the Home button.**  
The Home screen is displayed.
- 2 Touch [Phone].**  
The Phone menu screen is displayed.
- 3 Touch [Phone Book].**  
The Phone Book screen is displayed.
- 4 Touch anywhere on the Percent search bar.**



Percent search bar

For example, 100 entries are stored in the Phone book. These 100 entries are divided into 10 groups (10%, 20%, ... 100%).

Suppose the number you are searching for is located at around the 50th number of your phone book: touch around the middle (50%) of the percent search bar to jump to the number you desire.

## Assigning as a Short Cut Dialling Number

### Assigning from Call History

- 1 Press the Home button.**  
The Home screen is displayed.
- 2 Touch [Phone].**
- 3 Touch [Recent Calls].**
- 4 Touch the person name you intend to assign as the Short Cut dialling number.**  
The details screen of the Phone book is displayed.
- 5 Touch [Preset].**  
The details screen for the Short Cut is displayed.
- 6 Touch [Save].**  
The phone number is assigned to the selected Short Cut dialling number.
  - If Dial1, Dial2 or Dial3 is already registered, it is overwritten.
  - Touch [Delete] to delete an assigned short cut dialling number.

### Assigning from the Phone Book.

- 1 Press the **Home** button.**  
The Home screen is displayed.
  - 2 Touch **[Phone]**.**
  - 3 Touch **[Phone Book]**.**
  - 4 Touch the phone number you intend to assign as the Short Cut dialling number.**  
The details screen of the Phone book is displayed.
  - 5 Touch **[Preset]**.**  
The details screen for the Short Cut is displayed.
  - 6 Touch **[Save]**.**  
The phone number is assigned to the selected Short Cut dialling number.
- *If Dial1, Dial2 or Dial3 is already registered, it is overwritten.*
  - *Touch **[Delete]** to delete an assigned short cut dialing number.*

130.com.ua

# BLUETOOTH Audio

If a BLUETOOTH compatible mobile phone, portable player, etc. is connected by wireless, you can play back a song (operation is controllable from the unit).

## ■ Display example for BLUETOOTH Audio main screen

### Simple mode



### Info mode



- ① Current song no.
- ② Status Indicator  
The Indicator displays during Repeat and M.I.X. playback.
- ③ Song title
- ④ Artist title
- ⑤ Album title
- ⑥ Next file (song) title
- ⑦ Elapsed time
- ⑧ Audio Setup button (see "Audio Setup Operation" on page 35)

- The displayed onscreen buttons may differ depending on the AVRCP version.
- Status Indicator/Song title/Artist title/Album title/Elapsed time do not display for AVRCP Ver. 1.0.
- For instructions on switching between Simple mode and Info mode, refer to "Switching between Simple Mode & Info Mode" (page 19).
- To play back audio, a mobile phone or a portable player conforming to A2DP (Advanced Audio Distribution Profile) or AVRCP (Audio/Video Remote Control Profile) is required.  
Not all functions work with all devices.
- During a call, sound on the BLUETOOTH audio source is muted.

### Compatible AVRCP versions: 1.0, 1.3, 1.4

- Available functions may differ depending on the AVRCP version.

# Playback

- 1 **Press the Home button.**  
The Home screen is displayed.
- 2 **Touch [BLUETOOTH].**
- 3 **Touch [◀◀] or [▶▶] to select the desired track (file).**

### Returning to the beginning of the current file:

Touch [◀◀].

### Fast backward the current file:

Touch and hold [◀◀].

### Advance to the beginning of the next file:

Touch [▶▶].

### Fast forward the current file:

Touch and hold [▶▶].

- 4 **To pause playback, press Media Control button 2 (▶/||).**

Pressing Media Control button 2 (▶/||) again will resume playback.


- Operations can be performed in the same way by pressing **Media Control buttons 1 or 3**. Refer to "Using the Media Control buttons" (page 14).

# Repeat Play

Available for AVRCP Ver. 1.3 and 1.4 only.

### Touch [↺] during playback.

The repeat mode switches every time the button is touched.




- Operations may differ depending on the connected BLUETOOTH compatible device.

## M.I.X. (Random Play)

Available for AVRCP Ver. 1.3 and 1.4 only.

**Touch [⌂] during playback.**

The M.I.X. mode switches every time [⌂] is touched.



- Operations may differ depending on the connected BLUETOOTH compatible device.

## Selecting Groups

Available for AVRCP Ver. 1.3 and 1.4 only.

**Touch [◀ Group] or [Group ▶] to select the group.**

## Search Function

Available for AVRCP Ver. 1.4 only.

The displayed list differs with the connected BLUETOOTH device.

### 1 Touch [🔍 (Search)] during playback.

Select the track, etc., you want to listen to from the displayed list.

# Navigation System (Optional)

## Switching the Navigation Screen (Optional)

If an optional Alpine Navigation System is connected to the ICS-X8, the Navigation screen can be displayed on this unit.

### 1 Press the **Home** button.

The Home screen is displayed.

### 2 Touch [Nav].

The Navigation screen is displayed.

The operation is possible with the navigation.

For navigation operations, refer to the Owner's Manual of the navigation.

- If the Navigation icon is not displayed on the Home screen, select "On" in "Setting the Navigation Mode" (page 48).
- When the Navigation System is on and in guidance mode, the voice prompts, and the navigation map interrupts the current audio source.

# Auxiliary Device (Optional)

## Operating Auxiliary Devices (Optional)

To operate devices connected to the AUX terminals of ICS-X8, follow the procedure described below.

- Set AUX In to "On." Refer to "Setting the AUX Mode" (page 48).
- Depending on the connected unit, the onscreen buttons may not work, or their operation may differ.

### ⚠ WARNING

It is dangerous (and illegal in many states) for the driver to watch TV/video while driving the vehicle. The driver may be distracted from looking ahead and an accident could occur.

Install the ICS-X8 correctly so that the driver cannot watch TV/video unless the vehicle is stopped and the emergency brake is applied.

If the ICS-X8 is not installed correctly, the driver will be able to watch TV/video while driving the vehicle and may be distracted from looking ahead and cause an accident. The driver or other people could be severely injured.

- If you try to activate the auxiliary device while driving, the display will show the warning-Picture off for your safety.

### 1 Press the **Home** button.

The Home screen is displayed.

### 2 Touch **[AUX1]\*<sup>1</sup>, [AUX2]\*<sup>1</sup> or [AUX3]\*<sup>2</sup>**.

The AUX mode screen is displayed.

\*<sup>1</sup> The name which is given as the mode name in "Setting the Primary AUX Name" (page 48) and "Setting the Secondary AUX Name" (page 48) is displayed.

\*<sup>2</sup> When "Setting the AUX3" (page 49), AUX3 appears when setting "AUX" only.

## AUX Operation Screen Display During Video File Playback

### Touch the screen.

The AUX operation screen is displayed.

### ■ Example for AUX1, AUX2, AUX3, DVD, Game, USB Player mode display



### ① [Audio]

Calls up the Audio Setup screen. (See "Audio Setup Operation" on page 35)

### ② [Display]

Calls up the Display Setup screen. (See "Display Setup Operation" on page 40)

- The operation screen changes to the visual screen in the AUX mode for 5 seconds after an operation has been performed. To hide the AUX operation screen, touch the video display area.

Touch the display panel to display the operation screen again.

- Setting the AUX name for EXT.DVD, DVD-CHG, DVB-T, and TV mode displays their individual operation switches and enables operation. Refer to "Setting the Primary AUX Name" (page 48) and "Setting the Secondary AUX Name" (page 48).
- The direct touch feature is available in USB Player mode. Directly touch operation switches displayed on the screen to operate.

## Operating an External DVD Player

To operate an External DVD player (Optional), set "Setting the Primary AUX Name" (page 48) or "Setting the Secondary AUX Name" (page 48) to "EXT.DVD."

### Change to the External DVD Mode

#### 1 Press the **Home** button.

The Home screen is displayed.


#### 2 Touch **[EXT.DVD]**.

The display shows the EXT. DVD mode screen.

### About the DVD Operation Screen

When the external DVD player playback screen is displayed, you can touch the screen to display the operation screen. For details on how to operate, refer to the Owner's Manual of the connected DVD player.

### ■ External DVD player display example 1/2 (Info mode)



#### ① [Media Control button 1 (fast reverse)]

Touch the switch to go back to the beginning of the current chapter/track/file. Touch the switch once more to find the beginning of the previous chapter/track/file. Touch and hold to fast reverse.

#### ② Media Control button 2 (play/pause)

Switches between play and pause.

#### ③ [Media Control button 3 (fast forward)]

Touch the switch to advance to the beginning of the next chapter/track/file. Touch and hold to fast forward.

#### ④ [Top Menu]


Calls up the Top Menu screen.

#### ⑤ [Menu]

Calls up the Menu screen.


- ⑥ [∞]  
Starts/Stop M.I.X. play.
- ⑦ [↺]  
Starts/Stop repeat play.
- ⑧ [🔊 Audio]  
Calls up the Audio Setup screen. (See "Audio Setup Operation" on page 35)
- ⑨ [◀]  
Switches the programme/playlist/folder down.
- ⑩ [▶]  
Switches the programme/playlist/folder up.
- ⑪ [⏮] [⏭]  
Calls up the menu operation mode.
- ⑫ [Page 1/2]  
Changes the operation screen.

#### ■ External DVD player display example 2/2 (Info mode)



- ⑬ [■]  
Touching during play initiates a pre stop. Touching again stops play.
- ⑭ [🔊 Display]  
Calls up the Display Setup screen. (See "Display Setup Operation" on page 40)
- ⑮ [Angle]  
Switches angle.
- ⑯ [Audio]  
Switches audio.
- ⑰ [Sub T.]  
Switches sub titles.
- ⑱ [Page 2/2]  
Changes the operation screen.

#### ■ Menu operation mode screen display example



- ⑲ [▲], [◀], [▼], [▶]  
Moves menu cursor.
- ⑳ [⏮], [⏭]  
Moves key panel location.
- ㉑ [Enter]  
Determines the selected item.
- ㉒ [Return]  
Returns to the previous item/screen.

- ㉓ [Key]  
The menu operation mode will be displayed.
- ㉔ [X]  
Closes menu operation mode.
- ㉕ [X]  
Closes key panel.

## Operating an External DVD Changer

To operate an External DVD changer (Optional), set "Setting the Primary AUX Name" (page 48) or "Setting the Secondary AUX Name" (page 48) to "DVD-CHG.."

### Change to the External DVD Changer Mode


- 1 **Press the Home button.**  
The Home screen is displayed.
- 2 **Touch [DVD-CHG.].**  
The display shows the DVD-CHG. mode screen.

### About the DVD Changer Operation Screen

When the External DVD changer playback screen is displayed, you can touch the screen to display the operation screen. For details on how to operate, refer to the Owner's Manual of the connected DVD changer.

- The DVD-CHG. operation mode screen 1/3, 2/3, and the Menu operation mode screen are the same as the external DVD player operation screen. Refer to "Operating an External DVD Player."

#### ■ External DVD changer display example 3/3 (Info mode)



- ① [Disc1]-[Disc6]  
Selects a Disc.
- ② [Page 3/3]  
Changes the operation screen.

## Operating the Mobile Digital TV Receiver (DVB-T)

To operate the Mobile Digital TV Receiver (DVB-T) (Optional), set "Setting the Primary AUX Name" (page 48) or "Setting the Secondary AUX Name" (page 48) to "DVB-T."


### Changing to the Mobile Digital TV Receiver (DVB-T) Mode

- 1 **Press the Home button.**  
The Home screen is displayed.
- 2 **Touch [DVB-T].**  
The display shows the DVB-T mode screen.

## About the DVB-T operation screen

When you touch the screen in the DVB-T mode, the operation screen is displayed. For details on how to operate, refer to the Owner's Manual of the connected Digital TV Receiver (DVB-T).

### Menu operation mode screen display example



- ① [◀], Media Control button 1 (◀)  
Switches the Channel number/ Favorite channel number down.
  - ② Media Control button 2 (Channel or FAV)  
Switches between the Channel mode and the Favorite channel mode.
  - ③ [▶], Media Control button 3 (▶)  
Switches the Channel number / Favorite channel number up.
  - ④ [EPG]  
Call up the Electronic Programme Guide (EPG).
  - ⑤ [A/V]  
Switches the source.
  - ⑥ [🔊 Audio]  
Calls up the Audio Setup screen. (See "Audio Setup Operation" on page 35)
  - ⑦ [◀▶]  
Call up the menu operation mode.
  - ⑧ [Scan]  
Touch the switch to start the scan procedure.
  - ⑨ [Menu]  
Call up the menu screen.
  - ⑩ [🔊 Display]  
Calls up the Display Setup screen. (See "Display Setup Operation" on page 40)
- If the setting for "Setting Direct Touch Operation" (page 48) is set to "On," direct touch operation is possible. Directly touch operation switches displayed on the screen to operate. To display the operation screen, touch [Control].

## Operating a TV


To operate a TV Receiver (TV) (Optional), set "Setting the Primary AUX Name" (page 48) or "Setting the Secondary AUX Name" (page 48) to "TV."

### Change to the TV mode

- 1 **Press the Home button.**  
The Home screen is displayed.
- 2 **Touch [TV].**  
The display shows the TV mode screen.

### About the TV operation screen

When the TV playback screen is displayed, you can touch the screen to display the operation screen. For details on how to operate, refer to the Owner's Manual of the connected TV.



- ① [◀], [◀◀], Media Control button 1 (◀, ◀◀)  
Switches the Channel number / Preset channel / frequency down.
- ② Media Control button 2 (Channel or PRESET or MANUAL)  
Switches amongst Channel mode, Preset mode, and Manual mode.
- ③ [▶], [▶▶], Media Control button 3 (▶, ▶▶)  
Switches the Channel number / Preset channel / frequency up.
- ④ [A.Memo]  
The tuner automatically seeks and stores stations.
- ⑤ [Band]  
Switches the band.
- ⑥ [🔊 Audio]  
Calls up the Audio Setup screen. (See "Audio Setup Operation" on page 35)
- ⑦ [🔊 Display]  
Calls up the Display Setup screen. (See "Display Setup Operation" on page 40)

# Camera Operation (Optional)

When an optional camera is connected, the view video of camera can be output to the monitor.

## Rear camera:

If an HCE-C300R\*/HCE-C200R/HCE-C117D/HCE-C107D camera is connected, when the vehicle is reversed, the rear camera view (guide marks for vehicle width and available distance) is displayed automatically on the screen of this unit.

\* When connecting to HCE-C300R, calibration must be performed. For details, refer to "Calibration when connected to HCE-C300R" (page 66) and "Calibration" in the owner's manual of HCE-C300R.

## Rear Camera Operation

Set "Rear" for "Direct Camera" (page 47).

### Displaying the rear view video while the car is in reverse

- 1 **Shift the gear lever to the reverse (R) position.**  
The rear view image is displayed while the car remains in reverse.
- 2 **If you shift the gear lever to a position other than reverse (R), the monitor returns to the previous screen.**
  - Never depend solely on the camera when backing up. Always turn and look and only use the camera for additional assistance.
  - This function is effective when the reverse wire is properly connected.

### Switching the Image Pattern for the Rear Camera

If the camera has a view switch function, the Direct Change switch is displayed.

- 1 **Touch the screen when the image from the rear camera is displayed.**  
The operation screen is displayed on the screen.
  - After a 5-second time-out, the operation screen returns to the camera display screen.
- 2 **Touch [Back], [Panorama], [Corner] or [Top].**  
The image pattern changes.  
[Back]: Rear View  
[Panorama]: Panorama View  
[Corner]: Corner View  
[Top]: Ground View
  - For detailed information about image patterns, see the camera Owner's Manual.

## Guide Display ON/OFF Setting

- 1 **Touch the screen when the image from the camera is displayed.**  
The operation screen is displayed on the screen.
  - After a 5-second time-out, the operation screen returns to the camera display screen.
- 2 **Touch [Guide OFF] on the Rear camera display screen.**  
The guide disappears, and then the [Guide OFF] switch changes to [Guide ON].
- 3 **Touch [Guide ON] to turn on the guide.**

## Adjusting the Caution Display Location

- 1 **Touch the screen when the image from the camera is displayed.**  
The operation screen is displayed on the screen.
  - After a 5-second time-out, the operation screen returns to the camera display screen.
- 2 **Touch [Caution ⬆/⬇].**
  - For each touch, the caution location moves to the top or bottom of the screen.


## About the Rear Camera Guide

To display the guide, set "Guide Display ON/OFF Setting" (page 63) to On. Also, to adjust the guide, refer to "Adjusting the Rear Camera Guide" (page 47). You can also turn off the guide in the Rear camera display screen.



## ■ Indication mark meaning

When the car is put into reverse gear, the monitor switches to the rear view camera image. Guides appear to help visualize the car's width and distance from the rear bumper.



### ① Car width extension marks (red, yellow and green in order of distance)

If properly calibrated, the marks indicate the car's width. This helps guide the car's path when backing up in a straight line.

The marks represent the distance from the rear of the car (from the rear end of the bumper).

- The marks do not move in synchronisation with the steering wheel.

### ② Distance guidance marks


The marks represent the distance from the rear of the car (from the rear end of the bumper).

- The marks do not move in synchronisation with the steering wheel.
- Each centre position of the mark represents about 0.5 m (red), about 1 m (yellow) and about 2 m (green) behind.
- Depending on the condition of the car or road surface, the range of vision may vary.
- The camera has a limited range of vision. Objects at extreme angles to the camera (e.g. under the bumper or at opposite ends of the bumper) may not be in the its field-of-vision.
- The rear camera image may have a tint which is different from the actual surroundings.
- Depending on the car, the guidance may deviate to the right or left. This is not a malfunction.


## ■ Distance guidance mark

The distance guides represent the ground level distance from the rear bumper. It is difficult to accurately estimate the distance to objects above ground level.

<Screen>



<Positions of A, B and C>



In the screen, according to the distance guidance marks, the truck seems to be parked about 1 m away (at the position B). In actual fact, however, if you reversed to position A, you would collide with the truck. In the screen, positions A, B and C seem to be located in order of proximity. However, in actual fact, the position A and C are the same distance, and B is farther away than positions A and C.

- The car width extension mark represents the distance to the road surface. The distance to an object on the road is not accurately represented by the guides.
- In the following conditions, screen visibility may be impaired. This is not a malfunction.
  - When it is dark (during the night, etc.).
  - Under very high or very low temperature conditions.
  - When water drops adhere to the camera, or when the humidity is high (such as rainy weather, etc.).
  - When foreign bodies (such as mud, etc.) adhere to the camera or its peripheral area.
  - When sunlight or headlights directly strike the camera lens.
  - When a CCD camera is connected, smearing\* may occur. This phenomenon is peculiar to CCD cameras.

### \* Smear phenomenon:

A phenomenon which occurs when a high-intensity spot (such as a reflection of the sunlight on a car body) is shot by the camera. The picture below is an example of 'vertical smear' common to CCD cameras.




A high-intensity spot

## Error between the screen and the actual road surface

In the following conditions, errors are produced between the screen guidance and the actual road surface. (The illustrations represent a case when the camera is installed in the standard position.)


■ When there is a steep upward slope behind the car (example)

<Screen>




Distance guidance marks

<Situation of the car>




■ When there is a steep downward slope behind the car (example)

<Screen>



<Situation of the car>



The distance guidance mark represents the distance to a flat road surface. Therefore in the case of an upward slope behind the car, the distance guides are displayed closer to the rear bumper than the actual distance. For example, if there is an obstacle on the upward slope, it may appear farther away than its actual position. Also, an error may occur between the guidance and the actual path of the car on the road surface.

In the case of a downward slope behind the car, the distance guides are displayed farther from the rear bumper than the actual distance. If there is an obstacle on the downward slope, it seems closer than its actual position. Also, an error may occur between the guidance and the actual path of the car on the road surface.

## Calibration when connected to HCE-C300R

Obstacle detection performance adjustment and guidance mark settings of HCE-C300R (REAR VIEW CAMERA SYSTEM) require that camera installation information be entered and calibration performed. If camera information is not entered, accurate detection will not be possible, so be sure to perform calibration. For details on calibration, refer to “Calibration” in the owner’s manual of HCE-C300R. To perform calibration with the supplied switch, refer to “Performing Calibration” in the owner’s manual of HCE-C300R. When connected to this unit, you can perform operations via the screen of this unit.

### About the Connection


Refer to “Connection of HCE-C300R” (page 94) for details on connecting the unit to HCE-C300R.

### About the Camera Settings


Before performing calibration, set the camera. Set “Direct Camera” to “Rear.” Refer to “Setting the Camera Input” (page 47).

## To activate the Calibration Setup Mode of this unit

- 1 Set the **SETUP** switch of the control unit to “ON.”




- 2 Set the ignition key to **ACC ON**.  
The camera system starts in calibration mode.
- 3 Touch any area of the screen to display the onscreen buttons.
- 4 Touch **[Back]** → **[Corner]** → **[Back]**, following the instructions on the screen.



The Setup Mode screen appears.

Continue with the following operations after performing step 4 in “Performing Calibration” of the owner’s manual of HCE-C300R. During these operations, touch the button on the screen to select “CHANGE” or “DONE” to perform calibration on this unit. Touching **[Corner]** and **[Back]** on the screen of this unit performs the same operation as pressing the switch which is supplied by HCE-C300R.



**[Corner] = VIEW:** Selects a desired item. (The selected switch is enclosed by a yellow frame.)

**[Back] = SET:** Executes the selection.

# USB Memory (Optional)

This unit can connect to up to 2 USB memory devices. You can play back music files (MP3/WMA/AAC) and video files (DivX®) stored in a USB memory device on the internal player of this system.

This section explains music operations only. Refer to the DivX® operation section in “DVD” (page 28) for information on video.

- If the first file played is a music file, the mode will be the music play mode. If the first file played is a video file, the mode will be the video play mode. Also, the mode changes by selecting “AUDIO” or “VIDEO” in step 2 in Search Function. Refer to “Searching for a Desired Song” (page 68) and “Searching for a Desired Video File” (page 33).

## ■ Display example for the USB main screen (Info mode)

### Audio mode



### Video mode



- Refer to “Display example for MP3/WMA/AAC main screen” (page 25) and “Display example for DivX® main screen” (page 28) for screen element explanations.
- You can display artwork during USB playback.

## ■ About creating a tag information library

You can scan music files in a USB memory device and create a library of tag information in this unit. Library creation starts when the USB memory device is connected. The time it takes to create the library depends on the number of files in the USB memory device, but it may take several minutes.

### About operations during library creation

- “Tag Search” (page 68) does not work properly while a library is being created.
- The order in which songs are played during library creation may differ from the order in the USB memory device.

## Playback

### 1 Press the Home button.

The Home screen is displayed.

### 2 Touch [USB1] or [USB2].

The USB mode is activated and the display changes to the USB screen.

### 3 Touch [◀◀] or [▶▶] or to select the desired track (file).

**Returning to the beginning of the current track (file):**

Touch [◀◀].

**Fast reverse :**

Touch and hold [◀◀].

**Advancing to the beginning of the next track (file) :**

Touch [▶▶].

**Fast forward :**

Touch and hold [▶▶].

### 4 To pause playback, press Media Control button 2 (▶/||).

Pressing **Media Control button 2** (▶/||) again will resume playback.

- Operations can be performed in the same way by pressing **Media Control buttons 1 or 3**. Refer to “Using the Media Control buttons” (page 14).
- Any file protected by DRM (Digital Rights Management) copy protection, cannot be played back on this unit.
- The playback time may not be correctly displayed when a VBR (Variable Bit Rate) recorded file is played back.
- If there is tag information, artist name/album name/track name is displayed.
- ID3 tag/WMA tag  
If an MP3/WMA/AAC file contains ID3 tag/WMA tag information, the ID3 tag/WMA tag information is displayed (e.g., song name, artist name, and album name).
- If the combined number of files/folders in the two USB memory devices reaches 15,000, the message “The system has reached its limit of recognizable files/folders from the USB device.” will be displayed. To delete the message, remove the USB memory devices.

## Repeat Play

Operation differs depending on whether the most recent song search was a Tag Search or a Folder/File Search.

**Touch [↺] during playback.**

The repeat mode switches every time the button is touched.

**Folder/File Search mode:**

Repeat → Repeat Folder\* → (OFF) → Repeat

**Tag Search mode:**

Repeat → (OFF) → Repeat

- \* Only files in a folder are repeatedly played back.
- If the Repeat Play mode is activated during M.I.X. playback, the M.I.X. mode will be cancelled.

## Random Play (M.I.X.)

Operation differs depending on whether the most recent song search was a Tag Search or a Folder/File Search.

### Touch [⌂] during playback.

The tracks (files) on the disc will be played back in a random sequence. To cancel M.I.X. play, touch [⌂].

#### Folder/File Search mode:

M.I.X. Folder\*<sup>1</sup> → M.I.X. File → (OFF) → M.I.X. Folder\*<sup>1</sup>  
⌂ ■                      ⌂ ■                      ⌂ ■

#### Tag Search mode:

M.I.X. Songs\*<sup>2</sup> → (OFF) → M.I.X. Songs\*<sup>2</sup>  
⌂ 🎵                      ⌂ 🎵

\*<sup>1</sup> Only files in a folder are played back in random sequence.

\*<sup>2</sup> M.I.X. Songs randomly plays back songs within a selected category (playlist, album, etc.). The songs within the category are played just once until all songs have been played.

- If the M.I.X. mode is activated during Repeat playback, the Repeat Play mode will be cancelled.
- If you select a track by using the search mode, the M.I.X. play mode will be cancelled.

## Random Play (M.I.X. ALL)

This operation is available only if the most recent song search was a Tag Search.

### Touch [⌂ ALL] during playback.

The tracks (files) on the disc will be played back in a random sequence.

To cancel M.I.X. play, touch [⌂ ALL].

M.I.X. ALL\* → (OFF) → M.I.X. ALL\*  
⌂ [ALL]                      ⌂ [ALL]

\* All songs in the USB memory are played back in random sequence. Any one song does not play back again until all songs have been played back.

## Searching for a Desired Song

ICS-X8 can carry out 2 kinds of searches.

### File/Folder Name Search

**1 Touch [🔍 (Search)] during playback.**

**2 Touch [AUDIO].**

The search mode is activated.

**3 Touch [FOLDERS].**

The folder name list screen is displayed.

#### Folder Name Search Mode

**4 Touch [▶] of the desired folder.**

The first file in the selected folder is played back.

### File Name Search Mode

**4 Touch the desired folder name.**

The file name of the selected folder is displayed.

**5 Touch the desired file name.**

The selected file is played back.

- To return to the previous hierarchy, touch [◀].
- For details on how to scroll through the list, refer to “Selecting an Item in a List” (page 20).
- After selecting a folder via a Folder name search, touch [◀] on the main screen to display the folder search screen.
- After selecting a file via a File name search, touch [◀] on the main screen to display the file search screen.

### Tag Search

By using file tag information and keeping these songs organized in playlists, this unit's search functions will ease song searches in large libraries.

Each music category has its own individual hierarchy. Use the Playlists/Artists/Albums/Songs/Genres/Composers search mode to narrow searches based on the table below.

Hierarchy 1	Hierarchy 2	Hierarchy 3	Hierarchy 4
Playlists	Songs	—	—
Artists	Albums	Songs	—
Albums	Songs	—	—
Songs	—	—	—
Genres	Artists	Albums	Songs
Composers	Albums	Songs	—

For example: Searching by Artist name

The following example explains how an ARTISTS search is performed. Another search mode can be used for the same operation, although the hierarchy differs.

#### ■ Searching by artist name

**1 Touch [🔍 (Search)] during playback.**

**2 Touch [AUDIO].**

The search mode screen appears.

**3 Touch [ARTISTS].**

The Artists search screen is displayed.

**4 Select the desired artist.**

#### To Play Back the Artist Directly

1 Touch [▶] of the artist's name.

All songs of the selected artist are played back.

#### To Search for the Album of the Artist

1 Touch the selected artist name.

The Albums search screen of the selected artist is displayed.

2 Touch [▶] of the desired album's name.

All songs of the selected album are played back.

### **To Search for a Song in the Album of the Artist**

- 1 Touch the desired artist's name.  
All albums of the selected artist are displayed.
  - 2 Touch the desired album's name.  
All songs of the selected album are displayed.
  - 3 Touch the desired song's name.  
The selected song is played back.
- A *Percent search function* is available. Refer to “*Percent Search Function*” (page 72).
  - For details on how to scroll through the list, refer to “*Selecting an Item in a List*” (page 20).
  - After selecting a file via a *Tag search*, touch [ < ] on the main screen to display the search screen. The hierarchy level you selected last in the search mode is displayed.

---

## **Direct Up/Down Function**

---

This operation is available only if the most recent song search was a Tag Search.

Playlist/Artist/Album/Genre/Composer can be easily changed.

For example, if you listen to a song from a selected album, the album can be changed.

### **Touch [ ◀ ] or [ ▶ ] to select the desired Playlist/Artist/Album/Genre/Composer.**

- If an album is selected from an artist search, the album can be searched.
- For details on icon display, refer to “*Direct Up/Down switch icon:*” (page 72).
- If search selection mode is not activated, *Direct Up/Down Function* is not possible.
- During *M.I.X.* playback, this operation is not possible.

---

## **Select the desired Folder (Folder up/down)**

---

This operation is available only if the most recent song search was a Folder/File Search.

If you listen to a file from a selected folder, the folder can be changed.

### **Touch [ ◀ ] or [ ▶ ] to select the folder.**

- During *M.I.X.* playback, this operation is not possible.

# iPod/iPhone (Optional)

An iPod/iPhone can be connected to this unit by using the cable KCU-461iV (sold separately). You can connect a video-capable iPod to enjoy video as well as music.

When the ICS-X8 is connected by the above cable, the controls on the iPod are disabled.

- *Internet or telephone functions, etc., of the iPhone or iPod touch are not controllable from the unit, but these functions can be controlled using the iPhone or iPod touch itself.*
- *To watch the video screen of the file in the iPod/iPhone, the parking brake must be engaged.*
- *For automatic transmission vehicles, place the transmission lever in the Park position.*

## About iPod/iPhone models usable with this unit

- The following devices have been tested and shown to work with this unit. Correct function of earlier versions cannot be guaranteed.
  - iPod nano 6th generation 8GB/16GB: Ver.1.1
  - iPod touch 4th generation 8GB/32GB/64GB: Ver.4.3.1
  - iPod touch 3rd generation 8GB/32GB/64GB: Ver.4.3.1
  - iPod nano 5th generation(video camera) 8GB/16GB: Ver.1.0.2
  - iPod classic(Late2009) 160GB: Ver.2.0.4
  - iPod touch 2nd generation 8GB/16GB/32GB/64GB: Ver.4.2.1
  - iPod nano 4th generation(video) 8GB/16GB: Ver.1.0.4
  - iPod touch 1st generation 8GB/16GB/32GB: Ver.3.1.3
  - iPod nano 3rd generation(video) 4GB/8GB: Ver.1.1.3
  - iPod classic 80GB/160GB: Ver.1.1.2
  - iPod classic 120GB: Ver.2.0.1
  - iPod nano 2nd generation(aluminum) 2GB/4GB/8GB: Ver.1.1.3
  - iPod 5th generation(video) 60GB/80GB: Ver.1.3
  - iPod 5th generation(video) 30GB: Ver.1.3
  - iPod nano 1st generation 1GB/2GB/4GB: Ver.1.3.1
- The following devices have been tested and shown to work with this unit. Correct function of earlier versions cannot be guaranteed.
  - iPhone 4 16GB/32GB: Ver.4.3.1
  - iPhone 3GS 8GB/16GB/32GB: Ver.4.3.1
  - iPhone 3G 8GB/16GB: Ver.4.2.1
  - iPhone 4GB/8GB/16GB: Ver.3.1.3
- For clarity in identifying your model of iPod, please see Apple's own document "Identifying iPod models" at <http://support.apple.com/kb/HT1353>.

### WARNING

**It is dangerous for the driver to watch video while driving the vehicle. The driver may be distracted from looking ahead and an accident could occur.**

**Install the ICS-X8 correctly so that the driver cannot watch Video unless the vehicle is stopped and the emergency brake is applied.**

**If the ICS-X8 is not installed correctly, the driver will be able to watch the Video while driving the vehicle and may be distracted from looking ahead causing an accident. The driver or other people could be severely injured.**



## ■ Display example for iPod/iPhone main screen (Info mode)

### Audio mode



### Video mode



- ① Current song no./Total song no.
  - ② Status Indicator  
The Indicator displays during Repeat and Shuffle playback.
  - ③ Artwork display
  - ④ Song title/Episode title\*
  - ⑤ Artist title/Release Date\*
  - ⑥ Album title/Podcast title\*
  - ⑦ Next file (song) title
  - ⑧ Elapsed time
  - ⑨ Total playback time
- \* *Podcast mode*
- \*\*  : During audio-only playback of a video file in a Playlist, the Video icon is displayed.
-  : During audio-only playback of a music file in a video Playlist, the Music icon is displayed.

## The iPod/iPhone operation screen display during video file playback

**Touch the screen while the iPod/iPhone playback screen is displayed.**

The iPod/iPhone operation screen is displayed.

- *The operation screen changes to the visual screen in the iPod mode for 5 seconds after an operation has been performed.*

## Playback

### 1 Press the **Home** button.

The Home screen is displayed.

### 2 Touch [**iPod**].

The display shows the iPod mode screen.

### 3 Touch [**◀◀**] or [**▶▶**] or to select the desired track (file).

**Returning to the beginning of the current track (file):**

Touch [**◀◀**].

**Fast reverse :**

Touch and hold [**◀◀**].

**Advancing to the beginning of the next track (file) :**

Touch [**▶▶**].

**Fast forward :**

Touch and hold [**▶▶**].

### 4 To pause playback, press **Media Control button 2** (▶/||).

Pressing **Media Control button 2** (▶/||) again will resume playback.

- Operations can be performed in the same way by pressing **Media Control buttons 1** or **3**. Refer to “Using the Media Control buttons” (page 14).
- If a song is playing on the iPod/iPhone when it is connected to the ICS-X8, it will continue playing after the connection.
- An episode may have several chapters. The chapter can be changed by Pressing **Media Control button 1** or **Media Control button 3** or touching [**◀◀**] or [**▶▶**].
- If the artist, album or song name, created in iTunes, has too many characters, songs may not be played back when connected to the ICS-X8. Therefore, a maximum of 64 characters is recommended. The maximum number of characters for the unit is 64.
- Some characters may not be correctly displayed.

## Searching for a Music File

An iPod/iPhone can contain thousands of songs. For this reason, this unit can make various searches using the search function as shown below.

Using the Playlist/Artist/Album/Podcast/Audiobook/Genre/Composer/Song search mode's individual hierarchy, you can narrow down your search as shown in the table below.

<MUSIC Search Menu>

Hierarchy 1	Hierarchy 2	Hierarchy 3	Hierarchy 4
Playlists	Songs	—	—
Artists	Albums	Songs	—
Albums	Songs	—	—
Songs	—	—	—
Podcasts	Episodes	—	—
Genres	Artists	Albums	Songs
Composers	Albums	Songs	—
Audiobooks	—	—	—

**For example: Searching by Artist name**

The following example explains how an ARTISTS search is performed. Another search mode can be used for the same operation, although the hierarchy differs.

### ■ Searching by artist name

#### 1 Touch [**🔍 (Search)**] during playback.

#### 2 Touch [**AUDIO**].

The search mode screen appears.

#### 3 Touch [**ARTISTS**].

The Artists search screen is displayed.

#### 4 Select the desired artist.

### To Play Back the Artist Directly

1 Touch [**▶**] of the artist's name.

All songs of the selected artist are played back.

### To Search for the Album of the Artist

1 Touch the selected artist name.

The Albums search screen of the selected artist is displayed.

2 Touch [**▶**] of the desired album's name.

All songs of the selected album are played back.

### To Search for a Song in the Album of the Artist

1 Touch the desired artist's name.

All albums of the selected artist are displayed.

2 Touch the desired album's name.

All songs of the selected album are displayed.

3 Touch the desired song's name.

The selected song is played back.

- Touching [**▶**] of “ALL” will play back all songs in the list.
- Touching “ALL” will display the search list in the next hierarchy.
- An alphabet skip function is available. Refer to “Alphabet Skip Function” (page 72).
- A Percent search function is available. Refer to “Percent Search Function” (page 72).
- For details on how to scroll through the list, refer to “Selecting an Item in a List” (page 20).

## Searching for a Desired Video File

You can select a movie, music video, etc., from the list screen.

- Video search mode depends on the iPod/iPhone. If the specification of the iPod/iPhone is changed, the search mode on this unit will also be changed.

### Examples for the video search mode

- Video Playlists
- Movies
- Music Videos, etc.

### For example: Searching by Movie

The following example explains how a Movie search is performed.

Another search mode can be used for the same operation, although the hierarchy differs.

#### 1 Touch [**🔍 (Search)**] during playback.

#### 2 Touch [**VIDEO**].

The Video search mode screen appears.

#### 3 Touch [**MOVIES**].

The Movies search screen is displayed.

#### 4 Touch the desired movie.

The selected movie is played back.

- For details on how to scroll through the list, refer to “Selecting an Item in a List” (page 20).




## Percent Search Function

This search mode splits all listings, into 10 groups on the Percent search bar.

If you touch and hold the percentage area, the first character of the first index in each group on the percentage (10-100%) display.

### ■ Display example for Albums search screen




① Percent search bar

#### Percent Search Function:

In search mode, touch anywhere on the Percent search bar to step through items. The search list display also changes according to the selected song position.

## Alphabet Skip Function

The unit is provided with an alphabet skip function for effective searching. When you use this function in the search mode, you can quickly search an artist or a song, etc.




#### Alphabet skip function:

The alphabet skip function is skipped to the next alphabet such as from A to B, B to C by touching [ALPHABET ▼]. You can also skip in reverse order such as from B to A by touching [▲ ALPHABET].

## Direct Up/Down Function

If you touch [▶] of the album name in the search mode, this album will be played back repeatedly. To go to the previous or next Album, use the Direct Up/Down Function.

Touch [◀] or [▶] to select the desired Playlist/Artist/Album/Genre/Podcast/Composer.



Direct Up/Down switch icon

#### Direct Up/Down switch icon:

	Playlist
	Artist
	Album
	Podcast
	Genre
	Composer

- You can use the Direct Up/Down Function during video file playback. The Direct Up/Down Function switches in the video mode are [◀] [▶].
- If you are searching for a song, this operation cannot be performed.
- If an album is selected from an artist search, the album can be searched.
- During shuffle playback, this operation is not possible.

## Search Position Memory

During iPod/iPhone playback, you can quickly move back up the selected hierarchy, a level at time.

#### Touch [◀]. (ex. [◀ Playlists])

The hierarchy level you selected last in the search mode is displayed. Repeated touches return to each previous level up to the highest.

## Repeat Play

#### Touch [↺] to repeatedly play back the currently track.

The tracks (files) will be played repeatedly.  
Touch [↺] again to deactivate Repeat play.

Repeat → (OFF) → Repeat



---

## Random Play (Shuffle)

---

### Touch [**>>**] during playback.

The files will be played back in a random sequence.

The Shuffle mode switches every time [**>>**] is touched.

Shuffle Songs → Shuffle Albums → (OFF) → Shuffle Songs



**Shuffle Albums:** The songs on each album are played back in proper order. Upon completing of all the songs on the album, the next album is selected randomly. This continues until all albums have been played.

**Shuffle Songs:** Song shuffle randomly plays back songs within a selected category (playlist, album, etc.). The songs within the category are played just once until all songs have been played.

- For details on the search mode, refer to “Searching for a Music File” (page 71).

---

## Random Play (Shuffle All)

---

All files in the iPod are played back in random sequence.

### Touch [**>> ALL**] during playback.

The indicator “**>> ALL**” lights, and the songs will be played back in random sequence.

- To cancel, set the Shuffle mode to Off. Refer to “Random Play (Shuffle)” (page 73).

---

## Displaying in Cover Flow

---

You can display the cover flow screen.

Songs can also be selected from artwork on the cover flow screen.

- 1 Touch artwork during play.
- 2 Slide the display horizontally with your finger.



By sliding the display, album artworks on the iPod/iPhone can be flipped through.

- 3 Touch the artwork of the file you wish to listen to.
- You can touch the artwork displayed in the centre. The file for the selected artwork is played.

# Nokia(Optional)

Nokia Drive and Nokia Music applications are made available by connecting compatible Nokia phones to the ICS-X8. The Nokia phone require a specific software to support this feature. To obtain more details about the underlying technology and the compatible phones, please visit [www.alpine-europe.com](http://www.alpine-europe.com) , [www.nokia.com](http://www.nokia.com).

## DISCLAIMER

ENABLED BY CONNECTIVITY FUNCTIONS OF THE NOKIA PHONE, THE MOBILE PHONE'S USER INTERFACES FOR MUSIC OR DRIVE ARE DISPLAYED DIRECTLY ON OUR HEAD UNIT WITH NO ALTERATION. ALPINE SHALL NOT BE RESPONSIBLE OR LIABLE TO USERS FOR ANY DAMAGES, LOSSES OR COSTS RELATED TO OR ARISING OUT OF THESE MOBILE PHONE INTERFACES.

## Using a Nokia Application

To use a Nokia application, connect a compatible Nokia phone to the USB connector with the attached cable.

**When using a Nokia application, we recommend that you connect the Nokia phone via both USB and BLUETOOTH.**

- For details on BLUETOOTH connection, refer to "Registering the BLUETOOTH Device" (page 43).

### 1 Press the Home button.

The Home screen is displayed.

### 2 Touch [Nokia Drive] or [Nokia Music].

The screen for the selected application is displayed.

- Nokia applications can only be linked to when connected to a Nokia phone that is compatible with this unit. Check the Alpine website for compatible models.
- After connecting to a Nokia phone that is compatible with this unit, application icons will appear on the Home screen.
- If you have displayed a screen other than Nokia Drive or Nokia Music using the Nokia phone, ICS-X8 will display the Home screen.
- The Nokia phone applications that can be controlled are "Nokia Drive" and "Nokia Music."
- If the Nokia phone is locked, it cannot be operated from the unit.
- If the built-in GPS of the Nokia phone does not function due to usage conditions, the GPS antenna (optional) connected to this device can be used.
- The Nokia phone connection capacity is 1 phone only. If a second phone is connected, a message saying, "USB device error," will be displayed.

## Displaying the Nokia Drive

### 1 Press the Home button.

The Home screen is displayed.

### 2 Touch [Nokia Drive].

The display shows the Nokia Drive screen.

In Nokia Drive, you can use the direct touch function. You can operate the map by directly touching the operation buttons displayed on the screen.

## Play Nokia Music

Some Nokia Music can be operated from this device.

### 1 Press the Home button.

The Home screen is displayed.

### 2 Touch [Nokia Music].

The display shows the Nokia Music screen.

- Operations can be performed by touching the onscreen buttons or pressing the **Media Control** button.
- Depending on the connected model, some functions cannot be operated.

# Information

## Product Software Update

This product uses software that can be updated through a USB memory device. Download the software from the Alpine website and update the product using the USB memory device.

### Updating this product


Check the Alpine website for details on updating.

<http://www.alpine-europe.com>


## About DVDs

Music CDs and DVDs have grooves (tracks) in which the digital data is recorded. The data is represented as microscopic pits recorded into the track – these pits are read by a laser beam to play the disc. On DVDs, the density of the tracks and pits is twice that of CDs, so DVDs can contain more data in less space.

### CDs



### DVDs



A 12 cm disc can contain one movie or about four hours of music. In addition, DVDs provide sharp picture quality with vivid colors thanks to a horizontal resolution of over 500 lines (compared to less than 300 for VHS tape).

### In addition, DVDs offer a variety of functions.

#### Multiple audio\* (page 34)

Movies can be recorded in up to eight languages. The desired language can be selected from the unit.

#### Subtitles function\* (page 34)

Movies can include subtitles in up to 32 languages. The desired subtitle language can be selected from the unit.

#### Multi angle function\* (page 33)

When the DVD contains a movie shot from multiple angles, the desired angle can be selected from the unit.

#### Multi story function\*

With this function, a single movie includes various story lines. You can select different story lines to view various versions of the same movie.

Operation differs from disc to disc. Story line selection screens including instructions appear during the movie. Just follow the instructions.

\* These functions differ from disc to disc. For details, refer to the disc's instructions.

## List of Language Codes

(For details, see page 50.)

Abbreviation	Code	Language	Abbreviation	Code	Language	Abbreviation	Code	Language
AA	6565	Afar	IE	7369	Interlingue	RN	8278	Kirundi
AB	6566	Abkhazian	IK	7375	Inupiak	RO	8279	Romanian
AF	6570	Afrikaans	IN	7378	Indonesian	RU	8285	Russian
AM	6577	Amharic	IS	7383	Icelandic	RW	8287	Kinyarwanda
AR	6582	Arabic	IT	7384	Italian	SA	8365	Sanskrit
AS	6583	Assamese	IW	7387	Hebrew	SD	8368	Sindhi
AY	6589	Aymara	JP	7465	Japanese	SG	8371	Sangho
AZ	6590	Azerbaijani	JI	7473	Yiddish	SH	8372	Serbo-Croatian
BA	6665	Bashkir	JW	7487	Javanese	SI	8373	Singhalese
BE	6669	Byelorussian	KA	7565	Georgian	SK	8375	Slovak
BG	6671	Bulgarian	KK	7575	Kazakh	SL	8376	Slovenian
BH	6672	Bihari	KL	7576	Greenlandic	SM	8377	Samoan
BI	6673	Bislama	KM	7577	Cambodian	SN	8378	Shona
BN	6678	Bengali, Bangla	KN	7578	Kannada	SO	8379	Somali
BO	6679	Tibetan	KO	7579	Korean	SQ	8381	Albanian
BR	6682	Breton	KS	7583	Kashmiri	SR	8382	Serbian
CA	6765	Catalan	KU	7585	Kurdish	SS	8383	Siswati
CO	6779	Corsican	KY	7589	Kirghiz	ST	8384	Sesotho
CS	6783	Czech	LA	7665	Latin	SU	8385	Sundanese
CY	6789	Welsh	LN	7678	Lingala	SV	8386	Swedish
DA	6865	Danish	LO	7679	Laothian	SW	8387	Swahili
DE	6869	German	LT	7684	Lithuanian	TA	8465	Tamil
DZ	6890	Bhutani	LV	7686	Latvian, Lettish	TE	8469	Telugu
EL	6976	Greek	MG	7771	Malagasy	TG	8471	Tajik
EN	6978	English	MI	7773	Maori	TH	8472	Thai
EO	6979	Esperanto	MK	7775	Macedonian	TI	8473	Tigrinya
ES	6983	Spanish	ML	7776	Malayalam	TK	8475	Turkmen
ET	6984	Estonian	MN	7778	Mongolian	TL	8476	Tagalog
EU	6985	Basque	MO	7779	Moldavian	TN	8478	Setswana
FA	7065	Persian	MR	7782	Marathi	TO	8479	Tonga
FI	7073	Finnish	MS	7783	Malay	TR	8482	Turkish
FJ	7074	Fiji	MT	7784	Maltese	TS	8483	Tsonga
FO	7079	Faroese	MY	7789	Burmese	TT	8484	Tatar
FR	7082	French	NA	7865	Nauru	TW	8487	Twi
FY	7089	Frisian	NE	7869	Nepali	UK	8575	Ukrainian
GA	7165	Irish	NL	7876	Dutch	UR	8582	Urdu
GD	7168	Scots Gaelic	NO	7879	Norwegian	UZ	8590	Uzbek
GL	7176	Galician	OC	7967	Occitan	VI	8673	Vietnamese
GN	7178	Guarani	OM	7977	(Afan) Oromo	VO	8679	Volapuk
GU	7185	Gujarati	OR	7982	Oriya	WO	8779	Wolof
HA	7265	Hausa	PA	8065	Punjabi	XH	8872	Xhosa
HI	7273	Hindi	PL	8076	Polish	YO	8979	Yoruba
HR	7282	Croatian	PS	8083	Pashto, Pushto	ZH	9072	Chinese
HU	7285	Hungarian	PT	8084	Portuguese	ZU	9085	Zulu
HY	7289	Armenian	QU	8185	Quechua			
IA	7365	Interlingua	RM	8277	Rhaeto-Romance			

# List of Country Codes

(For details, see page 50.)

Abbreviation	Code	Country	Abbreviation	Code	Country	Abbreviation	Code	Country
AD	6568	Andorra	DM	6877	Dominica	KI	7573	Kiribati
AE	6569	United Arab Emirates	DO	6879	Dominican Republic	KM	7577	Comoros
AF	6570	Afghanistan	DZ	6890	Algeria	KN	7578	Saint Kitts and Nevis
AG	6571	Antigua and Barbuda	EC	6967	Ecuador	KP	7580	Korea, Democratic People's Republic of
AI	6573	Anguilla	EE	6969	Estonia			
AL	6576	Albania	EG	6971	Egypt	KR	7582	Korea, Republic of
AM	6577	Armenia	EH	6972	Western Sahara	KW	7587	Kuwait
AN	6578	Netherlands Antilles	ER	6982	Eritrea	KY	7589	Cayman Islands
AO	6579	Angola	ES	6983	Spain	KZ	7590	Kazakhstan
AQ	6581	Antarctica	ET	6984	Ethiopia	LA	7665	Lao People's Democratic Republic
AR	6582	Argentina	FI	7073	Finland			
AS	6583	American Samoa	FJ	7074	Fiji	LB	7666	Lebanon
AT	6584	Austria	FK	7075	Falkland Islands	LC	7667	Saint Lucia
AU	6585	Australia	FM	7077	Micronesia, Federated States of	LI	7673	Liechtenstein
AW	6587	Aruba	FO	7079	Faroe Islands	LK	7675	Sri Lanka
AZ	6590	Azerbaijan	FR	7082	France	LR	7682	Liberia
BA	6665	Bosnia and Herzegovina	GA	7165	Gabon	LS	7683	Lesotho
BB	6666	Barbados	GB	7166	United Kingdom	LT	7684	Lithuania
BD	6668	Bangladesh	GD	7168	Grenada	LU	7685	Luxembourg
BE	6669	Belgium	GE	7169	Georgia	LV	7686	Latvia
BF	6670	Burkina Faso	GF	7170	French Guiana	LY	7689	Libyan Arab Jamahiriya
BG	6671	Bulgaria	GH	7172	Ghana	MA	7765	Morocco
BH	6672	Bahrain	GI	7173	Gibraltar	MC	7767	Monaco
BI	6673	Burundi	GL	7176	Greenland	MD	7768	Moldova, Republic of
BJ	6674	Benin	GM	7177	Gambia	MG	7771	Madagascar
BM	6677	Bermuda	GN	7178	Guinea	MH	7772	Marshall Islands
BN	6678	Brunei Darussalam	GP	7180	Guadeloupe	MK	7775	Macedonia, The former Yugoslav Republic of
BO	6679	Bolivia	GQ	7181	Equatorial Guinea			
BR	6682	Brazil	GR	7182	Greece	ML	7776	Mali
BS	6683	Bahamas	GS	7183	South Georgia and the South Sandwich Islands	MM	7777	Myanmar
BT	6684	Bhutan				MN	7778	Mongolia
BV	6686	Bouvet Island	GT	7184	Guatemala	MO	7779	Macau
BW	6687	Botswana	GU	7185	Guam	MP	7780	Northern Mariana Islands
BY	6689	Belarus	GW	7187	Guinea-Bissau	MQ	7781	Martinique
BZ	6690	Belize	GY	7189	Guyana	MR	7782	Mauritania
CA	6765	Canada	HK	7275	Hong Kong	MS	7783	Montserrat
CC	6767	Cocos (Keeling) Islands	HM	7277	Heard Island and McDonald Islands	MT	7784	Malta
CD	6768	Congo, the Democratic Republic of the				MU	7785	Mauritius
CF	6770	Central African Republic	HN	7278	Honduras	MV	7786	Maldives
CG	6771	Congo	HR	7282	Croatia	MW	7787	Malawi
CH	6772	Switzerland	HT	7284	Haiti	MX	7788	Mexico
CI	6773	Cote d'Ivoire	HU	7285	Hungary	MY	7789	Malaysia
CK	6775	Cook Islands	ID	7368	Indonesia	MZ	7790	Mozambique
CL	6776	Chile	IE	7369	Ireland	NA	7865	Namibia
CM	6777	Cameroon	IL	7376	Israel	NC	7867	New Caledonia
CN	6778	China	IN	7378	India	NE	7869	Niger
CO	6779	Colombia	IO	7379	British Indian Ocean Territory	NF	7870	Norfolk Island
CR	6782	Costa Rica	IQ	7381	Iraq	NG	7871	Nigeria
CU	6785	Cuba	IR	7382	Iran, Islamic Republic of	NI	7873	Nicaragua
CV	6786	Cape Verde	IS	7383	Iceland	NL	7876	Netherlands
CX	6788	Christmas Island	IT	7384	Italy	NO	7879	Norway
CY	6789	Cyprus	JM	7477	Jamaica	NP	7880	Nepal
CZ	6790	Czech Republic	JO	7479	Jordan	NR	7882	Nauru
DE	6869	Germany	JP	7480	Japan	NU	7885	Niue
DJ	6874	Djibouti	KE	7569	Kenya	NZ	7890	New Zealand
DK	6875	Denmark	KG	7571	Kyrgyzstan	OM	7977	Oman
			KH	7572	Cambodia	PA	8065	Panama

Abbreviation	Code	Country	Abbreviation	Code	Country	Abbreviation	Code	Country
PE	8069	Peru	SJ	8374	Svalbard and Jan Mayen	TW	8487	Taiwan, Province of China
PF	8070	French Polynesia	SK	8375	Slovakia	TZ	8490	Tanzania, United Republic of
PG	8071	Papua New Guinea	SL	8376	Sierra Leone	UA	8565	Ukraine
PH	8072	Philippines	SM	8377	San Marino	UG	8571	Uganda
PK	8075	Pakistan	SN	8378	Senegal	UM	8577	United States Minor Outlying Islands
PL	8076	Poland	SO	8379	Somalia	US	8583	United States
PM	8077	Saint Pierre and Miquelon	SR	8382	Suriname	UY	8589	Uruguay
PN	8078	Pitcairn	ST	8384	Sao Tome and Principe	UZ	8590	Uzbekistan
PR	8082	Puerto Rico	SV	8386	El Salvador	VA	8665	Holy See (Vatican City State)
PT	8084	Portugal	SY	8389	Syrian Arab Republic	VC	8667	Saint Vincent and the Grenadines
PW	8087	Palau	SZ	8390	Swaziland	VE	8669	Venezuela
PY	8089	Paraguay	TC	8467	Turks and Caicos Islands	VG	8671	Virgin Island, British
QA	8165	Qatar	TD	8468	Chad	VI	8673	Virgin Islands, U.S
RE	8269	Reunion	TF	8470	French Southern Territories	VN	8678	Viet Nam
RO	8279	Romania	TG	8471	Togo	VU	8685	Vanuatu
RU	8285	Russian Federation	TH	8472	Thailand	WF	8770	Wallis and Futuna
RW	8287	Rwanda	TJ	8474	Tajikistan	WS	8783	Samoa
SA	8365	Saudi Arabia	TK	8475	Tokelau	YE	8969	Yemen
SB	8366	Solomon Islands	TM	8477	Turkmenistan	YT	8984	Mayotte
SC	8367	Seychelles	TN	8478	Tunisia	YU	8985	Yugoslavia
SD	8368	Sudan	TO	8479	Tonga	ZA	9065	South Africa
SE	8369	Sweden	TP	8480	East Timor	ZM	9077	Zambia
SG	8371	Singapore	TR	8482	Turkey	ZW	9087	Zimbabwe
SH	8372	Saint Helena	TT	8484	Trinidad and Tobago			
SI	8373	Slovenia	TV	8486	Tuvalu			

## In Case of Difficulty

If you encounter a problem, please turn the power off, then on again. If the unit is still not functioning normally, please review the items in the following checklist. This guide will help you isolate the problem if the unit is at fault. Otherwise, make sure the rest of your system is properly connected, or then consult your authorized Alpine dealer.

### Basic

#### No function or display.

- Vehicle's ignition is off.
  - If connected according to the instructions, the unit will not operate with the vehicle's ignition off.
- Improper power lead connections.
  - Check power lead connections.
- Blown fuse.
  - Check the fuse on the battery lead of the unit; replace with the proper value if necessary.
- Internal micro-computer malfunctioned due to interference noise, etc.
  - Press the RESET switch with a ballpoint pen or other pointed article.

#### No sound or unnatural sound.

- Incorrect setting of volume/balance/fader controls.
  - Readjust the controls.
- Connections are not properly or securely made.
  - Check the connections and firmly connect.

#### Screen not displayed.

- Brightness/Contrast control is set at the minimum position.
  - Adjust the Brightness/Contrast control.
- Temperature in the vehicle is too low.
  - Increase the vehicle's interior temperature to operation temperature range.
- Connections to the DVD, navigation system are not securely made.
  - Check the connections and firmly connect.
- The Parking Brake Lead is not connected.
- The Parking Brake is not engaged.
  - Connect the Parking Brake Lead, then engage the Parking Brake. (See page 87)

#### Movement of displayed picture is abnormal.

- Temperature in the vehicle is too high.
  - Allow the vehicle's interior temperature to cool.

#### Alpine Navigation system inoperative.

- Connections to the navigation system are incorrect.
  - Check the connections with the navigation system and connect the cables correctly and firmly.

#### The optional remote control is inoperative.

- The remote control sensor setting of "Remote Sensor Setting" (page 46) is not set to this unit ("Front").
  - Set for "Front."

### Radio

#### Unable to receive stations.

- No antenna, or open connection in the antenna cable.
  - Make sure the antenna is properly connected; replace the antenna or cable if necessary.

#### Unable to tune stations in the seek mode.

- You are in a weak signal area.
  - Make sure the tuner is in DX mode.
- If the area you are in is a primary signal area, the antenna may not be grounded and connected properly.
  - Check your antenna connections; make sure the antenna is properly grounded at its mounting location.
- The antenna may not be the proper length.
  - Make sure the antenna is fully extended; if broken, replace the antenna with a new one.

#### Broadcast is noisy.

- The antenna is not the proper length.
  - Extend the antenna fully; replace it if it is broken.
- The antenna is poorly grounded.
  - Make sure the antenna is grounded properly at its mounting location.
- The station signal is weak and noisy.
  - If above solution does not work, tune in another station.

### Disc

#### Disc playback sound is wavering.

- Moisture condensation in the disc Module.
  - Allow enough time for the condensation to evaporate (about 1 hour).

#### Disc insertion not possible.

- A disc is already in this unit.
  - Eject the disc and remove it.
- The disc is being improperly inserted.
  - Insert the disc correctly. (See page 16)

#### Unable to fast forward or backward the disc.

- The disc has been damaged.
  - Eject the disc and discard it; using a damaged disc in your unit can cause damage to the mechanism.

#### Disc playback sound skips due to vibration.

- Improper mounting of the unit.
  - Securely re-mount the unit.
- Disc is very dirty.
  - Clean the disc.
- Disc has scratches.
  - Change the disc.
- The pick-up lens is dirty.
  - Do not use a commercially available lens cleaner disc. Consult your nearest Alpine dealer.


#### Disc playback sound skips without vibration.

- Dirty or scratched disc.
  - Clean the disc; a damaged disc should be replaced.

#### CD-R/CD-RW/DVD-R/DVD-RW/DVD+R/DVD+RW playback not possible.

- Close session (finalization) has not been performed.
  - Perform finalization and attempt playback again.

#### Error displays.

- Mechanical error.
  - Touch [  Disc ] on the Open/Tilt screen. After the error indication disappears, insert the disc again. If the above-mentioned solution does not solve the problem, consult your nearest Alpine dealer.

#### MP3/WMA/AAC is not played back.

- Writing error occurred. The CD format is not compatible.
  - Make sure the CD has been written in a supported format. Refer to "About MP3/WMA/AAC" (pages 26 to 27), then rewrite in the format supported by this device.



**Unit does not operate.**

- Condensation.
  - Wait a while (about 1 hour) for the condensation to dry.

**Playback does not start.**

- Disc is loaded upside-down.
  - Check the disc and load it with the labeled side facing upward.
- Disc is dirty.
  - Clean the disc.
- A disc not able to play back with this unit is loaded.
  - Check if the disc is able to be played back.
- Parental lock is set.
  - Cancel the parental lock or change the rating level.

**Picture is unclear or noisy.**

- Disc is being fast-forwarded or fast-reversed.
  - The picture may be slightly disturbed, but this is normal.
- Vehicle's battery power is weak.
  - Check the battery power and wiring.  
(The unit may malfunction if the battery power is under 11 volts with a load applied.)

**Image stops sometimes.**

- Disc is scratched.
  - Replaced with a non-scratched disc.

---

## If this Message Appears

---

Various messages are displayed on the screen during operation. In addition to the messages telling you the current status or providing guidance for the next operation, there are also the following error messages. If one of these error messages is displayed, carefully follow the instructions in the solution column.

**System****Unable to operate while driving.**

- A setup operation, etc., was carried out while the vehicle was running.
  - Move the vehicle to a safe location, stop, and engage the parking brake, then carry out this operation.

---

**USB current error.**

- Abnormal current is run to the USB connector device.
  - Turn the ignition key off, and then set to ON again.
  - Attempt to connect another iPod/iPhone/USB memory device.

---

**Unable to access the DVD drive.****The system will reset.**


- An access error to DVD drive occurred for some reasons.
  - The unit is rebooted automatically.

---

**Unable to access the DVD drive.****Please inquire details from the service center.**

- An access error to DVD drive occurred for some reasons.
    - Please ask Service Centre for help.
- 

**Audio/Visual****Read error.****Please check the Disc.**

- Scratched disc, contaminated disc/poor recording/disc incompatible with this unit.
    - Touch [  Disc ] on the Open/Tilt screen.
    - Change the disc.
- 

**USB device error.**

- An iPod/iPhone that is not supported by the unit is connected.
    - Connect an iPod/iPhone that is supported by the unit.
    - Reset the iPod.
  - A USB device that is not supported by the unit is connected.
    - Attempt to connect another USB memory device.
  - Communication error.
    - Turn the ignition key off, and then set to ON again.
    - Check the display by reconnecting between the iPod/iPhone and the unit, using the iPod/iPhone cable.
    - Check the display by reconnecting between the USB memory device and the unit.
  - Caused by the iPod/iPhone Software Version not being compatible with this unit.
    - Update the iPod/iPhone Software Version to be compatible with this unit.
  - The iPod/iPhone is not verified.
    - Change another iPod/iPhone.
- 

**Region code violation.**

- Disc does not match regional code number.
    - Load a disc that matches the regional code number.
- 

**No data.**

- There are no data in the iPod/iPhone.
    - Download data to the iPod/iPhone and connect to the ICS-X8.
  - There are no data in the USB memory.
    - Download data to the USB memory and connect to this unit.
- 

**Un-readable song was skipped.**

- A copy-protected WMA file has been detected.
    - You can only play back non-copy-protected files.
  - A sampling rate/bit rate not supported by the unit is used.
    - Use a sampling rate/bit rate supported by the unit.
- 

**BLUETOOTH****Please check BLUETOOTH audio device.**

- The BLUETOOTH audio device was not connected correctly.
    - Check the settings for ICS-X8 and the BLUETOOTH audio device and reconnect.
- 

**Please check mobile device.**

- The mobile phone was not connected correctly.
    - Check the settings for ICS-X8 and the mobile phone and reconnect.
-

#### **Unable to download phonebook.**

- Phonebook failed to read due to mobile phone disconnection, etc.
    - Check the mobile phone connection, and then conduct synchronizing and adding again. (See page 55)
  - The connected mobile phone does not support synchronising of its phone book.
    - Connect the mobile phone that supports synchronising the phone book, then synchronise again. (See page 55)
- 

#### **Playing back a DRM protected DivX File**

Some operations cannot be performed while displaying the following message.

##### **Authorization Error.**

##### **This player is not authorized to play this video.**

- The version of the DRM protected DivX<sup>®</sup> File is not supported by this unit.
    - Play the supported DivX<sup>®</sup> File.
- 

##### **Rental Expired.**

- The file being attempted to play has a limited number of viewings. The viewing limit has been reached and can no longer be played on this device. After the message has been displayed, the beginning of the next file will automatically be played back.
- 

##### **This DivX rental has used XX out of YY views.**

##### **Continue?**

- If the total number of viewings for this file has not been exceeded, the views remaining is displayed.
    - To play back, select [YES]. If the next file is to be played back, select [NO].
- 

##### **Do you wish to stop playing rental file?**

- While playing back a rental file, "Do you wish to stop playing rental file?" is displayed when the following operations are performed. Selecting [YES], reduces the number of views by 1.
    - Folder Up/Down
    - STOP
    - Search operation
    - Move to the first/last DivX<sup>®</sup> file by Chapter Up/Down
    - To interrupt the playback, touch [YES], or touch [NO] to not interrupt.
- 

##### **Audio format not supported.**

- The file being played is a DivX<sup>®</sup> file with an unsupported audio format, so only the video data is played.
    - Play a DivX<sup>®</sup> file with a supported audio format.
- 

##### **Video framerate not supported.**

- The file being played is a DivX<sup>®</sup> file with an unsupported frame rate.
    - Play a DivX<sup>®</sup> file with a supported frame rate.
- 

##### **Video resolution not supported.**

- The file being played is a DivX<sup>®</sup> file with an unsupported resolution.
    - Play a DivX<sup>®</sup> file with a supported resolution.
-

# Specifications

## MONITOR SECTION

Screen Size	7.0"
LCD Type	Transparent type TN LCD
Operation System	TFT active matrix
Number of Picture Elements	1,152,000 pcs. (800 × 3 × 480)
Effective Number of Picture Elements	99% or more
Illumination System	LED

## FM TUNER SECTION

Tuning Range	87.5 – 108.0 MHz
Mono Usable Sensitivity	8.1 dBf (0.7 $\mu$ V/75 ohms)
50 dB Quieting Sensitivity	12 dBf (1.1 $\mu$ V/75 ohms)
Alternate Channel Selectivity	80 dB
Signal-to-Noise Ratio	65 dB
Stereo Separation	35 dB
Capture Ratio	2.0 dB

## MW TUNER SECTION

Tuning Range	531 – 1,602 kHz
Usable Sensitivity	25.1 $\mu$ V/28 dBf

## LW TUNER SECTION

Tuning Range	153 – 281 kHz
Sensitivity (IEC Standard)	31.6 $\mu$ V/30 dBf

## USB SECTION

USB requirements	USB 1.1/2.0
Max. Power Consumption	1,000 mA
USB Class	USB (Play From Device)/ USB (Mass Storage Class)
File System	FAT12/16/32
MP3 Decoding	MPEG-1/2 AUDIO Layer-3
WMA Decoding	Windows Media™ Audio
AAC Decoding	AAC-LC format “.m4a” file
Number of Channels	2-Channel (Stereo)
Frequency Response*	5-20,000 Hz ( $\pm$ 1 dB)
Total Harmonic Distortion	0.008% (at 1 kHz)
Dynamic Range	95 dB (at 1 kHz)
Signal-to-Noise Ratio	100 dB
Channel Separation	85 dB (at 1 kHz)

\* Frequency response may differ depending on the encoder software/bit rate.

## CD/DVD SECTION

Frequency Response	5 – 20,000 Hz ( $\pm$ 1 dB)
Wow & Flutter (% WRMS)	Below measurable limits
Total Harmonic Distortion	0.008% (at 1 kHz)
Dynamic Range	95 dB (at 1 kHz)
Channel Separation	85 dB (at 1 kHz)
Signal system	NTSC/PAL
Horizontal resolution	500 lines or greater
Video output level	1Vp-p (75 ohms)
Video S/N ratio	DVD: 60 dB
Audio S/N ratio	100 dB

## PICKUP

Wave length	DVD: 666 nm CD: 785 nm
Laser power	CLASS II

## GPS SECTION

GPS Reception frequency	1575.42 $\pm$ 1 MHz
GPS Reception sensitivity	-130 dB max.

## BLUETOOTH SECTION

BLUETOOTH Specification	Bluetooth V2.1+EDR
Output Power	+4 dBm Max. (Power class 2)
Profile	HFP (Hands-Free Profile) OPP (Object Push Profile) PBAP (Phone Book Access Profile) A2DP (Advanced Audio Distribution Profile) AVRCP (Audio/Video Remote Control Profile)

## GENERAL

Power Requirement	14.4 V DC (11–16 V allowable)
Operating temperature	-4°F to +140°F (-20°C to + 60°C)
Maximum Power Output	50 W $\times$ 4
Output Voltage	4,000 mV/10k ohms
Weight	2.6 kg (5 lbs. 12 oz)
Audio output level	
Preout (Front, Rear):	4V/10k ohms (max.)
Preout (Subwoofer):	4V/10k ohms (max.)
AUX OUT:	1.2V/10k ohms

## CHASSIS SIZE

Width	178 mm (7")
Height	100 mm (3-7/8")
Depth	159 mm (6-1/4")

- Due to continuous product improvement, specifications and design are subject to change without notice.
- The LCD panel is manufactured using an extremely high precision manufacturing technology. Its effective pixel ratio is over 99.99%. This means that there is a possibility that 0.01% of the pixels could be either always ON or OFF.

## CAUTION

**CLASS 1  
LASER PRODUCT**

(Bottom side of player)

CAUTION-Laser radiation when open, DO NOT STARE INTO BEAM

(Bottom side of player)

# Installation and Connections

Before installing or connecting the unit, please read the following and pages 7 to 11 of this manual thoroughly for proper use.

## Warning

### **MAKE THE CORRECT CONNECTIONS.**

Failure to make the proper connections may result in fire or product damage.

### **USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.**

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

### **BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY TERMINAL.**

Failure to do so may result in electric shock or injury due to electrical shorts.

### **DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING OBJECTS.**

Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, gear lever, brake pedals, etc. can be extremely hazardous.

### **DO NOT SPLICE INTO ELECTRICAL CABLES.**

Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

### **DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.**

When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire.

### **DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS.**

Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire etc.

### **KEEP SMALL OBJECTS SUCH AS SCREWS OUT OF THE REACH OF CHILDREN.**

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

### **DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT.**

Doing so may obstruct forward vision or hamper movement etc. and results in serious accident.

## Caution

### **HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.**

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

### **USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.**

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

### **ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.**

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

### **DO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR DUST.**

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

## Precautions

- Be sure to disconnect the cable from the (–) battery post before installing your ICS-X8. This will reduce any chance of damage to the unit in case of a short-circuit.
- Be sure to connect the colour coded leads according to the diagram. Incorrect connections may cause the unit to malfunction or damage to the vehicle's electrical system.
- When making connections to the vehicle's electrical system, be aware of the factory installed components (e.g. on-board computer). Do not tap into these leads to provide power for this unit. When connecting the ICS-X8 to the fuse box, make sure the fuse for the intended circuit of the ICS-X8 has the appropriate amperage. Failure to do so may result in damage to the unit and/or the vehicle. When in doubt, consult your Alpine dealer.
- The ICS-X8 uses female RCA-type jacks for connection to other units (e.g. amplifier) having RCA connectors. You may need an adaptor to connect other units. If so, please contact your authorized Alpine dealer for assistance.
- Be sure to connect the speaker (–) leads to the speaker (–) terminal. Never connect left and right channel speaker cables to each other or to the vehicle body.
- The Display must be completely retracted in the casing when installing. If it is not, problems may occur.
- When installing in automobiles, make sure the Display can open/close without coming in contact with the gear shift.

#### **IMPORTANT**

Please record the serial number of your unit in the space provided below and keep it as a permanent record. The serial number plate is located on the bottom of the unit.

SERIAL NUMBER: \_\_\_\_\_

INSTALLATION DATE: \_\_\_\_\_


INSTALLATION TECHNICIAN: \_\_\_\_\_

PLACE OF PURCHASE: \_\_\_\_\_

## Installation


### Caution

Do not block the unit's fan or heat sink, thus preventing air circulation. If blocked, heat will accumulate inside the unit and may cause a fire.




### Caution concerning the installation location

- 1 Before installing, make sure that the opening and closing of the display will not interfere with operation of the gear shift.



### 2 Angle of installation

Install at an angle between horizontal and 30°. Note that installing at an angle outside of this range will result in a loss of performance and possibly damage.




### 3 Mounting the Microphone.


For safe use, make sure of the following:

- location is stable and firm.
- driver's view and operations are not obstructed.
- microphone is located where the driver's voice can be easily picked up (on the sun visor, etc.).

When you speak into the microphone, you should not have to change your driving posture. This may cause a distraction, taking your attention away from safely driving your vehicle. Carefully consider direction and distance while mounting the microphone. Confirm that the driver's voice can be easily picked up at the selected location.




- 4 Remove the mounting sleeve from the main unit (see "Removal" on page 85). Slide the unit into the mounting sleeve and secure it.



\*1 If the installed mounting sleeve is loose in the dashboard, the pressure plates may be bent slightly to remedy the problem.

\*2 The supplied face plate may be mounted.

- 5** When your vehicle has the Bracket, mount the long hex bolt onto the rear panel of the ICS-X8 and put the Rubber Cap on the hex bolt. If your vehicle does not have the Mounting Support, reinforce the head unit with the metal mounting strap (not supplied). Secure the ground lead of the unit to a clean metal spot using a screw (\*1) already attached to the vehicle's chassis. Connect all the leads of the ICS-X8 according to details described in the CONNECTION section.




- For the screw marked “\*2,” use an appropriate screw for the chosen mounting location.

- 6** Slide the ICS-X8 into the dashboard until it clicks. This ensures that the unit is properly locked and will not accidentally come out from the dashboard.

## Removal


1. Insert the bracket keys into the unit, along the guides on either side. The unit can now be removed from the mounting sleeve.



2. Pull the unit out, keeping it unlocked as you do so.

### Connection Diagram of SPST Switch (sold separately)

(If the ACC power supply is not available)




- If your vehicle has no ACC power supply, add an SPST (Single-Pole, Single-Throw) switch (sold separately) and fuse (sold separately).
- The diagram and the fuse amperage shown above are in the case when ICS-X8 is used individually.
- If the switched power (ignition) lead of the ICS-X8 is connected directly to the positive (+) post of the vehicle's battery, the ICS-X8 draws some current (several hundred milliamperes) even when its switch is placed in the OFF position, and the battery may be discharged.

#### **To prevent external noise from entering the audio system.**

- Locate the unit and route the leads at least 10 cm away from the car harness.
- Keep the battery power leads as far away from other leads as possible.
- Connect the ground lead securely to a bare metal spot (remove any paint, dirt or grease if necessary) of the car chassis.
- If you add an optional noise suppressor, connect it as far away from the unit as possible. Your Alpine dealer carries various noise suppressors, contact them for further information.
- Your Alpine dealer knows best about noise prevention measures so consult your dealer for further information.

# Connections






- ① **Radio Antenna Receptacle**
- ② **ISO/JASO Antenna Adapter (sold separately)**  
ISO/JASO Antenna Adapter may be required, depending on the vehicle.
- ③ **Remote Control Output Lead (Brown)**  
Connect this lead to the remote control input lead. This lead outputs the controlling signals from the remote control.
- ④ **Remote Control Input Lead (Brown)**  
Connect the external Alpine product to the remote control output lead.
- ⑤ **Reverse Lead (Orange/White)**  
Connect to the plus side of the car's reverse lamp. This lamp illuminates when the transmission is shifted into reverse (R).  
With this lead properly wired, the video picture automatically switches to the rear camera whenever the car is put into reverse (R).
- ⑥ **Direct CAMERA Input Connector**  
Use when the optional direct camera is connected.
- ⑦ **CAMERA Input RCA Connector (Yellow)**  
*\* Not used for this unit.*
- ⑧ **Camera Switch Lead**  
*\* Not used for this unit.*
- ⑨ **Video Input Connector (AUX INPUT) (Yellow)**  
Input the video.
- ⑩ **Audio Input Connectors (AUX INPUT)**  
RED is right and WHITE is left input the audio.
- ⑪ **Video Output Connector (AUX OUTPUT) (Yellow)**  
Output the video.
- ⑫ **Audio Output Connectors (AUX OUTPUT)**  
RED is right and WHITE is left output the audio.
- ⑬ **Rear Output RCA Connectors**  
It can be used as Rear Output RCA Connectors. RED is right and WHITE is left.
- ⑭ **Front Output RCA Connectors**  
It can be used as Front Output RCA Connectors. RED is right and WHITE is left.
- ⑮ **Subwoofer RCA Connectors**  
RED is right and WHITE is left.
- ⑯ **RCA Extension Cable (sold separately)**
- ⑰ **Steering Remote Control Interface Connector**  
To steering remote control interface box.  
For details about connections, consult your nearest Alpine dealer.
- ⑱ **RGB Input Terminal**  
Connect this to the RGB output terminal of the Navigation System.
- ⑲ **iPod VIDEO Input Connector**  
Input the iPod/ iPhone video signal or AUX video/audio signal.
  - Set "AUX3 In Sel." (page 49) to "iPod Video" when an iPod/iPhone is connected.
  - Set "AUX3 In Sel." (page 49) to "AUX3" when AUX video/ audio is input.
- ⑳ **GPS antenna Receptacle**  
Connect to separately sold GPS antenna. Installing the antenna in the best area for receiving GPS transmissions will aid in acquiring Nokia Phone GPS data.
- ㉑ **Vehicle Display Interface Connector**  
Outputs Vehicle Display Interface control signals. Connect this to the optional Vehicle Display Interface box.  
For details about connections, consult your nearest Alpine dealer.
- ㉒ **USB Connector (USB1)**  
To USB Memory, iPod/iPhone or Nokia Phone.
- ㉓ **USB Connector (USB2)**  
To USB Memory, iPod/iPhone or Nokia Phone.
- ㉔ **MIC Input Connector**  
To Microphone (Included).
- ㉕ **Power Supply Connector**
- ㉖ **Remote Turn-On Lead (Blue/White)**  
Connect this lead to the remote turn-on lead of your amplifier or signal processor.
- ㉗ **Audio Interrupt In Lead (Pink/Black)**  
*\* Not used for this unit.*
- ㉘ **Parking Brake Lead (Yellow/Blue)**  
Connect this lead to the power supply side of the parking brake switch to transmit the parking brake status signals to the ICS-X8.
- ㉙ **ISO Power Supply Connector**
- ㉚ **Switched Power Lead (Ignition) (Red)**  
Connect this lead to an open terminal on the vehicle's fuse box or another unused power source which provides (+) 12V only when the ignition is turned on or in the accessory position.
- ㉛ **Ground Lead (Black)**  
Connect this lead to a good chassis ground on the vehicle. Make sure the connection is made to bare metal and is securely fastened using the sheet metal screw provided.
- ㉜ **Power Antenna Lead (Blue)**  
Connect this lead to the +B terminal of your power antenna, if applicable.
  - *This lead should be used only for controlling the vehicle's power antenna. Do not use this lead to turn on an amplifier or a signal processor, etc.*
- ㉝ **Battery Lead (Yellow)**  
Connect this lead to the positive (+) post of the vehicle's battery.
- ㉞ **Fuse Holder (10A)**
- ㉟ **ISO Connector (Speaker Output)**
- ㊱ **Left Rear (+) Speaker Output Lead (Green)**
- ㊲ **Left Rear (-) Speaker Output Lead (Green/Black)**
- ㊳ **Left Front (+) Speaker Output Lead (White)**
- ㊴ **Left Front (-) Speaker Output Lead (White/Black)**
- ㊵ **Right Front (-) Speaker Output Lead (Grey/Black)**
- ㊶ **Right Front (+) Speaker Output Lead (Grey)**
- ㊷ **Right Rear (-) Speaker Output Lead (Violet/Black)**
- ㊸ **Right Rear (+) Speaker Output Lead (Violet)**
- ㊹ **CAMERA Connector**
- ㊺ **AUX/PRE OUT Connector**


## System Example

### Connection of a USB Memory, NOKIA Phone



- Attach USB extension cables (L type) to the USB1 connector of the this unit and USB extension cables (I type) to the USB2 connector of the this unit.
- Do not leave USB memory, Nokia Phone in a vehicle for a long time. Heat and humidity may damage the USB memory, Nokia Phone.
- iPods, iPhones, USB memory devices, and Nokia Phones are connectable with a USB connector. Both USB1 and USB2 can receive connections in the same way. However, you cannot connect 2 iPod/iPhone units or 2 Nokia Phones.


### Connection of an iPod/iPhone



\*1 If iPod VIDEO is supported, use the iPod VIDEO extension cable.

- Attach USB extension cables (L type) to the USB1 connector of the this unit and USB extension cables (I type) to the USB2 connector of the this unit.
- To connect an iPod/iPhone, an optional connection kit KCU-461iV is required.
- Do not leave an iPod/iPhone in a vehicle for a long time. Heat and humidity may damage the iPod/iPhone and you may not be able to play it again.
- iPods, iPhones, USB memory devices, and Nokia Phones are connectable with a USB connector. Both USB1 and USB2 can receive connections in the same way. However, you cannot connect 2 iPod/iPhone units or 2 Nokia Phones.

## Connection of an External device



① **Video/Audio Input Connectors (AUX INPUT)**

② **Video/Audio Output Connectors (AUX OUTPUT)**

Use when connecting an optional monitor etc.

③ **RCA Extension Cable (Sold Separately)**

④ **Remote Control Input Lead (Brown)**


Connect this lead to the remote control output lead. This lead inputs the controlling signals from the remote control.

⑤ **Remote Control Output Lead (Brown)**

Connect this lead to the remote control input lead. This lead outputs the controlling signals from the remote control.


- You can change the name of an external device. Refer to "Setting the AUX Mode" (page 48).

111



- You can connect one more external input device only when the “Primary Name” is set to “DVB-T” or “USB Player.” Refer to “Setting the Primary AUX Name” (page 48).
- To connect an external input device to the iPod VIDEO connector, set “AUX3 In Sel.” to “AUX3.” Refer to “Setting the AUX3” (page 49).

## Connection of an External Amplifier



### ① Front Output RCA Connectors

RED is right and WHITE is left.


### ② Rear Output RCA Connectors

RED is right and WHITE is left.

### ③ Subwoofer RCA Connector


### ④ RCA Extension Cable (Sold separately)

## Connection of camera and Alpine Navigation system



- ① RGB Cable (Included with Navigation)
- ② Direct CAMERA Input Connector
- ③ Camera extension cable (Included with direct rearview camera)

## Connection of HCE-C300R



- ① Direct CAMERA Input Connector
- ② Monitor connector extension cable (Included with HCE-C300R)

## DECLARATION of CONFORMITY For



Product: Bluetooth PWB  
Model: ICS-X8 BT PWB

**Supplied by**  
Alpine Electronics, Inc.,  
20-1 Yoshima-Kogyodanchi, Iwaki-City  
Fukushima, Japan

**Technical Construction File held by**  
Alpine Electronics, Inc.,  
20-1 Yoshima-Kogyodanchi, Iwaki-City  
Fukushima, Japan

**R&TTE Directive**  
**(Article 3.1(a) Safety)**

**Standard used for comply**  
EN 60950-1: 2006 + Amd.1: 2010 (incl. Amd.11:2009)

**R&TTE Directive**  
**(Article 3.1(b) EMC)**

EN 301 489-1 V1.8.1: 2008-04  
EN 301 489-17 V2.1.1: 2009-05  
ISO7637-2: 2004

**R&TTE Directive**  
**(Article 3.2 Spectrum)**

EN 300 328 V1.7.1: 2006-10

### Means of Conformity

We declare under our sole responsibility that the Product (s) is conformity with the essential requirements and other relevant requirements of the Radio and Telecommunication Terminal Equipment (R&TTE) Directive (1999/5/EC).

**Date:** 26 April 2011

**Signature of Responsible Person:**

Isamu Takaku

Isamu Takaku  
Global Engineering Strategy Office



# IZJAVA O SUKLADNOSTI

Ronis d.o.o.

<Ime(naziv) pravne/fizičke osobe odgovorne za uvoz i/ili stavljanje na tržište>

ADRESA:

Josipa Kozarca 3, Čakovec 40000, Croatia

MATIČNI BROJ SUBJEKTA (MBS):

***Pod punom odgovornošću izjavljujemo da je radijska oprema i  
telekomunikacijska terminalna (RiTT) oprema***

OPIS OPREME:	INTEGRATED CLOUD SYSTEM
TIPSKA OZNAKA OPREME:	ICS-X8
MARKETINŠKO IME OPREME:	ALPINE
PROIZVOĐAČ OPREME:	Alpine Electronics, Inc.

***sukladna s bitnim zahtjevima iz članka 4. Pravilnika o radijskoj opremi i  
telekomunikacijskoj opremi ("Narodne Novine", br. 112/2008), odnosno  
primjenjenim normama:***

<Dodati popis normi>

EN300 328 V1.7.1 (2006-10)

EN55013

EN55020

EN60950-1: 2006 + Amd. 1: 2010+Amd.11: 2009

Čakovec, 26.07.2011.  
Mjesto i datum

**Ronis**  
Ronis d.o.o. Josipa Kozarca 3, 40000 Čakovec  
www.ronis.hr Tel: 040 396 039, OIB: 21720746203

Žig i potpis odgovorne osobe